

# **SV414**

# **SHOP MANUAL**

**SAKAI®**

3498-64214-0



# Introduction

This manual provides important information to familiarize you with safe operating and maintenance procedures for your SAKAI roller. Even though you may be familiar with similar equipment you must read and understand this manual before operating or servicing this unit.

Safety is everyone's business and it is one of your primary concerns. Knowing the guidelines presented in this manual will help provide for your safety, for the safety of those around you and for the proper operation and maintenance of the machine. Improper operation is dangerous and can result in injury or death.

Sakai Heavy Industries cannot foresee all possible circumstances or varying conditions to which the operator, serviceman or machine may be exposed to that might lead to a potential hazard. Therefore, the warnings and cautions listed in this manual and those placed on the machine are not intended to be all inclusive and liability for personal injury or damage to equipment or property cannot be assumed.

All information, specifications and illustrations in this publication are based on the product information available at the time that the publication was written. The contents may change without prior notice due to modifications of the model.



# CONTENTS

## 1. SAFETY

### 1. GENERAL SAFETY

1-1. Understanding the Safety Symbols and Words .....	1-001
1-2. General .....	1-001
1-3. Qualifications of Operators and Maintenance Personnel .....	1-002
1-4. Safety Practices and Policies .....	1-002
1-5. Pre Start Inspection .....	1-003
1-6. Safety Instructions .....	1-003
1-7. Starting .....	1-004
1-8. Operating .....	1-004
1-9. Stopping .....	1-004
1-10. Maintenance .....	1-005
1-11. Transporting the Machine .....	1-007

## 2. SPECIFICATIONS

### 1. SPECIFICATION DATA

1-1. SV414D .....	2-001
1-2. SV414T .....	2-003
1-3. SV414TF .....	2-005
1-4. Common Specifications .....	2-007

### 2. TABLE OF STANDARD VALUES

2-1. Engine .....	2-008
2-2. Propulsion .....	2-008
2-3. Hydraulic System .....	2-008
2-4. Steering .....	2-009
2-5. Brakes .....	2-009
2-6. Capacities .....	2-009

### 3. FUEL AND LUBRICANTS SPECIFICATION

3-1. Rating .....	2-010
3-2. Recommended Lubricants .....	2-010

### 4. TIGHTENING TORQUE CHART .....

2-011

### 3. ENGINE AND CONTROLS

1. ENGINE	
1-1. Engine Mount .....	3-001
2. FUEL SYSTEM .....	3-002
3. CONTROL SYSTEM	
3-1. Forward-reverse Control .....	3-004
4. PUMP MOUNT	
4-1. Pump Mount.....	3-005
4-1-1. Installation of pump .....	3-006

### 4. HYDRAULIC SYSTEMS

1. SYSTEM CIRCUIT DIAGRAM	
1-1. Graphic Symbols for Hydraulic Circuits .....	4-001
1-2. Hydraulic Circuit Diagram.....	4-003
2. PROPULSION HYDRAULIC SYSTEM	
2-1. Propulsion Hydraulic Piping.....	4-004
2-1-1. Propulsion hydraulic piping (F).....	4-004
2-1-2. Propulsion hydraulic piping (R) .....	4-005
2-2. Hydraulic Component Specifications .....	4-006
2-2-1. Hydraulic pump ASSY (propulsion + vibrator + steering + charge).....	4-006
2-2-2. Propulsion hydraulic motor (F) .....	4-008
2-2-3. Gear box.....	4-010
2-2-4. Propulsion hydraulic motor (R).....	4-012
2-2-5. Speed change solenoid valve (F) .....	4-014
2-2-6. Block (1) .....	4-015
2-2-7. Block (2) .....	4-016
2-3. Description and Operation of Propulsion System.....	4-018
3. VIBRATOR HYDRAULIC SYSTEM	
3-1. Vibrator Hydraulic Piping.....	4-021
3-2. Hydraulic Component Specifications .....	4-022
3-2-1. Vibrator hydraulic motor .....	4-022
3-3. Description and Operation of Vibrator System .....	4-024
4. STEERING SYSTEM	
4-1. Steering Hydraulic Piping .....	4-025
4-2. Steering Wheel.....	4-026
4-3. Hydraulic Component Specifications .....	4-027
4-3-1. Orbitrol.....	4-027

4-4. Description and Operation of Steering System.....	4-029
4-4-1. Description and operation of steering system.....	4-029
4-4-2. Structure and operation of Orbitrol.....	4-030

## 5. ELECTRICAL SYSTEM

### 1. PRECAUTIONS FOR WORK

1-1. Wire Numbers, Wire Sizes, Wire Colors and Connectors Shown in Electrical Circuit Diagram, Wiring Harness Layout and Wiring Harnesses.....	5-001
1-2. Electrical Equipment Installation.....	5-002

### 2. SYSTEM CIRCUIT DIAGRAM

2-1. Electrical Circuit Diagram.....	5-003
--------------------------------------	-------

### 3. ELECTRICAL COMPONENTS

3-1. Wiring Harness Layout (1).....	5-004
3-2. Wiring Harness Layout (2).....	5-005

### 4. WIRING HARNESES

4-1. Frame Harness (1).....	5-006
4-2. Frame Harness (2).....	5-008
4-3. Panel Harness.....	5-010
4-4. Fuse • Relay Box Assembly.....	5-012
4-5. Battery Relay Harness.....	5-014
4-6. Stater Switch Harness.....	5-016
4-7. Control Switch Harness.....	5-017
4-8. Throttle Switch Harness.....	5-018
4-9. Vibration Switch Harness.....	5-019
4-10. Control Harness.....	5-020
4-11. F-R Lever Vibration Switch Harness.....	5-021
4-12. Speed Change Solenoid Harness.....	5-022
4-13. Vibrator Solenoid Harness.....	5-023
4-14. Diagnostic Switch Harness.....	5-024
4-15. Hydraulic Oil Filter Harness.....	5-025
4-16. Engine Harness.....	5-026
4-17. Backup Buzzer Harness.....	5-027

### 5. ELECTRICAL COMPONENT SPECIFICATIONS

5-1. Fuse Box.....	5-028
5-2. Combination Meter.....	5-029

## 6. VIBRATORY DRUM • REAR AXLE

1. PRECAUTIONS FOR DISASSEMBLY AND REASSEMBLY	6-001
2. VIBRATORY DRUM	
2-1. Removal and Installation of Vibratory Drum	6-003
2-1-1. Removal of vibratory drum	6-003
2-1-2. Installation of vibratory drum	6-006
3. VIBRATORY DRUM ASSY	
3-1. Vibratory Drum ASSY	6-007
3-2. Disassembly and Reassembly of Vibratory Drum	6-008
3-2-1. Disassembly of vibratory drum	6-008
3-2-2. Reassembly of vibratory drum	6-019
4. REAR AXLE	
4-1. Rear Axle ASSY	6-038
4-2. Rear Axle Lubrication	6-039
4-3. Rear Axle Structure	6-040
4-3-1. Center housing	6-040
4-3-2. Differential	6-041
4-3-3. Hub reduction gear	6-042
4-3-4. Brake	6-043

## 7. BRAKE

1. BRAKE PEDAL	7-001
2. BRAKE HYDRAULIC PIPING	7-002
3. BRAKE SYSTEM	
3-1. Description and Operation of Brake Circuit	7-003
4. HYDRAULIC COMPONENT SPECIFICATIONS	
4-1. Parking Brake Solenoid Valve	7-004
4-2. Servo Bypass Solenoid Valve	7-005

## 8. INSPECTION AND ADJUSTMENT

1. INSPECTION AND ADJUSTMENT	
1-1. Safety Precautions for Inspection and Adjustment	8-001
1-2. Preparation for Inspection and Adjustment	8-001
1-3. Precautions for Inspection and Adjustment	8-001
1-4. Warm-up	8-001
1-5. Inspection and Adjustment of Engine Related Items	8-001



2. MEASUREMENT AND ADJUSTMENT OF PROPULSION CIRCUIT PRESSURE	
2-1. Measurement	8-002
2-2. Adjustment	8-003
3. MEASUREMENT AND ADJUSTMENT OF PROPULSION CHARGE CIRCUIT PRESSURE	
3-1. Measurement	8-005
3-2. Adjustment	8-006
4. MEASUREMENT OF PROPULSION SERVO CIRCUIT PRESSURE	
4-1. Measurement	8-007
5. MEASUREMENT OF MACHINE HIGH/LOW SPEED CHANGE CIRCUIT PRESSURE	
5-1. Measurement of Propulsion Motor (F)	8-008
5-2. Measurement of Propulsion Motor (R)	8-009
6. MEASUREMENT OF PARKING BRAKE RELEASE PRESSURE	
6-1. Measurement	8-010
7. MEASUREMENT AND INSPECTION OF VIBRATOR CIRCUIT PRESSURE	
7-1. Measurement	8-011
7-2. Inspection	8-012
8. MEASUREMENT AND ADJUSTMENT OF VIBRATOR CHARGE CIRCUIT PRESSURE	
8-1. Measurement	8-014
8-2. Adjustment	8-015
9. MEASUREMENT OF VIBRATOR HIGH/LOW CHANGE CIRCUIT PRESSURE	
9-1. Measurement	8-016
10. MEASUREMENT AND INSPECTION OF STEERING CIRCUIT PRESSURE	
10-1. Measurement	8-017
10-2. Inspection	8-018
11. MEASUREMENT OF PROPULSION PUMP CASE PRESSURE	
11-1. Measurement	8-019
12. MEASUREMENT OF PROPULSION MOTOR CASE PRESSURE	
12-1. Measurement of Propulsion Motor (F)	8-020
12-2. Measurement of Propulsion Motor (R)	8-021
13. MEASUREMENT OF VIBRATOR MOTOR CASE PRESSURE	
13-1. Measurement	8-022
14. ADJUSTMENT OF F-R LEVER LINKAGE	
14-1. Adjustment	8-023
15. BRAKE ADJUSTMENT	
15-1. Manually Releasing the Brake	8-024
15-2. Adjustment after Manual Release of Brake	8-025

## 9. TROUBLESHOOTING

### 1. TROUBLESHOOTING

- 1-1. Safety Precautions for Troubleshooting ..... 9-001
- 1-2. Important Information for Troubleshooting ..... 9-001
- 1-3. Before Starting ..... 9-002

### 2. ELECTRICAL SYSTEM TROUBLESHOOTING

- 2-1. When Performing Electrical System Fault Diagnosis..... 9-003
  - 2-1-1. Precautions to take during electrical circuit fault diagnosis..... 9-003
  - 2-1-2. Inspection procedures using a tester ..... 9-004
  - 2-1-3. Inspection of electrical system ..... 9-009
- 2-2. Fault Codes..... 9-011
  - 2-2-1. Fault code list ..... 9-011
- 2-3. Engine..... 9-022
  - 2-3-1. Engine will not start (Starter motor does not run) 1/3..... 9-022
  - 2-3-1. Engine will not start (Starter motor does not run) 2/3..... 9-024
  - 2-3-1. Engine will not start (Starter motor does not run) 3/3..... 9-026
  - 2-3-2. No charging..... 9-028
  - 2-3-3. Grid heater dose not work  
(Engine starting performance is bad in cold weather) ..... 9-028
  - 2-3-4. Starter motor runs even when F-R lever is not at “N”  
and parking brake is not applied ..... 9-030
  - 2-3-5. Engine speed cannot be switched ..... 9-030
- 2-4. Propulsion..... 9-032
  - 2-4-1. Machine moves neither forward nor backward 1/2 ..... 9-032
  - 2-4-1. Machine moves neither forward nor backward 2/2 ..... 9-034
  - 2-4-2. Machine speed cannot be changed ..... 9-036
  - 2-4-3. Travel mode cannot be changed 1/2..... 9-038
  - 2-4-3. Travel mode cannot be changed 2/2..... 9-040
  - 2-4-4. Brake cannot be released 1/2 ..... 9-042
  - 2-4-4. Brake cannot be released 2/2 ..... 9-044
  - 2-4-5. Brake does not work..... 9-046
- 2-5. Vibration ..... 9-048
  - 2-5-1. No vibration occurs..... 9-048
  - 2-5-2. Amplitude does not change (Remains either Low or High)..... 9-050
  - 2-5-3. Vibration mode cannot be switched  
(F-R lever vibration switch does not work) ..... 9-052

2-6. Lighting	9-054
2-6-1. Illumination of combination meter does not light	9-054
2-6-2. Combination meter warning lamp or indicator lamp is abnormal	9-056
2-6-3. Hour meter is abnormal	9-058
2-6-4. Fuel meter is abnormal	9-058
2-6-5. Hydraulic oil filter warning lamp remains ON	9-060
2-6-6. Vibration indicator lamp does not light	9-062
2-6-7. Parking brake indicator lamp does not light	9-064
2-6-8. Horn does not sound	9-066
2-6-9. Backup buzzer does not sound	9-066
3. HYDRAULIC SYSTEM TROUBLESHOOTING	
3-1. When Performing Hydraulic System Troubleshooting	9-067
3-2. Propulsion System	9-068
3-2-1. Machine moves neither forward nor backward 1/2	9-068
3-2-1. Machine moves neither forward nor backward 2/2	9-069
3-2-2. Machine moves in one direction only (forward or backward)	9-069
3-2-3. Slow machine speed or small drive force 1/2	9-069
3-2-3. Slow machine speed or small drive force 2/2	9-070
3-2-4. Machine speed cannot be switched	9-070
3-2-5. Machine does not stop completely with F-R lever in "N"	9-070
3-2-6. Propulsion system is overheating	9-071
3-2-7. Abnormal noise from propulsion system	9-071
3-3. Vibrator System	9-072
3-3-1. No vibration	9-072
3-3-2. Vibrator frequency is too low	9-073
3-3-3. Amplitude does not switch between high and low	9-073
3-3-4. Vibrator does not stop	9-074
3-3-5. Vibrator system is overheating	9-074
3-3-6. Abnormal noise from vibrator system	9-074
3-4. Steering System	9-075
3-4-1. Steering wheel is hard to turn	9-075
3-4-2. Steering response is slow	9-075
3-4-3. Steering wheel backlash or play is large	9-076
3-4-4. Steering system is overheating	9-076
3-4-5. Abnormal noise from steering system	9-076



---

---

# **SAFETY**

---


---





# 1. GENERAL SAFETY

## 1-1. Understanding the Safety Symbols and Words

The words DANGER, WARNING, and CAUTION are used with the safety-alert symbol. DANGER identifies the most serious hazard. When the symbols DANGER, WARNING and CAUTION are displayed, become alert. Your safety or those around you may be involved. NOTICE is used to provide important information that is not hazard related.

 **DANGER:** Indicates an imminently hazardous situation or condition which if not avoided can result in serious personal injury or death.

 **WARNING:** Indicates a potentially hazardous situation or condition which if not avoided can result in serious personal injury or death.

 **CAUTION:** Indicates a potentially hazardous situation or condition which if not avoided may result in moderate personal injury or damage to the machine or personal property.

(NOTICE): Indicates important information about operation or maintenance of the machine that may cause damage, breakdown, or shortened service life of the machine if you fail to observe or important point to maintain of quality in maintenance works.

★: Indicates standard value to judge whether measured value is good or not.



Items that indicate the weight of a part or equipment and require attention in wire selection and operating posture for slinging operation.



In the assembly operation, tightening torque in locations that require particular attention.

## 1-2. General

- Operators and maintenance personnel must be alert to recognize and avoid potential hazards. They should also have comprehensive training, the required skills and necessary tools to perform the job safely.
- The machine was built in accordance to the latest safety standards and recognized safety rules. Nevertheless, misuse of the machine may result in risk to life and limb of the user or nearby personnel and may cause damage to the machine or other property.
- The machine must only be used for its intended purpose as described in the Operator's Manual. It must be operated by safety-conscious persons who are fully aware of the risks involved when operating the machine. Any malfunctions especially those affecting the safety of the machine must be corrected immediately.


- The machine is designed specifically for the compaction of asphalt or soil road construction materials. Use of the machine for other purposes such as towing other equipment is considered contrary to the designated use. The manufacturer cannot be responsible or held liable for any damage resulting from such use. The risk for such use lies entirely with the user.
- Operating the machine within the limits of its designated use also involves compliance with the inspection and maintenance requirements contained in the Operation and Maintenance Manual.

### 1-3. Qualifications of Operators and Maintenance Personnel

- Work on the machine must be performed by qualified personnel only. Individual responsibilities of personnel regarding operation, maintenance, repair of the machine must be clearly stated.
- Define the operator's responsibilities; the operator should have authority to refuse instructions that are contrary to safety.
- Do not allow persons being trained to operate or perform maintenance on the machine without constant supervision by an experienced person.
- Work on the electrical system of the machine must be done only by an experienced person or under the guidance of a skilled electrician and according to electrical engineering rules and regulations.
- Work on the frame, brakes, hydraulic and steering systems must be performed by skilled personnel with special knowledge and training for such work.

### 1-4. Safety Practices and Policies

- Keep the manuals in the container provided on the machine. Manuals must always be available at the site where the machine is being used.
- The operator or user of the machine must be aware of all applicable or legal and mandatory regulations relevant to accident prevention and environmental protection. These regulations may also deal with handling of hazardous substances, the required proper personal safety and protective equipment and traffic or jobsite regulations.
- Machine operating instructions should also be supplemented with detailed instructions pertaining to the specific jobsite or work location.
- Always be sure the persons working on the machine have read the operating instructions and all safety precautions before beginning work. Reading safety instructions after work has already begun is too late.
- Wear close fitting garments and always tie back and secure long hair, also avoid wearing jewelry such as rings. Injury can result from loose clothing, hair or jewelry being caught up in the machinery or rotating parts.
- Use protective equipment as required by the circumstances or by law.





- Observe all safety instructions and warnings attached to the machine.
- Make sure all safety instructions and warnings on the machine are complete and perfectly legible.
- Stop the machine immediately in the event of any malfunction. Report any malfunction immediately to the supervisor or other person of authority.
- Never perform service or maintenance on the machine unless the drums or tires are adequately blocked, articulation lock bar and pin is in the locked position and the parking brake is applied.
- Never make any modifications to the machine which might affect safety without the manufacturer's approval.
- Always perform the recommended routine inspections and adjustments according to the prescribed intervals.

### **1-5. Pre Start Inspection**

- Inspect your machine daily. Ensure that the routine maintenance and lubrication are properly performed. Repair or replace any malfunctioning, broken or missing parts before using the machine. Refer to the maintenance schedule in the Operator's Manual.
- Check that all instructions and safety stickers are in place and readable.
- Never fill the fuel tank with the engine running or while near an open flame or while smoking.
- Always clean up any spilled fuel.
- Check for any warning tags placed on the machine, do not operate the machine until all repairs have been made and warning tags have been removed by authorized personnel.
- Check the seat belt for wear or damage; inspect the belt hardware and fabric. Replace if hardware is damaged or the belt is frayed or nicked or stitching is loose. Check that mounting hardware is tight.
- Clean the steps and operating platform of dirt and foreign matter to reduce danger of slipping.
- Know how to shut-down or stop the machine immediately in case of emergency.
- Know the capabilities and limitations of the machine such as speed, gradeability, steering and braking.
- Be aware of the dimensions of the machine such as height, weight especially for transporting.

### **1-6. Safety Instructions**

- Take all necessary precautions to ensure that the machine is used only when in a safe and reliable condition.
- Avoid any operational mode that might compromise safety.
- Operate the machine only if all protective and safety devices are in place and fully functional.
- Always use the hand rails and steps to get on and off your machine maintaining 3-point contact (using both hands).

## **1-7. Starting**

- Start the machine only from the driver's seat and always wear the seat belt.
- Watch that the warning lights and indicators during start-up and shutdown are working in accordance with operating instructions.
- Watch that no one is in danger before starting and when moving the machine.
- Check that braking, steering, signals and lights are fully functional before starting work or traveling with the machine.

## **1-8. Operating**


- Always make sure that there are no obstructions or persons in your line of travel before starting the compactor in motion.
- Never climb on and off the machine while it is in motion.
- Always remain seated with the seat belt fastened when traveling, compacting or loading or unloading the machine.
- Use caution and be very observant when operating in close quarters and congested areas.
- Obey all traffic regulations when working on public roads and make sure machine is compatible with these regulations.
- Never carry passengers.
- Know and use the hand signals for particular jobs and who has the responsibility for signaling.
- Do not work close to edges or in the vicinity of overhanging banks or on grades that could cause the compactor to slide or roll over. Avoid any areas that may be a risk to machine stability.
- Avoid side hill travel. Always operate up and down the slope. Always keep the propulsion (travel control) lever in low speed range when climbing or descending hills or steep grades.
- Make sure there is sufficient clearance when crossing underpasses, bridges and tunnels or when passing under overhead power lines.
- Never allow anyone to stand in the articulation area of the machine when the engine is running.
- Always look in all directions before reversing the direction of travel.
- Always switch on the lighting system (if equipped) during poor visibility conditions and after dark.
- Do not attempt to control the compactor travel speed with the throttle control. Maintain engine speed at the full operating RPM.
- Do not run the engine in a closed building for an extended period of time. Exhaust fumes can kill.

## **1-9. Stopping**

- Always park the machine in a safe area on solid and level ground. If this is not possible, always park at a right angle to the slope and block the drums or tires.
- Do not leave the operator's platform with the engine running. Always move the travel lever to neutral position and apply the parking brake then turn the starter switch to OFF.
- Lock all lockable compartments.
- Park behind a safe barrier, use proper flags, and warning devices, especially when parking in areas of heavy traffic.

## 1-10. Maintenance

- In any performing any work concerning the operation, adjustment or modification of the machine or it's safety devices or any work related to maintenance, inspection or repair, always follow the start-up and shut-down procedures in the Operator's Manual and the Maintenance Manual.
- Ensure that the maintenance area is safe and secure.
- If the machine is shut down for maintenance or repair work it must be secured against inadvertent starting by removing the starter key and attaching a warning sign to the starter switch.
- The machine must be parked on stable and level ground with the drums or tires blocked to prevent inadvertent movement.
- Immediately after the engine has stopped, the exhaust system, engine, radiator coolant, engine oil, hydraulic fluid and other lubricants and components will be very hot. Fluids can be under pressure, removing the radiator cap or draining oil or changing filters can cause serious burns. Wait until the machine has cooled down.
- Use care when attaching and securing lifting tackle to individual parts and large assemblies being removed or repositioned for repair purposes to avoid the risk of accident. Use lifting devices that are in perfect condition and of sufficient lifting capacity. Never stand under suspended loads.
- Always use the proper tools and workshop equipment in good condition when performing maintenance or repairs on the machine.
- Always use specially designed safety ladders and working platforms when working above floor level. Never use machine parts as a climbing aid.
- Keep all steps, handles, handrails, platforms and ladders free from mud, dirt, grease, ice or snow.
- Clean the machine, especially threaded connections of any traces of oil or fuel before carrying out any maintenance or repairs. Never use aggressive detergents. Use lint free cleaning rags.
- Examine all fuel, lubricant and hydraulic fluid lines and connectors for leaks, loose connections chafe marks or damage after cleaning.
- Repair or replace defective parts immediately.
- Whenever possible, avoid servicing or maintenance when the engine is running unless the drums or tires are adequately blocked, the articulation lock bar is in the locked position and the parking brake is applied.
- Never fill the fuel tank with the engine running, while near an open flame or while smoking. Always clean up any spilled fuel.
- Ensure safe operation, optimum performance of the machine and its warranty by using only genuine SAKAI replacement parts.



## SAFETY

- Use only the specified fluids and lubricants. Substitute only products known to be equivalent from reputable manufacturers.
- Disconnect the battery cables when working on the electrical system or when welding on the compactor.
- Be sure the battery area is well ventilated (clear of fumes) should it be necessary to connect a jumper cable or battery charger. Fumes can ignite from a spark and may explode.
- Be sure battery charger is OFF when making connections if charging is required.
- Use only original fuses with the specified rating. Switch off the machine immediately if trouble occurs in the electrical system.
- Work on the electrical system may only be carried out by a qualified electrician or by a specially trained person according to electrical engineering principles.
- Inspect the electrical equipment of the machine at regular intervals. Defects such as loose connections or burnt or scorched wires must be repaired or replaced immediately.
- Do not weld, flame cut or perform grinding on the machine unless expressly authorized, as there may be a risk of fire or explosion. Disconnect the battery when welding on the machine.
- Clean the machine and its surrounding from dust or other flammable substances and make sure the area is adequately ventilated before beginning welding, flame cutting or grinding operations.
- Inspect hydraulic hoses at regular intervals and immediately replace if they show signs of chafing, cracking, brittleness, deformation, blistering, fitting separation, leakage, corrosion or other damage which may affect their function or strength.
- Do not work on hydraulic system while the engine is running and the system is under pressure. The hydraulic system remains pressurized even after the engine has stopped.
- Do not disconnect hydraulic hoses or fittings until the pressure has been properly relieved.
- Wait until the systems and fluid have cooled down before disconnecting.
- Never use your hands to check for leaks when inspecting a hydraulic system. Use a piece of cardboard and always wear gloves and safety glasses.



- Get immediate medical attention if fluid has been injected under your skin. Fluid penetration from a pin hole leak can cause severe injury or death.
- Ensure that hydraulic lines and hoses are routed and fitted properly. Ensure that no connections are interchanged. All fittings, lengths and specifications of hoses must comply with the technical requirements.
- Observe all product safety regulations when handling fuel, oils, grease, engine coolant and other chemical substances. Be careful especially when these items are hot as there is a risk of burning or scalding.
- Operate internal combustion engines and fuel operated heating systems only in adequately ventilated premises. Before starting the engine in an enclosed area, make sure there is sufficient ventilation.



## 1-11. Transporting the Machine

- Use only suitable and approved trailers and haul vehicles and lifting equipment of sufficient capacity.
- Entrust to experienced personnel the fastening and lifting of loads and instructing of crane operators.
- Only experienced persons familiar with the operation of the machine may load and unload the machine.
- Use ramps or a loading dock when loading or unloading the machine. Ramps must be the proper strength, low angle and the proper height and width.
- Block the drums or tires (front and rear) of the hauling vehicle when loading and unloading the compactor. Ensure that the haul vehicle is on level ground and approach the loading ramps squarely to make sure that the compactor does not slide off the edge of the ramp.
- Keep the deck clear of mud, oil, ice or snow or other materials that can make the deck slippery.
- Position the compactor on the trailer or transport vehicle centered from side to side, and apply the brake. Shut off the engine and lock all lockable compartments.
- Block the drums or tires and lock the articulation lock bar. Chain the machine down properly using the appropriate tackle.
- Know the overall height of the compactor and hauling vehicle. Observe height and weight regulations and be sure you can pass safely at overhead obstructions.
- Obey all traffic regulations and be sure that the proper clearance flags, lights and warning signs including “Slow Moving Vehicle” emblem are displayed when traveling on public roads.
- Know the approximate stopping distance at any given speed.
- Drive Safely. Never turn corners at excessive speeds.



---

---

# **SPECIFICATIONS**

---

---









# 1. SPECIFICATION DATA

## 1-1. SV414D




0421-99005-0-10168-0

Model & Type	Model		SAKAI SV414D with ROPS	
	Type		VIBRATORY SINGLE-DRUM ROLLER	
Weight	Operating weight	without ballast	7,090 kg	( 15,630 lbs. )
		with ballast	N/A kg	( N/A lbs. )
	Maximum weight		7,150 kg	( 15,765 lbs. )
	Shipping weight	with ROPS	6,960 kg	( 15,345 lbs. )
		without ROPS	6,740 kg	( 14,860 lbs. )
	Load on front axle with operating weight		3,490 kg	( 7,695 lbs. )
Load on rear axle with operating weight		3,600 kg	( 7,935 lbs. )	
Dimensions	Overall length		5,035 mm	( 198 in. )
	Overall width		1,905 mm	( 75 in. )
	Overall height	with ROPS	2,810 mm	( 111 in. )
		without ROPS	2,075 mm	( 82 in. )
	Wheelbase		2,655 mm	( 105 in. )
	Compaction width		1,700 mm	( 67 in. )
	Front drum (outer shell)	width × dia. × thickness	1,700 mm × 1,220 mm × 22 mm (67 in. × 48 in. × 0.9 in.)	
	Front drum (inner shell)	width × dia. × thickness	N/A (N/A)	
	Front drum (pad foot)	height × dia. × pcs.	N/A (N/A)	
	Rear tyers	Size	14.9-24-8PR	
		Inflation pressure	177 kPa	( 26.0 psi )
	Ground clearance		305 mm	( 12.0 in. )
	Kerb clearance	Right	395 mm	( 15.6 in. )
		Left	395 mm	( 15.6 in. )
Side clearance	Right	102.5 mm	( 4.0 in. )	
	Left	102.5 mm	( 4.0 in. )	
Leveling blade width		N/A mm	( N/A in. )	

Performance	Vibrator system	Front	Centrifugal force	Low amplitude	93 kN	( 20,905 lbf. )	
				High amplitude	118 kN	( 26,525 lbf. )	
			Frequency	Low amplitude	38.0 Hz	( 2,280 vpm )	
				High amplitude	30.0 Hz	( 1,800 vpm )	
			Amplitude	Low amplitude	0.75 mm	( 0.030 in. )	
				High amplitude	1.55 mm	( 0.061 in. )	
		Rear	Centrifugal force	Low amplitude	N/A kN	( N/A lbf. )	
				High amplitude	N/A kN	( N/A lbf. )	
			Frequency	Low amplitude	N/A Hz	( N/A vpm )	
				High amplitude	N/A Hz	( N/A vpm )	
			Amplitude	Low amplitude	N/A mm	( N/A in. )	
				High amplitude	N/A mm	( N/A in. )	
	Linear pressure	Static linear pressure	Front drum	Operating weight		201 N/cm	( 115 lbf./in. )
			Rear drum	Operating weight		N/A N/cm	( N/A lbf./in. )
		Dynamic linear pressure	Front drum	Operating weight	Low amplitude	748 N/cm	( 425 lbf./in. )
					High amplitude	895 N/cm	( 510 lbf./in. )
			Rear drum	Operating weight	Low amplitude	N/A N/cm	( N/A lbf./in. )
					High amplitude	N/A N/cm	( N/A lbf./in. )
		Traveling speed	Number of speed shift			3 speed	
			Speed range	1st	0 to 4 km/h		( 0 to 2.5 mile/h )
	2nd			0 to 6 km/h		( 0 to 3.7 mile/h )	
	3rd			0 to 9.5 km/h		( 0 to 5.9 mile/h )	
	Gradeability (without vibration)			63 %		( 32 ° )	
Turning radius	Machine clearance radius inside			3.1 m		( 123 in. )	
	Machine clearance radius outside			5.1 m		( 201 in. )	
	Turning radius inside compacted surface			3.2 m		( 126 in. )	
	Turning radius outside compacted surface			4.9 m		( 193 in. )	

1-2. SV414T





0421-99006-0-10169-0

Model & Type		Model		SAKAI SV414T with ROPS		
		Type		VIBRATORY SINGLE-DRUM ROLLER		
Weight	Operating weight	without ballast	7,090 kg	( 15,630 lbs. )		
		with ballast	N/A kg	( N/A lbs. )		
	Maximum weight		7,150 kg	( 15,765 lbs. )		
	Shipping weight	with ROPS	6,960 kg	( 15,345 lbs. )		
		without ROPS	6,740 kg	( 14,860 lbs. )		
	Load on front axle with operating weight		3,490 kg	( 7,695 lbs. )		
Load on rear axle with operating weight		3,600 kg	( 7,935 lbs. )			
Dimensions	Overall length		5,035 mm	( 198 in. )		
	Overall width		1,905 mm	( 75 in. )		
	Overall height	with ROPS		2,830 mm	( 111 in. )	
		without ROPS		2,095 mm	( 82 in. )	
	Wheelbase		2,655 mm	( 105 in. )		
	Compaction width		1,700 mm	( 67 in. )		
	Front drum (outer shell)	width × dia. × thickness	N/A (N/A)			
	Front drum (inner shell)	width × dia. × thickness	1,700 mm × 1,120 mm × 16 mm ( 67 in. × 44 in. × 0.6 in. )			
	Front drum (pad foot)	height × dia. × pcs.	75 mm × 1,270 mm × 112 pcs. ( 3.9 in. × 50 in. × 112 pcs. )			
	Rear tyers	Size	14.9-24-8PR			
		Inflation pressure		177 kPa	( 26.0 psi )	
	Ground clearance			330 mm	( 13.0 in. )	
	Kerb clearance	Right		430 mm	( 16.9 in. )	
		Left		430 mm	( 16.9 in. )	
Side clearance	Right		102.5 mm	( 4.0 in. )		
	Left		102.5 mm	( 4.0 in. )		
Leveling blade width			N/A mm	( N/A in. )		

Performance	Vibrator system	Front	Centrifugal force	Low amplitude	93 kN ( 20,905 lbf. )		
				High amplitude	118 kN ( 26,525 lbf. )		
			Frequency	Low amplitude	38.0 Hz ( 2,280 vpm )		
				High amplitude	30.0 Hz ( 1,800 vpm )		
			Amplitude	Low amplitude	0.75 mm ( 0.030 in. )		
				High amplitude	1.55 mm ( 0.061 in. )		
		Rear	Centrifugal force	Low amplitude	N/A kN ( N/A lbf. )		
				High amplitude	N/A kN ( N/A lbf. )		
			Frequency	Low amplitude	N/A Hz ( N/A vpm )		
				High amplitude	N/A Hz ( N/A vpm )		
			Amplitude	Low amplitude	N/A mm ( N/A in. )		
				High amplitude	N/A mm ( N/A in. )		
	Linear pressure	Static linear pressure	Front drum	Operating weight		N/A N/cm ( N/A lbf./in. )	
			Rear drum	Operating weight		N/A N/cm ( N/A lbf./in. )	
		Dynamic linear pressure	Front drum	Operating weight	Low amplitude	N/A N/cm ( N/A lbf./in. )	
					High amplitude	N/A N/cm ( N/A lbf./in. )	
			Rear drum	Operating weight	Low amplitude	N/A N/cm ( N/A lbf./in. )	
					High amplitude	N/A N/cm ( N/A lbf./in. )	
		Traveling speed	Number of speed shift			3 speed	
			Speed range	1st	0 to 4 km/h ( 0 to 2.5 mile/h )		
	2nd			0 to 6 km/h ( 0 to 3.7 mile/h )			
	3rd			0 to 9.5 km/h ( 0 to 5.9 mile/h )			
	Gradeability (without vibration)			63 % ( 32 ° )			
Turning radius	Machine clearance radius inside			3.1 m ( 123 in. )			
	Machine clearance radius outside			5.1 m ( 201 in. )			
	Turning radius inside compacted surface			3.2 m ( 126 in. )			
	Turning radius outside compacted surface			4.9 m ( 193 in. )			

1-3. SV414TF



0421-99007-0-10170-0

Model & Type		Model	SAKAI SV414TF with ROPS		
		Type	VIBRATORY SINGLE-DRUM ROLLER		
Weight	Operating weight	without ballast	8,320 kg	( 18,340 lbs. )	
		with ballast	N/A kg	( N/A lbs. )	
	Maximum weight		8,380 kg	( 18,475 lbs. )	
	Shipping weight	with ROPS	8,190 kg	( 18,055 lbs. )	
		without ROPS	7,970 kg	( 17,570 lbs. )	
	Load on front axle with operating weight		4,720 kg	( 10,405 lbs. )	
Load on rear axle with operating weight		3,600 kg	( 7,935 lbs. )		
Dimensions	Overall length		5,035 mm	( 198 in. )	
	Overall width		1,905 mm	( 75 in. )	
	Overall height	with ROPS		2,840 mm	( 112 in. )
		without ROPS		2,100 mm	( 83 in. )
	Wheelbase		2,655 mm	( 105 in. )	
	Compaction width		1,700 mm	( 67 in. )	
	Front drum (outer shell)	width × dia. × thickness	1,700 mm × 1,320 mm × 19 mm ( 67 in. × 52 in. × 0.7 in. )		
	Front drum (inner shell)	width × dia. × thickness	1,700 mm × 1,120 mm × 16 mm ( 67 in. × 44 in. × 0.6 in. )		
	Front drum (pad foot)	height × dia. × pcs.	75 mm × 1,270 mm × 112 pcs. ( 3.9 in. × 50 in. × 112 pcs. )		
	Rear tyers	Size	14.9-24-8PR		
		Inflation pressure	177 kPa	( 26.0 psi )	
	Ground clearance		345 mm	( 13.6 in. )	
	Kerb clearance	Right	445 mm	( 17.5 in. )	
		Left	445 mm	( 17.5 in. )	
Side clearance	Right	102.5 mm	( 4.0 in. )		
	Left	102.5 mm	( 4.0 in. )		
Leveling blade width		N/A mm	( N/A in. )		

Performance	Vibrator system	Front	Centrifugal force	Low amplitude	93 kN ( 20,905 lbf. )		
				High amplitude	118 kN ( 26,525 lbf. )		
			Frequency	Low amplitude	38.0 Hz ( 2,280 vpm )		
				High amplitude	30.0 Hz ( 1,800 vpm )		
			Amplitude	Low amplitude	0.50 mm ( 0.020 in. )		
				High amplitude	1.00 mm ( 0.039 in. )		
		Rear	Centrifugal force	Low amplitude	N/A kN ( N/A lbf. )		
				High amplitude	N/A kN ( N/A lbf. )		
			Frequency	Low amplitude	N/A Hz ( N/A vpm )		
				High amplitude	N/A Hz ( N/A vpm )		
			Amplitude	Low amplitude	N/A mm ( N/A in. )		
				High amplitude	N/A mm ( N/A in. )		
	Linear pressure	Static linear pressure	Front drum	Operating weight		272 N/cm ( 155 lbf./in. )	
			Rear drum	Operating weight		N/A N/cm ( N/A lbf./in. )	
		Dynamic linear pressure	Front drum	Operating weight	Low amplitude	819 N/cm ( 465 lbf./in. )	
					High amplitude	966 N/cm ( 550 lbf./in. )	
			Rear drum	Operating weight	Low amplitude	N/A N/cm ( N/A lbf./in. )	
					High amplitude	N/A N/cm ( N/A lbf./in. )	
		Traveling speed	Number of speed shift			3 speed	
			Speed range	1st	0 to 4 km/h ( 0 to 2.5 mile/h )		
	2nd			0 to 6 km/h ( 0 to 3.7 mile/h )			
	3rd			0 to 10 km/h ( 0 to 6.2 mile/h )			
	Gradeability (without vibration)			63 % ( 32 ° )			
Turning radius	Machine clearance radius inside			3.1 m ( 123 in. )			
	Machine clearance radius outside			5.1 m ( 201 in. )			
	Turning radius inside compacted surface			3.2 m ( 126 in. )			
	Turning radius outside compacted surface			4.9 m ( 193 in. )			

## SPECIFICATIONS

### 1-4. Common Specifications

Engine	Model		CUMMINS QSF 2.8 (Diesel, EPA-Tier 4)
	Type		4-cycle, water-cooled, 4-cylinder in-line, overhead valve, direct injection type, with turbo charger
	Cylinders - Bore × Stroke		94 mm × 100 mm (3.700 in. × 3.940 in.)
	Displacement		2.800 L ( 171.0 cu.in. )
	Performance	Rated speed	2,400 min <sup>-1</sup>
		Rated output	55.0 kW ( 74 HP )
		Max. torque	300 N·m ( 221 lbf·ft ) at 1,600 min <sup>-1</sup>
		Fuel consumption rate	239 g/kW·h ( 0.393 lb/HP·h ) at 2,400 min <sup>-1</sup>
		Fuel consumption	15 L/h with full load ( 4.0 gal with full load )
	Fuel system	Fuel	Diesel (ASTM D975-2D)
		Fuel injection pump	Inline injection pmp
		Fuel injection time regulator	All speed governor
	Lubrication system	Lubrication type	Full forced pressure feed
		Oil filter type	Full flow
		Oil cooler type	Integrated water cooled
	Air intake system	Air cleaner type	Dry
	Cooling system	Cooling type	Pressurized water forced circulation
		Cooling fan type	Inhale
	Electrical system	Alternator	12 V 120 A
		Starter	12 V 3.0 kW
Battery		12 V (CCA1000) × 1 pcs. (12 V)	
Dry weight		244 kg (538 lbs.)	
Drive system	Transmission	Type	Hydrostatic
		Speed	3 speed shifts
	Reverser		Switching the direction of flow delivered from the variable pump
	Differential type	Front	N/A
		Rear	Non-spin
Final drive	Front	Planetary gear	
	Rear	Planetary gear	
Vibration system	Power transmission type		Hydraulic
	Vibrator type		Single eccentric shaft
Brake system	Service brake		Dynamic braking through hydrostatic drive system (F-N-R lever)
	Secondary brake (Emergency brake)		Hydrostatic + spring applied hydraulically released type (Brake pedal)
	Parking brake		Spring applied hydraulically released type (Panel button)
Steering system	Power transmission type		Hydraulic
	Steering type		Articulated
	Steering angle		± 37°
	Oscillating angle		± 9°
Drum and tyres	Use	Front	Steel drum / Vibrate and drive / 1pc.
		Rear	Rubber tyre / Drive / 2pcs.
	Suspension type	Front	Rubber isolation
		Rear	Rigid
Sprinkler system	Water spray type		N/A
	Liquid spray type		N/A



## 2. TABLE OF STANDARD VALUES


### 2-1. Engine

Item		Standard value	Remarks
Engine model		CUMMINS QSF 2.8	
Rated output		55/2,400 kW/ min <sup>-1</sup> ( 74/2,400 HP/ min <sup>-1</sup> )	
Max. rpm under no load		2,400 rpm	
Min. rpm under no load		900 rpm	
Cylinder head tightening torque	1st	60 N·m ( 44 lbf-ft )	
	2nd	Tighten additional 90°	
	3rd	Tighten additional 90°	
Intake manifold tightening torque		10 N·m ( 7 lbf-ft )	
Exhaust manifold tightening torque		42 N·m ( 31 lbf-ft )	
Valve clearance (intake)		0.25 mm ( 0.01 in. )	
Valve clearance (exhaust)		0.51 mm ( 0.02 in. )	
Crankcase blowby		147.3 mm of H <sub>2</sub> O ( 5.8 in. of H <sub>2</sub> O )	Use mano meter

### 2-2. Propulsion

Item		Standard value	Remarks	
Travel speed (Forward/reverse)	1st	0 to 4 km/h ( 0 to 2.5 mile/h )		
	2nd	0 to 6 km/h ( 0 to 3.7 mile/h )		
	3rd	(SV414D,T)	0 to 9.5 km/h ( 0 to 5.9 mile/h )	
		(SV414TF)	0 to 10 km/h ( 0 to 6.2 mile/h )	

### 2-3. Hydraulic Systems



Item		Standard value	Remarks	
Propulsion	High pressure relief valve setting	41.8 ± 1.0 MPa ( 6,061 ± 145 psi )	at 1,800 min <sup>-1</sup>	
	Charge relief valve setting	2.5 ± 0.2 MPa ( 363 ± 29 psi )		
	Flushing relief valve setting	Front motor	1.6 MPa ( 232 psi )	at 10 L/min
		Rear motor	2.67 MPa ( 387 psi )	at 19 L/min
	Case pressure	Pump	0.3 MPa ( 43.5 psi ) or less	
		Front motor	0.3 MPa ( 43.5 psi ) or less	
		Rear motor	0.3 MPa ( 43.5 psi ) or less	
	Brake release pressure	Front motor	—	
		Rear motor	—	
		Rear axle	1.5 to 3.0 MPa ( 218 to 435 psi )	
Motor drainage	Front motor	5.4 L/min ( 1.4 gal./min )	 , 3rd	
	Rear motor	6.1 L/min ( 1.6 gal./min )		
Vibration	High pressure relief valve setting	25.0 ± 1.0 MPa ( 3,625 ± 145 psi )		
	Charge relief valve setting	2.5 ± 0.2 MPa ( 363 ± 29 psi )		
	Case pressure	Pump	0.3 MPa ( 43.5 psi ) or less	
		Motor	0.17 MPa ( 24.7 psi ) or less	
	Motor drainage	6.3 L/min ( 1.7 gal./min )		
Steering oil pressure		17.5 ± 1.0 MPa ( 2,538 ± 145 psi )	(orbitroll relief pressure + charge relief pressure)	

## SPECIFICATIONS

### 2-4. Steering

Item	Standard value	Remarks
Play in steering wheel	5 to 10 mm ( 0.2 to 0.4 in. )	Steering wheel circumference
	0.5 mm ( 0.02 in. ) or less	Steering column shaft direction

### 2-5. Brakes

Item	Standard value	Remarks
Brake pedal stopper bolts specified length	140 mm (5.5 in.) Note 1: See dimensions	 <p>SV520-02001</p>
	73 mm (2.9 in.) Note 2: See dimensions	
Brake disc wear limit	4.5 mm (0.18 in.) (S)	 <p>SV700-02003</p>

### 2-6. Capacities

Item	Standard value	Remarks
Engine oil pan	8.2 L ( 2.2 gal. )	
Fuel tank	145 L ( 38.3 gal. )	
Coolant	16 L ( 4.2 gal. )	
Gear box (front)	2.0 L ( 0.53 gal. )	
Center housing (rear axle)	7.3 L ( 1.9 gal. )	
Hub reduction gear case (rear left and right)	1.3 L × 2 ( 0.33 gal. × 2 )	
Hydraulic oil tank	53 L ( 14.0 gal. )	
Vibrator case (front)	21 L ( 5.5 gal. )	

### 3. FUEL AND LUBRICANTS SPECIFICATION

#### 3-1. Rating

Lubricant	Service classification	Ambient temp. and applicable viscosity rating			Applicable Standards
		-15 to 30°C (5 to 86°F) Cold	0 to 40°C (32 to 104°F) Moderate	15 to 55°C (59 to 131°F) Tropical	
Engine oil	API grade CJ4	SAE15W-40	SAE15W-40	SAE15W-40	MIL-L-2104B
Gear oil	API grade GL5	SAE80W-90	SAE90	SAE140	MIL-L-2105
Hydraulic oil	Anti wear	ISO-VG32	ISO-VG46	ISO-VG68	ISO-3448
Grease	Lithium type extreme pressure				NLGI-2
Fuel	Diesel oil				ASTM D975-2D

#### 3-2. Recommended Lubricants

Lubricant Oil company	Engine oil API-CJ4	Gear oil API GL 5	Hydraulic oil ISO-VG 46	Grease (NLGI-2)
CHEVRON	DELO 400 LE	—	Rando HDZ 46	Multifak EP 2
BP	—	BP Energear HYPO-U	Bartran HV 46	BP Energrease LS-EP 2
CASTROL	Tection Extra	EPX GEAR OILS	Castrol Hyspin AWH 46	Castrol Spherrol ELP 2
EXXON MOBIL	Mobil Delvac 1 ESP	Mobilude HD	Mobil DTE 10 Excel 46	Mobilux EP 2
SHELL	Shell Rimula R4 L	Shell Spirax S2 A 90	Shell Tellus S2 V 46	Shell Alvania Grease EP 2

# 4. TIGHTENING TORQUE CHART

N·m	(lbf·ft)
-----	----------

	Nominal Dia.	Pitch	Strength Classification							
			6.8		8.8		10.9		12.9	
Metric coarse screw	5	0.8	4.9	(3.6)	5.9	(4.4)	7.8	(5.8)	7.8	(5.8)
	6	1.0	7.8	(5.8)	9.8	(7.2)	13	(9.6)	13	(9.6)
	8	1.25	17	(13)	23	(17)	31	(23)	31	(23)
	10	1.5	39	(29)	49	(36)	59	(44)	59	(44)
	12	1.75	69	(51)	78	(58)	108	(80)	108	(80)
	14	2.0	98	(72)	127	(94)	167	(123)	167	(123)
	16	2.0	157	(116)	196	(145)	265	(195)	265	(195)
	18	2.5	196	(145)	245	(181)	343	(253)	343	(253)
	20	2.5	294	(217)	392	(289)	539	(398)	539	(398)
	22	2.5	441	(325)	539	(398)	686	(506)	686	(506)
	24	3.0	539	(398)	637	(470)	883	(651)	883	(651)
	27	3.0	785	(579)	981	(724)	1324	(977)	1324	(977)
	30	3.5	1079	(796)	1324	(977)	1765	(1302)	1765	(1302)
Metric fine screw	10	1.25	39	(29)	49	(36)	69	(51)	69	(51)
	12	1.25	69	(51)	88	(65)	118	(87)	118	(87)
	14	1.5	108	(80)	137	(101)	186	(137)	186	(137)
	16	1.5	167	(123)	206	(152)	284	(209)	284	(209)
	18	1.5	245	(181)	294	(217)	392	(289)	392	(289)
	20	1.5	343	(253)	441	(325)	588	(434)	588	(434)
	22	1.5	490	(361)	588	(434)	785	(579)	785	(579)
	24	2.0	588	(434)	735	(542)	981	(724)	981	(724)
	27	2.0	834	(615)	1030	(760)	1422	(1049)	1422	(1049)
	30	2.0	1177	(868)	1422	(1049)	1961	(1446)	1961	(1446)

---

---

# **ENGINE AND CONTROLS**


---

---



# 1. ENGINE

## 1-1. Engine Mount





0421-01801-0-10001-B

- |                    |                    |                     |
|--------------------|--------------------|---------------------|
| (1) Bracket        | (7) Plate          | (12) Bolt : M16×140 |
| (2) Bracket        | (8) Damper         | (13) Plate          |
| (3) Engine         | (9) Shim           | (14) Damper         |
| (4) Bracket        | (10) Nut : M16     | (15) Nut : M16      |
| (5) Bracket        | (11) Bolt : M12×30 | (16) Bolt : M12× 30 |
| (6) Bolt : M16×140 |                    |                     |




- |                  |                          |
|------------------|--------------------------|
| (10) Nut M16     | : 265 N·m ( 195 lbf-ft ) |
| (11) Bolt M12×30 | : 108 N·m ( 80 lbf-ft )  |
| (15) Nut M16     | : 265 N·m ( 195 lbf-ft ) |
| (16) Bolt M12×30 | : 108 N·m ( 80 lbf-ft )  |



## 2. FUEL SYSTEM







SECTION A-A




SECTION B-B

0421-02801-0-10002-B

- |  |   |
|--|---|
| (1) Fuel coller                                  | (11) Drain plug                                     |
| (2) Hose (Fuel return (engine) → Fuel coller IN) | (12) Hose (Main filter OUT → Fuel suction (engine)) |
| (3) Pre-filter                                   | (13) Fuel suction (tank)                            |
| (4) Hose (Pre-filter OUT → Main filter IN)       | (14) Fuel gauge unit                                |
| (5) Fuel tank                                    | (15) Fuel return (tank)                             |
| (6) Main filter                                  | (16) Hose (Fuel supply)                             |
| (7) Hose (Fuel coller OUT → Fuel return (tank))  | (17) Strainer                                       |
| (8) Fuel suction (engine)                        | (18) Fuel supply port                               |
| (9) Fuel return (engine)                         | (19) Filler cap                                     |
| (10) Hose (Fuel suction (tank) → Pre-filter IN)  |   |

### 3. CONTROL SYSTEM

#### 3-1. Forward-reverse Control




0421-12801-0-10009-0

- |                            |                              |
|----------------------------|------------------------------|
| (1) F-R lever switch       | (8) Rod end (Apply grease*)  |
| (2) Backup buzzer switch   | (9) Bolt : M16×30            |
| (3) F-R lever              | (10) Nut : M16               |
| (4) Control cable          | (11) Spring (Fill grease)    |
| (5) Bush (Apply grease*)   | (12) Steel ball              |
| (6) Nut : M12              | (13) Rod end (Apply grease*) |
| (7) Washer (Apply grease*) |                              |

\* : Lithium-based grease

## 4. PUMP MOUNT

### 4-1. Pump Mount



#### SECTION A-A

0421-36801-0-10013-A

- |                    |          |             |          |
|--------------------|----------|-------------|----------|
| (1) Bolt           | : M10×25 | (6) Housing |          |
| (2) Bolt           | : M10×35 | (7) Bolt    | : M14×45 |
| (3) Retaining ring |          | (8) Pump    |          |
| (4) Hub            |          | (9) Bolt    | : M12×35 |
| (5) Flange         |          |             |          |



- |          |        |   |         |   |            |   |
|----------|--------|---|---------|---|------------|---|
| (1) Bolt | M10×25 | : | 59 N·m  | ( | 44 lbf·ft  | ) |
| (2) Bolt | M10×35 | : | 49 N·m  | ( | 36 lbf·ft  | ) |
| (7) Bolt | M14×45 | : | 167 N·m | ( | 123 lbf·ft | ) |
| (9) Bolt | M12×35 | : | 86 N·m  | ( | 63 lbf·ft  | ) |


**4-1-1. Installation of pump**

- When the pump has been removed from the engine for repair or replacement, reinstall it in accordance with the following procedure.


- ① Apply adequate amount of grease to pump (8) and hub (4) splines.
- ② Install retaining ring (3) of hub (4) to pump (8) and set to the specified dimension.

★ Specified dimension a: 9 mm (0.35 in.)

- ③ Secure hub (4) with bolts (9).




- ④ Secure flange (5) to engine flywheel with eight bolts (2).



**(NOTICE)**

- Check for direction of flange (5).
- Bolt (2) is treated with thread-locking fluid. Use new thread-locking fluid treated bolt for installation.



- ⑤ Secure housing (6) to flywheel housing with twelve bolts (1).



**(NOTICE)**

- Bolt (1) is treated with thread-locking fluid. Use new thread-locking fluid treated bolt for installation.

- ⑥ Engage hub (4) with flange (5).
- ⑦ Secure pump (8) to housing (6) with four bolts (7), spring washers and washers.



---

---

# **HYDRAULIC SYSTEMS**

---

---





# 1. SYSTEM CIRCUIT DIAGRAM

## 1-1. Graphic Symbols for Hydraulic Circuits

### Basic Symbols








DESCRIPTION	SYMBOL
Lines:	
Main working	
Pilot control	
Drain or bleed	
Lines, joining	
Not connected	
Component outline	
Arrow indicates direction of flow.	
Line with fixed restriction (orifice).	
Test port, pressure measurement.	
Temperature measurement gauge	
Pressure measurement gauge	
Reservoir (vented)	
Filter or strainer	
Heat exchanger, lines indicate flow of coolant.	
Quick disconnect:	
Connected with mechanically opened checks.	
Disconnected.	
Sloping arrow through a symbol at 45° indicates that a component can be adjusted or varied.	

### Pump, Motors and Cylinders










DESCRIPTION	SYMBOL
Hydraulic pumps:	
Fixed displacement	
Unidirectional	
Bidirectional	
Variable displacement	
Unidirectional	
Bidirectional	
Variable displacement pressure compensated Unidirectional	
Hydraulic Motor:	
Unidirectional	
Bidirectional	
Double acting hydraulic cylinder	
Differential cylinder	
Electric motor	



**Valves**


DESCRIPTION	SYMBOL
Check valve	
Manual shut off (On-Off)	
Pressure relief	
Flow control, adjustable	
Valve symbols: The basic valve symbol one or more squares with lines representing flow paths and flow conditions between ports.	
Multiple squares indicate a valve with as many distinct positions there are squares providing various flow path options for the fluid. The multiple square moves to represent how flow paths change when the valving element is shifted within the component.	
Valves with infinite positioning between certain limits are symbolized with lines parallel to the squares.	

**Methods of Operation**

DESCRIPTION	SYMBOL
Spring	
Manual	
Pressure compensated	
Reversing motor	
Pilot pressure: Internal supply	
Remote supply	
Solenoid: Single winding	
Two windings operating in opposite directions.	
Pilot directional valve is actuated by the solenoid.	



1-2. Hydraulic Circuit Diagram



ENGINE  
CUMMINS:QSF2.8 T4F  
55 kW/2400min<sup>-1</sup>  
300 N·m/1600min<sup>-1</sup>  
MAX min<sup>-1</sup>:2400min<sup>-1</sup>

Drum  
D : φ1270  
T : φ1320  
TF : φ1320  
1700

Vibrator motor  
93 kN/2300vpm (9.5 ton)  
118 kN/1800vpm (12 ton)


Rear axle ASSY  
i=6.00  
i=7.286  
TOTAL: i=43.72  
D : φ1262  
T : φ1300  
TF : φ1300  
TIRE SIZE: 14.9-24 8PR-OR



## 2. PROPULSION HYDRAULIC SYSTEM

### 2-1. Propulsion Hydraulic Piping







#### 2-1-1. Propulsion hydraulic piping (F)




• The letters and numbers in the figure such as "RB2" and "FMB" show each port.  
 • Arrow "↔"; "→" symbols show the hose connection and the direction of the flow of the oil.



2-1-2. Propulsion hydraulic piping (R)



VIEW D



VIEW E

- The letters and numbers in the figure such as “PPA” and “PB1” show each port.
- Arrow “↔”; “→” symbols show the hose connection and the direction of the flow of the oil.













## 2-2. Hydraulic Component Specifications

### 2-2-1. Hydraulic pump ASSY (propulsion + vibrator + steering • charge)



VIEW A



Pump circuit diagram

(1) Propulsion pump

(1-1) Multifunction valve (For port A1)	
(1-2) Charge pressure gauge port	: 9/16-18UNF
(1-3) Charge supply port	<b>[PPC]</b> : 7/ 8-14UNF
(1-4) Multifunction valve (For port B1)	
(1-5) Port B1 (Reverse)	<b>[PPB]</b> : SAE 1"
(1-6) Drain port	<b>[PD1]</b> : 1 1/16-12UN
(1-7) Servo pressure gauge port	<b>[SGA]</b> : 7/16-20UNF
(1-8) Servo pressure gauge port	<b>[SGB]</b> : 7/16-20UNF
(1-9) High pressure gauge port (For port B1)	: 9/16-18UNF
(1-10) Charge relief valve	
(1-11) High pressure gauge port (For port A1)	: 9/16-18UNF
(1-12) Drain port	<b>[PD2]</b> : 1 1/16-12UN
(1-13) Port A1 (Forward)	<b>[PPA]</b> : SAE 1"

Specifications

- Displacement : 51 cm<sup>3</sup>/rev ( 3.1 cu.in./rev )
- High pressure relief valve pressure setting : 41.8 MPa ( 6,061 psi )
- Charge relief valve pressure setting : 2.5 MPa ( 363 psi )

(2) Vibrator pump

(2-1) High pressure relief valve (For port A2)	
(2-2) Drain port	<b>[VD1]</b> : 1 5/16-12UN
(2-3) Servo pressure gauge port	: 9/16-18UNF
(2-4) Charge pressure gauge port	: 9/16-18UNF
(2-5) High pressure relief valve (For port B2)	
(2-6) Solenoid valve b (Low amplitude)	
(2-7) Solenoid valve a (High amplitude)	
(2-8) Port B2	<b>[VPB]</b> : 1 1/16-12UN
(2-9) Drain port	<b>[VD2]</b> : 1 5/16-12UN
(2-10) Servo pressure gauge port	: 9/16-18UNF
(2-11) Port A2	<b>[VPA]</b> : 1 1/16-12UN
(2-12) Charge relief valve	
(2-13) Charge pressure gauge port	: 1/ 2-20UNF

Specifications

- Displacement (Low amplitude) : 35.0 cm<sup>3</sup>/rev ( 2.1 cu.in./rev )
- Displacement (High amplitude) : 28.0 cm<sup>3</sup>/rev ( 1.7 cu.in./rev )
- High pressure relief valve pressure setting : 25.0 MPa ( 3,625 psi )
- Charge relief valve pressure setting : 2.5 MPa ( 363 psi )



(3) Steering pump

(3-1) Discharge port	<b>[SCD]</b> : 1 1/16-12UN
(3-2) Suction port	<b>[SCS]</b> : 1 5/16-12UN




Specifications

- Displacement : 24.9 cm<sup>3</sup>/rev ( 1.5 cu.in./rev )
- Allowable pump case pressure : 0.3 MPa ( 43.5 psi ) or less
- Pump assembly weight : 95 kg ( 209 lbs. )


2-2-2. Propulsion hydraulic motor (F)



VIEW B



VIEW A



Motor circuit diagram

Flow of oil

•3 → 6 Clockwise rotation



•6 → 3 Counterclockwise rotation

- (1) Servo pressure gauge port (High) : 9/16-18UNF
- (2) Drain port : 7/ 8-14UNF
- (3) Port B (Reverse) **[FMB]** : SAE 3/4"
- (4) Control pressure gauge port **[FMC]** : 9/16-18UNF
- (5) Drain port **[FMD]** : 7/ 8-14UNF
- (6) Port A (Forward) **[FMA]** : SAE 3/4"
- (7) Servo pressure gauge port (Low) : 9/16-18UNF
- (8) Loop flushing shuttle valve
- (9) Gauge port (For Port B) : 7/ 8-14UNF
- (10) Loop flushing relief valve
- (11) Gauge port (For Port A) : 7/ 8-14UNF

#### Motor specifications

- Displacement (max.) : 60.0 cm<sup>3</sup>/rev ( 3.66 cu.in./rev )  
(min.) : 28.0 cm<sup>3</sup>/rev ( 1.71 cu.in./rev )
- Loop flushing relief valve pressure setting : 1.6 MPa ( 232 psi )
- Allowable motor case pressure : 0.3 MPa ( 43.5 psi ) or less
- Weight : 28 kg ( 62 lbs. )

2-2-3. Gear box




SV410-2-04002

(1) Gear box

Specifications

- Reduction ratio : 1/47.00
- Weight : 90 kg ( 198 lbs. )

1) Structure of gear box







SV410-2-04003

(1) Gear box


- |                          |              |                       |              |
|--------------------------|--------------|-----------------------|--------------|
| (1-1) Plug               | : 9/16-18UNF | (1-18) Plug           | : 9/16-18UNF |
| (1-2) Hub                |              | (1-19) Cover          |              |
| (1-3) Spacer             |              | (1-20) Pad            |              |
| (1-4) Plate              |              | (1-21) Shim           |              |
| (1-5) Snap ring          |              | (1-22) Bolt           | : M10×120    |
| (1-6) Housing            |              | (1-23) Cover          |              |
| (1-7) Bearing nut        | : M190       | (1-24) Sun gear       |              |
| (1-8) Ring gear          |              | (1-25) Snap ring      |              |
| (1-9) Plug               |              | (1-26) Bearing washer |              |
| (1-10) Needle bearing    |              | (1-27) Planetary gear |              |
| (1-11) Snap ring         |              | (1-28) Needle         |              |
| (1-12) Planetary gear    |              | (1-29) Bearing washer |              |
| (1-13) O-ring            |              | (1-30) Snap ring      |              |
| (1-14) Taper bearing     |              | (1-31) Carrier        |              |
| (1-15) Coupling          |              | (1-32) Gear pin       |              |
| (1-16) Bolt              | : M6×16      | (1-33) Sun gear       |              |
| (1-17) Floating seal kit |              |                       |              |

2-2-4. Propulsion hydraulic motor (R)



Motor circuit diagram

Flow of oil  
 •8→7 Clockwise rotation  
 •7→8 Counterclockwise rotation



SV505- I -04003




- (1) Charge pressure relief valve
- (2) Pilot supply port       **[RMP]** : 9/16-18UNF
- (3) Drain port               **[RMD]** : 1 1/16-12UN
- (4) Servo pressure gauge port : 9/16-18UNF
- (5) Speed change solenoid valve (R)
- (6) Servo pressure gauge port : 9/16-18UNF
- (7) Port B (Forward)       **[RMB]** : SAE 1"
- (8) Port A (Reverse)       **[RMA]** : SAE 1"
- (9) Drain port               : 1 1/16-12UN

#### Motor specifications

- Displacement (max.)               : 75 cm<sup>3</sup>/rev ( 4.58 cu.in./rev )  
  (min.)                               : 35 cm<sup>3</sup>/rev ( 2.14 cu.in./rev )
- Flushing relief valve pressure setting : 2.67 MPa ( 387 psi ) (at 19 L/min)
- Allowable motor case pressure       : 0.3 MPa ( 43.5 psi ) or less
- Weight                                 : 55 kg ( 121 lbs. )



2-2-5. Speed change solenoid valve (F)




- (1) Solenoid
- (2) O-ring (1B P14)
- (3) Spool (J)
- (4) Body
- (5) Spring
- (6) Port P            **[SCP]** : 9/16-18UNF-2B
- (7) Port A            **[SCA]** : 9/16-18UNF-2B
- (8) Port T            **[SCT]** : 9/16-18UNF-2B

Specifications

- Rated flow : 30 L/min ( 7.9 gal./min )
- Rated pressure : 4.9 MPa ( 710 psi ) (6, 7)
- : 0.5 MPa ( 72.5 psi ) (8)
- Weight : 1.5 kg ( 3.3 lbs. )

J-40146

2-2-6. Block (1)




SECTION A-A

R2-4-04006

- |  |                      |
|--|----------------------|
| (1) From propulsion pump port B ([PPB])    | [RA1] : 1-1/16-12UNF |
| (2) Body                                   |                      |
| (3) To propulsion motor (F) port B ([FMB]) | [RA2] : 1-1/16-12UNF |
| (4) To bypass valve                        | [RA3] : 3/ 4-16UNF   |
| (5) To propulsion motor (R) port A ([RMA]) | : $\phi 24.9$        |

2-2-7. Block (2)




SECTION A-A

SV414-04002

- |  |                      |
|--|----------------------|
| (1) From propulsion pump port A ([PPA])    | [RB1] : 1-1/16-12UNF |
| (2) Body                                   |                      |
| (3) To propulsion motor (F) port A ([FMA]) | [RB2] : 1-1/16-12UNF |
| (4) To bypass valve                        | [RB3] : 3/ 4-16UNF   |
| (5) To propulsion motor (R) port B ([RMB]) | : $\phi 24.9$        |

Fig.: Propulsion circuit



- 1. Engine
- 2. Coupling
- 3. Propulsion pump
  - a. Control valve (forward-reverse)
  - b. Charge relief valve
  - c. Servo piston
  - d. High pressure relief valves
  - e. Check valves
- 4. Vibrator pump
- 5. Steering charge pump
- 6. Propulsion motor (R)
  - f. Speed change solenoid valve
  - g. Flushing valve
  - h. Low pressure relief valve
- 7. Rear axle ASSY
  - j. Differential
  - k. Final drives
  - m. Tires
  - n. Brake
- 8. Speed change solenoid valve (F)
- 9. Parking brake solenoid valve
- 10. Bypass valve
- 11. Orbitrol
  - o. Relief valve
- 12. Hydraulic oil filter 1
- 13. Oil cooler
- 14. Suction filter
- 15. Drum
- 16. Gear box
- 17. Propulsion motor (F)
  - p. Speed change valve
  - q. Flushing valve
  - r. Low pressure relief valve
- 18. Servo bypass solenoid valve

## 2-3. Description and Operation of Propulsion System

### Description

- Made up of propulsion pump (3), propulsion motor (R) (6), rear axle ASSY (7), propulsion motor (F) (17), drum (15), speed change solenoid valve (F) (8) and parking brake solenoid valve (9).  
Rear axle ASSY (7) includes differential (j), final drives (k), tires (m) and brake (n).

### Basic function of propulsion pump and motor

#### Propulsion pump:

- A piston pump is used. By varying swashplate angle which varies the piston stroke, forward travel, bringing to neutral and backing are achieved.

#### Propulsion motor:

- Piston motors are used. The motor is a variable displacement type which controls the piston stroke by varying the swashplate angle.


### Operation (It is assumed that the machine travels forward.)

- The parking brake is supposed to have been released.
- Assemblies such as pump ASSY and motor ASSY are indicated by numbers such as “1” and “2”, while component parts of assemblies are shown by small letters such as “a” and “b”.
- Operation of the F-R lever forward puts pump control valve (a) into function. Servo piston (c) tilts the pump swashplate in the forward travel direction.
- Propulsion pump (3) discharges oil from its port B1. Then the oil flow branches into two lines; one line connecting to forward travel port (A) of propulsion motor (R) (6) and the other line to forward travel port (B) of propulsion motor (F) (17).
- The oil fed into the forward travel ports of the motors drives the motors, flowing out from the opposite side ports (port A in propulsion moto (F) and port B in propulsion motor (R)) and joins again to flow into suction port (A1) in propulsion pump (3). At the same time, part of oil is drained to the tank via flushing valve (g), low pressure relief valve (h), and the motor casing

### (NOTE)

- **Because the propulsion circuit is a closed circuit, the relationship between the suction port and discharge port is reversed when the travel direction is reversed.**
- The power from propulsion motor (R) (6) is delivered to tires (m) through reduction mechanism in differential (j) and final drives (k).
- The drive from propulsion motor (F) (17) is conveyed to drum (15) via reduction gear (16).

Fig.: Propulsion circuit



- 1. Engine
- 2. Coupling
- 3. Propulsion pump
  - a. Control valve (forward-reverse)
  - b. Charge relief valve
  - c. Servo piston
  - d. High pressure relief valves
  - e. Check valves
- 4. Vibrator pump
- 5. Steering charge pump
- 6. Propulsion motor (R)
  - f. Speed change solenoid valve
  - g. Flushing valve
  - h. Low pressure relief valve
- 7. Rear axle ASSY
  - j. Differential
  - k. Final drives
  - m. Tires
  - n. Brake
- 8. Speed change solenoid valve (F)
- 9. Parking brake solenoid valve
- 10. Bypass valve
- 11. Orbitrol
  - o. Relief valve
- 12. Hydraulic oil filter 1
- 13. Oil cooler
- 14. Suction filter
- 15. Drum
- 16. Gear box
- 17. Propulsion motor (F)
  - p. Speed change valve
  - q. Flushing valve
  - r. Low pressure relief valve
- 18. Servo bypass solenoid valve



## Two-step Speed selection (High-Low)

### From Low to High:

- Speed change solenoid valve (F) (8) and propulsion motor (R) (6) is also equipped with speed change solenoid valve (f).
- When the changeover switch at the driver's seat is set in the (Rabbit) position, the oil is output from speed change solenoid valve (F) (8) to speed change valve (p) of propulsion motor (F) (17), moving the swash plate of the motor to the side where the piston stroke decreases.
- The charge circuit oil from hydraulic oil filter 1 (12) passes through speed change solenoid valve (f) of propulsion motor (R) (6), moving the swash plate of the motor to the side where the piston stroke decreases.
- Since the displacement per motor rotation decreases, the vehicle speed increases although the pump discharge does not change.

### To release parking brake

- Rear axle ASSY (7) contains brake (n).
- Actuation of the brake switch on the instrument panel in the driver's station energizes parking brake solenoid valve (9). The oil under pressure is fed, via parking brake solenoid valve (9), into the brake cylinders.
- This moves the brake pistons against the compression spring load, releasing the brake.

### Circuit protection against high pressure

- High pressure relief valves (d) built in propulsion pump (3) open to relieve the pressure if the system pressure exceeds the setting of the valves.


### Charge circuit

- The propulsion circuit is of a closed circuit, which needs feeding of oil into it for making up deficiency.
- In the charge circuit, oil from steering • charge pump (5) flows into orbitrol (11), then the whole amount of oil goes to propulsion pump (3) via hydraulic oil filter 1 (12) irrespective of the steering wheel operation.
- Charge relief valve (b) built in propulsion pump (3) maintains the pressure to operate the pump swashplate when the F-R lever is in the neutral position. When travelling, low pressure relief valve (h), (r) built in propulsion motor (6), (17) performs oil renewal, cooling or removal of foreign material as well as keeping the necessary pressure to control the pump swashplate angle.



### 3. VIBRATOR HYDRAULIC SYSTEM


#### 3-1. Vibrator Hydraulic Piping





### 3-2. Hydraulic Component Specifications

#### 3-2-1. Vibrator hydraulic motor



Hydraulic circuit diagram

Flow of oil

- 2→1 Clockwise rotation
- 1→2 Counterclockwise rotation

SV400-2-04012


- (1) Port B [FVB] : 1 1/16-12UN
- (2) Port A [FVA] : 1 1/16-12UN
- (3) Drain port [VDM] : 7/ 8-14UNF
- (4) Drain port : 7/ 8-14UNF
- (5) Drain port [VDT] : 7/ 8-14UNF

#### Specifications

- Displacement : 35.0 cm<sup>3</sup>/rev ( 2.1 cu.in. )
- Working pressure : 34.5 MPa ( 5,003 psi )
- Allowable motor case pressure : 0.17 MPa ( 24.7 psi )
- Weight : 11 kg ( 24.3 lbs. )

Fig.: Vibrator circuit

- 1. Engine
- 2. Coupling
- 3. Propulsion pump
- 4. Vibrator pump
  - a. Amplitude select valve
  - b. Charge relief valve
  - c. High pressure relief valves
  - d. Check valves
- 5. Steering charge pump
- 6. Vibrator motor
- 7. Vibrator
- 8. Orbitrol
- 9. Hydraulic oil filter 1
- 10. Hydraulic oil filter 2
- 11. Oil cooler
- 12. Suction filter



### 3-3. Description and Operation of Vibrator System

#### Description

- Made up of vibrator pump (4), vibrator motor (6) and vibrator (7).

#### Basic function of vibrator pump and motor

##### Vibrator pump:

- A piston pump is in use. Varying the pump swashplate angle varies the piston stroke to select low amplitude, neutral and high amplitude.

##### Vibrator motor:

- A fixed displacement piston motor is used. The displacement per rotation of the motor shaft is not variable.

#### Operation (It is assumed that HIGH amplitude is selected.)

- The operation of the vibration select switch actuates amplitude select valve (a) built in vibrator pump (4) to discharge oil from the high amplitude port (port A).
- Oil fed into the high amplitude port (port B) of the motor powers the motor and displaced from the opposite side port (port A), getting back to the pump suction port (port B).

#### (NOTE)

- **Because the vibrator system also uses a closed circuit (HST) like the propulsion circuit, every time the amplitude election is changed from low amplitude to high or vice versa, the function of the pump inlet and outlet is reversed with each other.**

#### Circuit protection against high pressure

- High pressure relief valves (c) built in the vibrator pump (4) relieve pressure to protect the circuit when the pressure exceeds the setting of the valves.

#### Charge circuit


- The vibrator circuit is also of a closed circuit, which needs feeding of oil into it for making up for deficiency and for other purposes.
- In the charge circuit, oil from steering • charge pump (5) flows into Orbitrol (8), then the whole amount of oil goes to propulsion pump (3) via hydraulic oil filter 1 (9) irrespective of the steering wheel operation.
- Charge relief valve (b) maintains the charge pressure when the machine is not in motion. When travelling, the charge pressure is kept by the low pressure relief valve (h).
- For the “2-3. Description and Operation of Propulsion System”, refer to page 4-018.





# 4. STEERING SYSTEM



## 4-1. Steering Hydraulic Piping



• The letters and numbers in the figure such as "SLR" and "SRB" show each port.  
 • Arrow "↔"; "→" symbols show the hose connection and the direction of the flow of the oil.



## 4-2. Steering Wheel



0418-62813-0-12540-B

(1) Steering wheel

(2) Bolt : M10×30

(3) Column shaft

(4) Nut : M12

P=1.25



(5) Orbitrol



(4) Nut M12 P=1.25 : 35 N·m ( 26 lbf·ft )

### 4-3. Hydraulic Component Specifications

#### 4-3-1. Orbitrol



Hydraulic circuit diagram

ORB-SD-04150


- |            |                        |                  |                        |
|------------|------------------------|------------------|------------------------|
| (1) Port L | <b>[L]</b> : 3/4-16UNF | (4) Port P       | <b>[P]</b> : 3/4-16UNF |
| (2) Port R | <b>[R]</b> : 3/4-16UNF | (5) Relief valve |                        |
| (3) Port T | <b>[T]</b> : 3/4-16UNF |                  |                        |

Specifications

- Displacement : 400 cm<sup>3</sup>/rev ( 24.4 cu.in./rev )
- Relief valve pressure setting : 15.0 MPa ( 2,175 psi )
- Weight : 7 kg ( 15 lbs. )



Fig.: Steering circuit



- 1. Engine
- 2. Coupling
- 3. Propulsion pump
- 4. Vibrator pump
- 5. Steering-charge pump
- 6. Orbitrol
  - a. Relief valve
  - b. Check valve
- 7. Steering cylinders
  - c. Piston rods
- 8. Hydraulic oil filter 1
- 9. Suction filter

## 4-4. Description and Operation of Steering System

### 4-4-1. Description and operation of steering system

#### Description

- Made up of steering • charge pump (5), Orbitrol (6), steering cylinders (7) and hydraulic oil filter 1 (8). The steering mechanism is of an articulated type in which the machine frame is articulated at its center.

#### Operation

- The oil discharged from steering • charge pump (5) enters Orbitrol (6), and a certain quantity of oil that matches the handle turning direction and speed is supplied to steering cylinders (7).
- The oil that enters the steering cylinder shifts piston rod (c) to operate it, while the oil pushed out of the port on the opposite side returns to orbitrol (6), flowing into the charge circuit of propulsion pump (3) through hydraulic oil filter 1 (8).
- For the “Charge circuit”, refer to page 4-020.
- Relief valve (a) built in Orbitrol (6) opens to relieve the pressure if the system pressure exceeds the setting of the valve, thus protecting the circuit.

### 4-4-2. Structure and operation of Orbitrol

- Orbitrol used here is a load-sensing type, in which oil is supplied from the steering hydraulic pump according to the steering wheel rotating speed.



#### Structure

##### Valve section:

- The valve is a rotary-type direction changeover valve composed of spool (1) and sleeve (2), and the spline connects the steering wheel to spool (1).
- When the steering wheel is not operated, spool (1) and sleeve (2) are held at the neutral position by centering spring (6), and the oil groove of spool (1) is not aligned with the oil hole of sleeve (2), completely stopping the oil flow into the steering cylinder.
- When the steering wheel is operated, the oil groove of spool (1) is aligned with the oil hole of sleeve (2) to open the circuit, allowing the oil to flow into the steering cylinder.


##### Rotor section:

- The rotor is a kind of internal gear, functioning as a hydraulic motor when the valve section (spool and sleeve) opens.
- The rotation of rotor (4) is transmitted to the valve section by drive shaft (5), controlling the valve opening according to the steering wheel rotating speed.



- |           |                     |
|-----------|---------------------|
| 1. Spool  | 5. Drive shaft      |
| 2. Sleeve | 6. Centering spring |
| 3. Stator | 7. Cross pin        |
| 4. Rotor  | 8. Check valve      |

SV414-04006



SV414-04007




## Operation

### Neutral (when the steering wheel is not operated):

- Spool (1) and sleeve (2) in the valve section have a slit respectively, and centering spring (6) is set in the slit in combination with a flat spring.
- When steering wheel is not operated, spool (1) and sleeve (2) are held in the neutral position by centering spring (6).
- This Orbitrol is a load-sensing, non-load reaction normally-closed type valve. All the oil holes of the spool are out of place when Orbitrol is in the neutral position, and the flow of oil from the hydraulic pump into the steering cylinder is closed completely.

### Swing (when the steering wheel is operated):


- All the ports of the valve section are closed when Orbitrol is in the neutral position. The oil in the rotor has been sealed up, and rotor (4) is fixed. Sleeve (2) is coupled with rotor (4) via cross pin (7) and drive shaft (5), and it is fixed also.
- When the steering wheel is operated, the turning force is applied to spool (1), contracting centering spring (6) that has been set in the slit. As a result, the oil groove of spool (1) is aligned with the oil hole of sleeve (2), opening the hydraulic circuit.
- Consequently, all the four ports (hydraulic pump, tank, and steering cylinder circuits on the right and left sides) open to permit oil to flow, and rotor (4) rotates.



- |           |                     |
|-----------|---------------------|
| 1. Spool  | 5. Drive shaft      |
| 2. Sleeve | 6. Centering spring |
| 3. Stator | 7. Cross pin        |
| 4. Rotor  | 8. Check valve      |


SV414-04009

### Neutral



SV414-04008


### Swing



SV414-04010

### Operation of feedback mechanism:

- When the steering wheel is operated and the centering spring generates the displacement angle (misalignment in the circumferential direction) between the spool and sleeve, the oil from the hydraulic pump enters Orbitrol to rotate the rotor, and the oil flows into the steering cylinder.
- As a result, the sleeve rotates slightly later than the spool, following the rotation of the spool. This phenomenon permits the spool to rotate continuously, permitting the steering wheel to turn and the vehicle to swing continuously.
- When the steering wheel operation is stopped, the spool stops rotation immediately, but the oil flows into Orbitrol if the displacement angle exists between the spool and sleeve, permitting the rotor to rotate continuously. This rotation allows the sleeve to catch up with the spool, closing the hydraulic circuit. Finally, the centering spring returns the spool and sleeve back to the neutral position, completely stopping the oil flow.





SV414-04011

**Steering speed and flow control:**

- In the steering mechanism, the flow to the steering cylinder must be increased or decreased according to the rotational speed of the steering wheel.
- Orbitrol controls the flow by changing the displacement angle between spool (1) and sleeve (2). In other words, sleeve (2) follows the rotation of spool (1) during the steering wheel operation, closing the hydraulic circuit.
- When rotational speed of the steering wheel increases, the delay of sleeve (2) (displacement angle) increases, increasing the flow.

**Hydraulic pump flow and operating force:**

- When the hydraulic pump discharge is sufficient, the steering operating force is used simply to overcome the sliding resistance of sleeve (2) and the rotor, permitting the steering wheel to rotate easily.
- When the hydraulic pump discharge is insufficient, the displacement angle between spool (1) and sleeve (2) reaches the maximum, reducing the quantity of oil flowing from the hydraulic pump into the rotor even if the hydraulic circuit opens widely, causing the rotor to rotate slowly.
- As a result, the spool rotation becomes faster than the rotor rotation to increase the displacement angle to a maximum extent, and the spool rotates the rotor via the cross pin and drive shaft. At that time, the rotor functions as a hydraulic pump, preventing the steering wheel from rotating smoothly.



1. Spool
2. Sleeve
6. Centering spring

SV414-04012



---

---

# **ELECTRICAL SYSTEM**

---


---




# 1. PRECAUTIONS FOR WORK

## 1-1. Wire Numbers, Wire Sizes, Wire Colors and Connectors Shown in Electrical Circuit Diagram, Wiring Harness Layout and Wiring Harnesses

- Codes used in electrical circuit diagrams give the following information.
- The wire size is AVS 0.85 unless otherwise specified.



- The pin or socket layout of mating connectors are symmetrical, either vertically or horizontally. When the connector valves are connected, the pin and socket that have the same number are connected.



## ELECTRICAL SYSTEM


- Wire color code chart

B	Black	BW	Black/White stripe	BY	Black/Yellow stripe	BR	Black/Red stripe	BG	Black/Green stripe	BL	Black/Blue stripe			O	Orange	YO	Yellow/Orange stripe
W	White	WR	White/Red stripe	WB	White/Black stripe	WL	White/Blue stripe	WY	White/Yellow stripe	WG	White/Green stripe					LO	Blue/Orange stripe
R	Red	RW	Red/White stripe	RB	Red/Black stripe	RY	Red/Yellow stripe	RG	Red/Green stripe	RL	Red/Blue stripe					GO	Green/Orange stripe
G	Green	GW	Green/White stripe	GR	Green/Red stripe	GY	Green/Yellow stripe	GB	Green/Black stripe	GL	Green/Blue stripe			Gy	Gray	GyR	Gray/Red stripe
Y	Yellow	YR	Yellow/Red stripe	YB	Yellow/Black stripe	YG	Yellow/Green stripe	YL	Yellow/Blue stripe	YW	Yellow/White stripe					GyL	Gray/Blue stripe
Br	Brown	BrW	Brown/White stripe	BrR	Brown/Red stripe	BrY	Brown/Yellow stripe	BrB	Brown/Black stripe	BrG	Brown/Green stripe	BrL	Brown/Blue stripe	Sb	Sky blue		
L	Blue	LW	Blue/White stripe	LR	Blue/Red stripe	LY	Blue/Yellow stripe	LB	Blue/Black stripe	LG	Blue/Green stripe			P	Pink	PB	Pink/Black stripe
Lg	Light green	LgR	Light green/Red stripe	LgY	Light green/Yellow stripe	LgB	Light green/Black stripe	LgW	Light green/White stripe	LgL	Light green/Blue stripe			Pu	Purple		

## 1-2. Electrical Equipment Installation

When wiring electrical components to this machine (for example, additional lighting or electrical devices), connect all grounds to a common ground location and then return to the negative side of the battery. Do not wire to the engine block, starter or alternator terminals. Reference picture is below.


**Attention! Do NOT wire to engine, alternator or starter motor.**





# 2. SYSTEM CIRCUIT DIAGRAM




## 2-1. Electrical Circuit Diagram






### 3. ELECTRICAL COMPONENTS


#### 3-1. Wiring Harness Layout (1)



#### SECTION B-B









#### DETAIL D



#### DETAIL E




3-2. Wiring Harness Layout (2)



# 4. WIRING HARNESSSES


## 4-1. Frame Harness (1)



No.	SIZE, COLOR	CONTACT POINTS	CONNECTION	
			(1)	(2)
ⓧ	B, 2B, 3B	13	#2D3, 2, 7M2, BU, H × 2, R, Fuel gauge unit, Ground, Parking brake solenoid, Servo bypass solenoid, Speed change solenoid (F), Terminating resistor -C	
②	GB	2	8M3, BU	
③	5R, 8R	3	1, 6M1 × 2	
④	BY, 5BY	3	#4D5, 1, 8M3	
⑥	YB	2	#3D4, Fuel gauge unit	
⑦	WG	2	5	Engine ECM-31
⑨	YR	2	8M3, H	
⑩	YB	2	8M3, H	
⑭	5R	2	3, Starter motor	
⑮	5RB	2	3, Starter motor	
⑱	2RW	2	2, 7M2	
㉓	3RG	2	2, 7M2	
㉔	BR	3	#3D4, 5, 8M3	
㉖	2Lg	2	#2D3, 7M2	
㉙	LB	2	M, 8M3	
⑤⑩	LW	2	#3D4, R	
⑤③	WR	2	#3D4, Speed change solenoid (F)	

No.	SIZE, COLOR	CONTACT POINTS	CONNECTION	
			(1)	(2)
⑥⑥	LY	3	8M3, Servo bypass solenoid, Parking brake solenoid	
⑦②	B	2	4, Ground	
⑦⑧	2WB, 3WB	4	2	Engine ECM-1, 3, 5
⑦⑨	2B, 3B	4	Ground	Engine ECM-2, 4, 6
⑧②	G	3	#5D6, Terminating resistor	Engine ECM-84
⑧③	L	3	#5D6, Terminating resistor	Engine ECM-62
⑧⑦	B	2	#3D4, Ground	
⑨①	LW	2	8M3	Engine ECM-39
⑨②	WL	2	8M3	Engine ECM-61
⑨④	BW	2	#3D4	Engine ECM-43
⑨⑧	BL	2	8M3	Engine ECM-15
⑩⑦	LgY	2	8M3	Engine ECM-9
⑩⑧	GB	3	5, 8M3	Engine ECM-57
⑪②	15B	2	Ground × 2	
⑪⑧	1.25WR	2	4, 8M3	
⑬⑩	BR	2	M	Engine ECM-87
⑬①	LgR	2	M	Engine ECM-70
⑬②	RW	2	M	Engine ECM-44
⑬③	GL	2	Fuel sensor	Engine ECM-69
⑬④	BrR	2	Fuel sensor	Engine ECM-45
⑭④	5BW	2	Ground × 2	

4-2. Frame Harness (2)




DETAIL A



No.	SIZE, COLOR	CONTACT POINTS	CONNECTION	
			(1)	(2)
ⓧ	B, 2B, 3B	13	#2D3, 2, 7M2, BU, H × 2, R, Fuel gauge unit, Ground, Parking brake solenoid, Servo bypass solenoid, Speed change solenoid (F), Terminating resistor -C	
②	GB	2	8M3, BU	
③	5R, 8R	3	1, 6M1 × 2	
④	BY, 5BY	3	#4D5, 1, 8M3	
⑥	YB	2	#3D4, Fuel gauge unit	
⑦	WG	2	5	Engine ECM-31
⑨	YR	2	8M3, H	
⑩	YB	2	8M3, H	
⑭	5R	2	3, Starter motor	
⑮	5RB	2	3, Starter motor	
⑱	2RW	2	2, 7M2	
㉓	3RG	2	2, 7M2	
㉔	BR	3	#3D4, 5, 8M3	
㉖	2Lg	2	#2D3, 7M2	
㉙	LB	2	M, 8M3	
⑤⑩	LW	2	#3D4, R	
⑤③	WR	2	#3D4, Speed change solenoid (F)	

No.	SIZE, COLOR	CONTACT POINTS	CONNECTION	
			(1)	(2)
⑥⑥	LY	3	8M3, Servo bypass solenoid, Parking brake solenoid	
⑦②	B	2	4, Ground	
⑦⑧	2WB, 3WB	4	2	Engine ECM-1, 3, 5
⑦⑨	2B, 3B	4	Ground	Engine ECM-2, 4, 6
⑧②	G	3	#5D6, Terminating resistor	Engine ECM-84
⑧③	L	3	#5D6, Terminating resistor	Engine ECM-62
⑧⑦	B	2	#3D4, Ground	
⑨①	LW	2	8M3	Engine ECM-39
⑨②	WL	2	8M3	Engine ECM-61
⑨④	BW	2	#3D4	Engine ECM-43
⑨⑧	BL	2	8M3	Engine ECM-15
⑩⑦	LgY	2	8M3	Engine ECM-9
⑩⑧	GB	3	5, 8M3	Engine ECM-57
⑪②	15B	2	Ground × 2	
⑪⑧	1.25WR	2	4, 8M3	
⑬⑩	BR	2	M	Engine ECM-87
⑬①	LgR	2	M	Engine ECM-70
⑬②	RW	2	M	Engine ECM-44
⑬③	GL	2	Fuel sensor	Engine ECM-69
⑬④	BrR	2	Fuel sensor	Engine ECM-45
⑭④	5BW	2	Ground × 2	


4-3. Panel Harness



No.	SIZE, COLOR	CONTACT POINTS	CONNECTION
ⓧ	B,2B	7	#2D3, J, P, Combination meter-3, Ground, Horn, Terminating resistor-C
④	5BY	2	#4D5, E
⑥	YB	2	#3D4, Combination meter-18
⑨	YR	2	5D2, B
⑩	YB	2	5D2, B
⑪	Y	2	5D2, B
⑫	R	2	4D1, Foot brake switch-COM
⑫	Y	3	Combination meter-16, Hydraulic oil filter harness × 2
⑫	BR	2	#3D4, E
⑫	2Lg	2	#2D3, E
⑫	1.25LgW	2	5D2, E
⑫	RY	2	5D2, T
⑫	Br	2	5D2, Combination meter-27
⑫	BY	3	4D1, Combination meter-10, 15
⑫	Lg	2	5D2, Horn switch
⑫	LgW	2	5D2, Horn
⑫	YW	3	4D1, Combination meter-2, 22
⑫	LgR	2	P, Foot brake switch-NO
⑫	BrW	2	4D1, P
⑫	GR	2	P, Combination meter-14

No.	SIZE, COLOR	CONTACT POINTS	CONNECTION
③⑨	L	2	5D2, P
④①	RG	2	4D1, Combination meter-30
⑤⑩	LW	2	#3D4, P
⑤①	G	2	5D2, P
⑤②	BrR	2	5D2, P
⑤③	WR	3	#3D4, 5D2, P
⑤④	LR	2	5D2, P
⑥⑦	BrY	2	4D1, P
⑦⑩	WR	2	4D1, Combination meter-1
⑧①	RG	2	5D2, B
⑧②	G	4	#5D6, Combination meter-11, Data link interface connector-C, Terminating resistor-A
⑧③	L	4	#5D6, Combination meter-12, Data link interface connector-D, Terminating resistor-B
⑧⑦	B	2	#3D4, Data link interface connector-A
⑨③	WG	2	5D2, T
⑨④	BW	2	#3D4, T
⑨⑥	Lg	2	J, Combination meter-21
⑨⑦	RW	3	5D2, B, T
⑩⑧	1.25WR	2	4D1, Data link interface connector-B


4-4. Fuse · Relay Box Assembly



No.	SIZE, COLOR	CONTACT POINTS	CONNECTION
ⓧ	B,2B	9	<b>2C</b> , <b>7M2</b> , Lamp check relay (A9), Relay box-A1, A2, A3, A4, A6, A7
②	GB	2	<b>3C</b> , <b>8M3</b>
③	5R	4	<b>6M1</b> × 2, Fuse box-4, 7
④	BY	2	<b>8M3</b> , Fuse box-10
⑨	YR	3	<b>5D2</b> , <b>8M3</b> , Diode unit
⑩	YB	3	<b>5D2</b> , <b>8M3</b> , Diode unit
⑪	Y	2	<b>3C</b> , <b>5D2</b>
⑫	R	4	<b>3C</b> , <b>4D1</b> , Fuse box-7, Relay box-A4
⑬	W	3	<b>3C</b> , Diode unit, Relay box-A1
⑯	2W	2	Fuse box-9, Relay box-A5
⑱	2RW	2	<b>7M2</b> , Relay box-A5
⑳	3RG	2	<b>7M2</b> , Fuse box-1
㉑	BR	2	<b>8M3</b> , Fuse box-11
㉒	2BW	2	Fuse box-9, Relay box-A2
㉓	2Lg	2	<b>7M2</b> , Relay box-A1
㉔	LgW	2	<b>5D2</b> , Lamp check relay (A9)
㉕	LB	2	<b>8M3</b> , Lamp check relay (A9)
㉖	RY, 1.25RY	4	<b>5D2</b> , Fuse box-8, Horn relay (A8) × 2
㉗	Br	2	<b>5D2</b> , Diode unit
㉘	BY	2	<b>4D1</b> , Lamp check relay (A9)
㉙	Lg	2	<b>5D2</b> , Horn relay (A8)
㉚	LgW	2	<b>5D2</b> , Horn relay (A8)
㉛	YW	2	<b>4D1</b> , Fuse box-6


No.	SIZE, COLOR	CONTACT POINTS	CONNECTION
⑳	BrW	2	<b>4D1</b> , Relay box-A3
㉑	L	2	<b>5D2</b> , Fuse box-5
㉒	RG	2	<b>4D1</b> , Fuse box-3
㉓	1.25RG, 2RG	3	<b>1-1</b> × 2, Fuse box-1
㉔	G	2	<b>5D2</b> , Relay box-A7
㉕	BrR	2	<b>5D2</b> , Relay box-A7
㉖	WR	2	<b>5D2</b> , Relay box-A7
㉗	LR	2	<b>5D2</b> , Relay box-A7
㉘	GW	3	Diode unit, Relay box-A3, A4
㉙	LY	3	<b>8M3</b> , Relay box-A3, A4
㉚	BrY	2	<b>4D1</b> , Relay box-A2
㉛	2LgR	2	Relay box-A1, A2
㉜	WR	2	<b>4D1</b> , Fuse box-10
㉝	RG	2	<b>3C</b> , <b>5D2</b>
㉞	LW	2	<b>8M3</b> , Relay box-A6
㉟	WL	2	<b>8M3</b> , Relay box-A6
㊱	WG	2	<b>5D2</b> , Relay box-A6
㊲	RW	2	<b>5D2</b> , Relay box-A6
㊳	BL	2	<b>8M3</b> , Fuse box-11
㊴	LgY	2	<b>8M3</b> , Relay box-A5
㊵	GB	2	<b>8M3</b> , Relay box-A5
㊶	1.25WR	2	<b>4D1</b> , <b>8M3</b>
㊷	1.25YB, 2YB	3	<b>#1-2</b> × 2, Fuse box-2
㊸	2Br	2	<b>2C</b> , Fuse box-4

4-5. Battery Relay Harness



No.	SIZE, COLOR	CONTACT POINTS	CONNECTION
ⓧ	2B	2	2, Starter relay
③	8R	2	1, Fusible link 75A
④	5BY	2	1, Fusible link 65A
⑦	WG	2	5, Grid heater relay
⑭	5R	2	3, Starter relay
⑮	5RB	2	3, Starter relay
⑱	2RW	2	2, Starter relay
⑳	3RG	2	2, Fusible link 45A
㉔	BR	3	5, Battery relay-BR, Diode-1
㉗	B	3	4, Battery relay-Ground, Diode-2
㉘	3G	2	Battery relay-NO, Fusible link 45A
㉙	8WR	2	Battery relay-NO, Fusible link 75A
㉚	5BW	2	Battery relay-COM, Fusible link 65A
㉛	3WB	2	2, Fuse 30A
⑧⑥	1.25WL, 3WL	3	Battery relay-COM, Fuse 10A, Fuse 30A
⑩⑧	GB	2	5, Grid heater relay
⑪⑧	1.25WR	2	4, Fuse 10A

### 4-6. Stater Switch Harness




1404-09077-0-31751-0

No.	SIZE, COLOR	CONTACT POINTS	CONNECTION
④	5BY	2	<b>E</b> , Starter switch-B
②④	BR	2	<b>E</b> , Starter switch-BR
②⑥	2Lg	2	<b>E</b> , Starter switch-C
②⑧	1.25LgW	2	<b>E</b> , Starter switch-ACC




## 4-7. Control Switch Harness



1421-09020-0-20151-0

No.	SIZE, COLOR	CONTACT POINTS	CONNECTION
(X)	B	2	[P], Parking brake switch-5
(36)	LgR	2	[P], Parking brake switch-1
(37)	BrW	2	[P], Parking brake switch-3
(38)	GR	2	[P], Parking brake switch-4
(39)	L	2	[P], Speed select switch-4
(50)	LW	3	[P], Speed select switch-5, Travel mode change switch-3
(51)	G	2	[P], Speed select switch-3
(52)	BrR	2	[P], Speed select switch-6
(53)	WR	2	[P], Travel mode change switch-2
(54)	LR	2	[P], Travel mode change switch-1
(67)	BrY	2	[P], Parking brake switch-2


### 4-8. Throttle Switch Harness



1421-09021-0-30152-0

No.	SIZE, COLOR	CONTACT POINTS	CONNECTION
③①	RY	2	T, Throttle switch-4
⑨③	WG	2	T, Throttle switch-3
⑨④	BW	2	T, Throttle switch-1
⑨⑦	RW	2	T, Throttle switch-5


### 4-9. Vibration Switch Harness



1421-09022-0-30153-0

No.	SIZE, COLOR	CONTACT POINTS	CONNECTION
⑨	YR	2	<b>B</b> , Vibration select switch-5
⑩	YB	2	<b>B</b> , Vibration select switch-2
⑪	Y	4	<b>B</b> , Vibration mode change switch-2, Vibration select switch-1, -4
⑧①	RG	2	<b>B</b> , Vibration mode change switch-3
⑨⑦	RW	2	<b>B</b> , Vibration mode change switch-1


4-10. Control Harness



1421-09043-1-20244-A

No.	SIZE, COLOR	CONTACT POINTS	CONNECTION
ⓧ	2B	2	2C, POW
②	GB	2	3C, Backup buzzer switch-NO
⑪	Y	2	3C, F-R lever vibration switch harness
⑫	R	3	3C, Backup buzzer switch-COM, F-R lever switch-COM
⑬	W	2	3C, F-R lever switch-NC
⑧①	RG	2	3C, F-R lever vibration switch harness
⑫③	2Br	2	2C, POW


## 4-11. F-R Lever Vibration Switch Harness



1539-12013-0-30226-0

No.	SIZE, COLOR	CONTACT POINTS	CONNECTION
–	Br	2	Control harness, F-R lever vibration switch-1
–	G	2	Control harness, F-R lever vibration switch-2
–	W	2	Control harness, F-R lever vibration switch-3


### 4-12. Speed Change Solenoid Harness



1412-09005-0-30074-A

No.	SIZE, COLOR	CONTACT POINTS	CONNECTION
(X)	B	2	<b>R</b> , Speed change solenoid (R)
(50)	LW	2	<b>R</b> , Speed change solenoid (R)


### 4-13. Vibrator Solenoid Harness



1402-09020-1-30430-D

No.	SIZE, COLOR	CONTACT POINTS	CONNECTION
(X)	B	4	[H] × 2, Vibrator solenoid (a), (b)
(9)	YR	2	[H], Vibrator solenoid (b)
(10)	YB	2	[H], Vibrator solenoid (a)

### 4-14. Diagnostic Switch Harness



1421-09023-1-30154-A

No.	SIZE, COLOR	CONTACT POINTS	CONNECTION
(X)	B	2	J, Diagnostic switch-3
(96)	Lg	2	J, Diagnostic switch-2




## 4-15. Hydraulic Oil Filter Harness



1405-09009-0-40195-0

No.	SIZE, COLOR	CONTACT POINTS	CONNECTION
(22)	Y	2	Hydraulic oil filter switch, Panel harness


### 4-16. Engine Harness



1421-09042-0-20243-A

No.	SIZE, COLOR	CONTACT POINTS	CONNECTION
②9	1.25LB	2	<b>M</b> , Alternator
⑬0	BR	2	<b>M</b> , Coolant level sensor
⑬1	LgR	2	<b>M</b> , Coolant level sensor
⑬2	RW	2	<b>M</b> , Coolant level sensor

## 4-17. Backup Buzzer Harness




1421-09044-0-30245-0

No.	SIZE, COLOR	CONTACT POINTS	CONNECTION
ⓧ	B	2	<b>BU</b> , Backup buzzer (-)
②	GB	2	<b>BU</b> , Backup buzzer (+)

# 5. ELECTRICAL COMPONENT SPECIFICATIONS

## 5-1. Fuse Box






SV414-05001

**Harness color codes**


- |                          |                                |
|--------------------------|--------------------------------|
| W : White                | WR : White/Red stripe          |
| R : Red                  | RY : Red/Yellow stripe         |
| Br : Brown               | RG : Red/Green stripe          |
| L : Blue                 | YW : Yellow/White stripe       |
| BW : Black/White stripe  | LgW : Light green/White stripe |
| BY : Black/Yellow stripe |                                |
| BL : Black/Blue stripe   |                                |

## 5-2. Combination Meter



Harness side

### DETAIL A



PIN	DESCRIPTION	NO.
1	Battery 12V (+)	(70)
2	Starter switch (ACC)	(35)
3	Ground	(X)
4	Turn signal (R)	
5	Engine stop	
6	Over heat	
7	REV. ratio SEL.1	
8	REV. ratio SEL.3	
9	Buzzer	
10	Lamp check	(32)
11	CAN(+)	(82)
12	CAN(-)	(83)
13	Head lamp	
14	Parking brake	(38)
15	Charge warning	(32)
16	HYD. oil filter warning	(22)
17	Engine warning	
18	Fuel meter	(6)
19	REV. ratio SEL.2	
20	REV. ratio SEL.4	
21	DTC display	(96)
22	Hour meter	(35)
23	Turn signal (L)	
24	Preheating	
25	Water spray	
26	Flood lamp	
27	Vibrator	(31)
28	Liquid spray	
29	High beam	
30	COMBI. meter ILLUMI.	(41)
31	Exhaust system high temperature	
32	DEF low level	
33	Manual regeneration	
34	LYS pin	
35	ECO mode	



---

---

# **VIBRATORY DRUM • REAR AXLE**

---

---





# 1. PRECAUTIONS FOR DISASSEMBLY AND REASSEMBLY

- When removing, installing, disassembling or reassembling the unit, observe the general precautions described below.
- 1) Precautions for removal work
    - Coolant that contains antifreeze should be treated as a chemical, and must not be drained carelessly on the ground.
    - To prevent dust from getting into disconnected hoses and tubes, cover them with a plug or similar means.
    - When draining oil, use a receptacle with sufficient capacity to receive it.
    - Before proceeding with the work, look for matchmarks that show the installation location. For reassembly, place matchmarks in the required locations to prevent errors. Then remove.
    - When disconnecting wiring connectors, hold the connector components so that unreasonable force is not applied to the wires.
    - Label wires and hoses to ensure correct installation location.
    - Confirm the number and thickness of shims prior to storage.
    - When lifting parts, use lifting equipment of sufficient capacity.
    - When separating parts by using pull bolts, tighten the bolts alternately.
    - Before removing a unit, clean its surrounding area. Then after removal, cover it to prevent dust and other substances from getting in.
    - Before removing piping for hydraulic oil or coolant, or removing related parts, satisfactorily release internal pressure.
  - 2) Precautions for installation work
    - Tighten bolts and nuts (sleeve nuts) to the specified torque (screw tightening torque table).
    - When installing hoses, do not twist them or allow them to interfere with other parts.
    - Replace gaskets, O-rings, split pins, and lock plates with new parts.
    - Properly bend split pins and lock plates.
    - When applying an adhesive, first clean and remove oil/grease from the surfaces properly. Then apply two or three drops to the threaded areas.
    - When applying a liquid gasket, first clean and remove oil/grease from the application surface properly, and confirm that the surface is free of dust and damage. Then apply the product evenly.
    - Clean parts well. Repair scratches, dents, burrs, rust, etc.
    - Apply grease to rotating and sliding components.
    - Apply gear oil to the surfaces of press-fit parts.
    - After installing snap rings, confirm that they are properly seated in the grooves.
    - Connect wiring connectors securely after cleaning off adhering oil, dust and water.
    - Use lifting bolts that are not fatigued or deformed. Screw them in fully.
    - When tightening a split flange, tighten screws alternately to prevent uneven tightening.
    - Before installing hydraulic parts, confirm that they are free of damage and dust, etc.

3) Precautions when work is completed

- If coolant has been drained, securely retighten the drain valve and fill with coolant (mixing in long-life coolant) to the specified level. Start the engine and allow the coolant to circulate through the piping. Then add coolant again to the specified level.
- If hydraulic equipment has been removed and reinstalled, fill with hydraulic oil to the specified level. Start the engine and allow the oil to circulate through the piping. Then add oil again to the specified level.

## 2. VIBRATORY DRUM


### 2-1. Removal and Installation of Vibratory Drum

#### 2-1-1. Removal of vibratory drum

- 1) Securing machine
  - Hold drum with chocks.
  - Joint front frame and rear frame with lock pin (1).

### **⚠ WARNING**

When lifting the machine body, use an appropriate hoist of sufficient strength. Confirm that the surrounding area is safe, and work in a natural, unstrained posture. Also, to firmly secure the machine body, use a support stand of sufficient strength.



- 2) Supporting rear frame
  - Lift rear frame with a crane.
  - Place support stands under rear frame when rear wheel tires is slightly off ground to support machine body.




Rear axle weight

- SV414D : 3,600 kg (7,935 lbs.)
- SV414T : 3,600 kg (7,935 lbs.)
- SV414TF : 3,600 kg (7,935 lbs.)

#### (NOTICE)

- Do not allow rear wheel tires to leave the ground. (The tires must support the machine's body weight, too.)




- 3) Lift front frame with a crane.
  - Ensuring that no load is applied to bolts (2) (left and right sides), place support stands at right and left sides of front frame. Firmly secure machine body.



Front axle weight

- SV414D : 3,490 kg ( 7,695 lbs.)
- SV414T : 3,490 kg ( 7,695 lbs.)
- SV414TF : 4,720 kg (10,405 lbs.)



## VIBRATORY DRUM • REAR AXLE

- 4) Lift cross member (3) with a crane and hold it.
  - Remove bolts (4) (left and right sides).
  - Lift cross member (3) and remove it from frame.




Cross member

SV414D : 180 kg (397 lbs.)

SV414T : 260 kg (573 lbs.)


SV414TF : 295 kg (650 lbs.)



### **WARNING**

The hydraulic oil in the machine is hot and compressed immediately after the machine is stopped. Disconnecting the hydraulic hoses in this condition can cause burns. Wait for the hydraulic oil to cool down before starting the work.

- 5) Disconnecting piping
  - 5-1) Propulsion motor piping
    - Disconnect hydraulic hoses (5), (6), (7) and (8) connecting to propulsion motor.




#### (NOTICE)

- Plug both ends of the disconnected hoses or implement other actions to prevent entry of foreign matter.


- 5-2) Vibrator motor piping
  - Disconnect hydraulic hoses (9), (10), (11) and (12) connecting to vibrator motor.

#### (NOTICE)


- Plug both ends of the disconnected hoses or implement other actions to prevent entry of foreign matter.




- 5-3) Remove vibratory drum ASSY
- Lift off vibratory drum ASSY (13) from frame.
  - Remove bolts (2).
  - Remove vibratory drum ASSY.

 **Vibratory drum ASSY**

- SV414D : 2,520 kg (5,556 lbs.)
- SV414T : 2,495 kg (5,500 lbs.)
- SV414TF : 3,785 kg (8,344 lbs.)



- 6) Put chocks or the like under removed drum (13) to prevent it from moving.



## 2-1-2. Installation of vibratory drum

- 1) Install vibratory drum in the reverse order in which it was removed.
  - Tightening torque for bolts where particular care is required when installing vibratory drum.



(2) Bolts M20×80 : 539 N·m (398 lbf·ft)  
(Vibrator drum)

(4) Bolts M20×90 : 539 N·m (398 lbf·ft)  
(Cross member)


- 2) Upon installing vibratory drum, pay particular attention to items mentioned below.
  - Fill hydraulic oil tank to specified level to make up for any oil leakage.
  - Start engine and circulate oil through piping. Then check oil level again, ensuring that the oil is at specified level.

### (NOTICE)


- **If the engine is run at high speed or the cylinder is operated to full stroke when the engine is started for the first time after the work is completed, the piston packing or other items may be damaged by air entering into the cylinder.**

### 3. VIBRATORY DRUM ASSY


#### 3-1. Vibratory Drum ASSY




- (1) Drum
- (2) Bolt : M22×70
- (3) Bolt : M16×50
- (4) Ring
- (5) Plug
- (6) Bolt : M16×50
- (7) Vibrator bearing
- (8) Eccentric shaft
- (9) Shaft
- (10) Bolt : M10×40
- (11) Sleeve
- (12) Spring pin
- (13) Bolt : M16×50
- (14) Plug
- (15) Disc
- (16) Bolt : M12×40
- (17) Nut : M12
- (18) Damper
- (19) Bolt : M12×40
- (20) Nut : M12
- (21) Holder
- (22) Plate
- (23) Bolt : M20×80
- (24) Nut : M20
- (25) Bolt : M20×80
- (26) Breather
- (27) Cover
- (28) O-ring
- (29) Vibrator motor
- (30) Bolt : M14×40
- (31) Bolt : M14×40
- (32) Cover
- (33) Oil seal
- (34) Bolt : M12×40
- (35) Holder
- (36) Shim
- (37) Housing
- (38) Roller bearing
- (39) Oil seal
- (40) O-ring
- (41) Axle shaft
- (42) Vibrator bearing
- (43) O-ring
- (44) Housing
- (45) Gear box
- (46) Disc
- (47) Bolt : M12×40
- (48) Nut : M12
- (49) Damper
- (50) Bolt : M12×40
- (51) Nut : M12
- (52) Holder
- (53) Bolt : M16×45
- (54) Bolt : M 8×16
- (55) Propulsion motor
- (56) Bolt : M16×40
- (57) Bolt : M20×80
- (58) Nut : M20
- (59) Holder



SECTION A-A



Propulsion motor side



Vibrator motor side

0421-43801-0-10017-0






### 3-2. Disassembly and Reassembly of Vibratory Drum

- Lead line numbers shown in the illustrations for the following vibratory drum disassembly and reassembly procedures are constant with part numbers of vibratory drum ASSY shown on page 6-007.

#### 3-2-1. Disassembly of vibratory drum

- 1) Remove plugs (14-1) and (14-2).
  - Drain gear oil in vibrator case.
  - Quantity of gear oil : 21 L (5.5 gal.)
  - Install plug (14-1) and drain plug (14-2).




### **⚠ WARNING**

- When standing the vibratory drum, use wooden blocks of sufficient strength to securely support the drum.
- Carry out the work in an unstrained posture using a work stool or the like.

- 2) Lift vibratory drum ASSY with a crane and stand it with its vibrator motor (29) side facing up as shown on the right.


$\mathfrak{J}_{kg}$	Vibratory drum ASSY
	SV414D : 2,500 kg (5,512 lbs.)
	SV414T : 2,470 kg (5,445 lbs.)
	SV414TF : 3,765 kg (8,300 lbs.)



- 3) Remove bolts (31).
  - Remove Vibrator motor (29).

$\mathfrak{J}_{kg}$	(29) Vibrator motor : 15 kg (33 lbs.)
---------------------	---------------------------------------


- Remove breather (26).




**⚠ WARNING**

When installing lifting bolts, secure them with nuts.

4) Install lifting bolts (M20) and nuts to holders (21) and (35).




5) Remove bolts (25).




6) Remove disc SUBASSY.


⚠<sub>kg</sub> Disc SUBASSY : 135 kg (298 lbs.)



- 7) Remove sleeve (11).
  - Remove bolts (13).




- 8) Lift axle shaft SUBASSY using two pulling bolts (M20×60).



**⚠ WARNING**

When installing lifting bolts, screw in the threads fully before using.

- 9) Install lifting bolts (M20) to axle shaft SUBASSY.




10) Remove axle shaft SUBASSY.


**(NOTICE)**

- In order not to lift eccentric shaft together with axle shaft SUBASSY, tap on the eccentric shaft end with a wooden hammer via a wooden bar during lifting.


  $k_g$  Axle shaft SUBASSY : 150 kg (331 lbs.)



11) Put axle shaft SUBASSY on wooden blocks.




12) Install a lifting bolt (M10) to eccentric shaft SUBASSY.



**⚠ WARNING**


Take care not to get your fingers caught in movable weights.

13) Remove eccentric shaft SUBASSY.

 kg Eccentric shaft SUBASSY : 135 kg (298 lbs.)

**(NOTICE)**


- Put the movable weight at its outmost position.




**⚠ WARNING**

Be careful because reversing the vibratory drum involves risk. Confirm that the surrounding area is safe, and work in a natural, unstrained posture.

14) Reverse drum SUBASSY.


 kg Drum SUBASSY


- SV414D : 2,055 kg (4,530 lbs.)
- SV414T : 2,045 kg (4,508 lbs.)
- SV414TF : 3,325 kg (7,330 lbs.)



15) Remove bolts (56).


- Remove propulsion motor (55).

 kg (55) Propulsion motor : 30 kg (66 lbs.)




## VIBRATORY DRUM • REAR AXLE


16) Install lifting bolts (M20) and nuts to holders (52) and (59).




17) Remove bolts (53).




18) Remove disc SUBASSY.

 Disc SUBASSY : 115 kg (254 lbs.)




19) Install lifting bolts (M16) to gear box (45).

- Remove bolts (3).




20) Remove gear box (45).

$\mathfrak{J}_{kg}$  (45) Gear box : 120 kg (265 lbs.)




21) Install lifting bolts (M16) to housing SUBASSY.


- Remove bolts (6).




## VIBRATORY DRUM • REAR AXLE

22) Remove housing SUBASSY.


 Housing SUBASSY : 100 kg (220 lbs.)



23) Put housing SUBASSY on wooden blocks.




24) The right illustration shows axle shaft SUBASSY removed from vibratory drum.







- 25) Remove bolts (34).  
 • Remove cover (27).



- 26) Remove bolts (30).  
 • Remove cover (32).  
 • Remove shim (36).




- 27) Put a piece of wooden board on the end of axle shaft (41) and set a puller on housing (37).  
 • Separate housing SUBASSY together with roller bearing from axle shaft SUBASSY.




## VIBRATORY DRUM • REAR AXLE

28) Install lifting bolts (M12) to housing SUBASSY.




29) Remove housing SUBASSY.


$\mathfrak{J}_{kg}$  Housing SUBASSY : 45 kg (99 lbs.)




30) The right illustration shown housing SUBASSY removed from vibratory drum.



31) Remove bolts (54) and seal washers.



32) Remove vibrator bearing (7) using long bolts (M8).




### 3-2-2. Reassembly of vibratory drum

- Before reassembling, clean disassembled parts well and check that there is no abnormality.

## **⚠ WARNING**

- When standing the drum, use wooden blocks of sufficient strength to securely support the drum.
- Carry out the work in an unstrained posture using a work stool or the like.

- 1) Lift vibratory drum (1) with a crane and put it in an upright position.

 (1) Drum

SV414D : 1,685 kg (3,715 lbs.)

SV414T : 1,660 kg (3,660 lbs.)

SV414TF : 2,955 kg (6,515 lbs.)

- 2) Apply a coat of gear oil to vibrator bearing (7) mounting surface of housing (44).


- Drive vibrator bearing into housing.

### (NOTICE)


- Take care not to damage the bearing when installing it.

- 3) Apply grease to O-ring (43).


- Install O-ring to housing (44).



SV510-III-06045



SV414-06022




SV414-06023

4) Reverse housing SUBASSY.

 Housing SUBASSY : 100 kg (220 lbs.)

- Apply grease to O-rings for plugs (5).
- Install plugs to housing SUBASSY.
- Install bolts (54) and seal washers to housing SUBASSY.




**⚠ WARNING**

When installing lifting bolts, screw in the threads fully before using.

5) Install lifting bolts (M16) to housing SUBASSY.  
 • Lift housing SUBASSY.


 Housing SUBASSY : 100 kg (220 lbs.)



6) Lower housing SUBASSY on mounting surface of drum (1).

(NOTICE)

- Take care not to let O-ring to protrude from its groove.




## VIBRATORY DRUM • REAR AXLE

- 7) Secure housing SUBASSY with sixteen bolts (6) and washers.



(6) Bolts M16×50 : 265 N·m (195 lbf-ft)




- 8) Reassembly of gear box SUBASSY.

- Secure ring (4) to gear box (45) with ten bolts (2) and washers.



(2) Bolts M22×70 : 686 N·m (506 lbf-ft)




- 9) Install lifting bolts (M16) to gear box (45).


- Lift gear box.




(45) Gear box : 120 kg (265 lbs.)




10) Lower gear box (45) on mounting surface of housing (44).




11) Secure gear box (45) with eighteen bolts (3) and washers.

 (3) Bolts M16×50 : 265 N·m (195 lbf·ft)





**⚠ WARNING**  
When installing lifting bolts, secure them with nuts.

12) Install lifting bolts and nuts (M20) to holders (52) and (59).




13) Lower disc SUBASSY on mounting surface of gear box (45).

 Disc SUBASSY : 115 kg (254 lbs.)





**(NOTICE)**

- Disc SUBASSY and propulsion motor mounting holes must be arranged as shown on the right.




14) Secure disc SUBASSY with seventeen bolts (53) and washers.

 (53) Bolts M16×45 : 265 N·m (195 lbf·ft)






15) Install propulsion motor (55) to gear box (45).


 (55) Propulsion motor : 30 kg (66 lbs.)


**(NOTICE)**

- When installing, face the servo pressure gauge port on the propulsion motor in the same direction as the hole on the disc.



16) Secure propulsion motor (55) with two bolts (56) and washers.


 (56) Bolts M16×40 : 265 N·m (195 lbf-ft)



**⚠ WARNING**

Be careful because reversing the vibratory drum involves risk. Confirm that the surrounding area is safe, and work in a natural, unstrained posture.


17) Reverse drum SUBASSY.

 Drum SUBASSY

SV414D : 2,055 kg (4,530 lbs.)

SV414T : 2,045 kg (4,508 lbs.)


SV414TF : 3,325 kg (7,330 lbs.)




18) Secure shaft (9) to eccentric shaft (8) with six bolts (10) and spring washers.



(10) Bolts M10×40 : 59 N·m (44 lbf·ft)



19) Install a lifting bolt (M10) to eccentric shaft SUBASSY.



**WARNING**

Take care not to get your fingers caught in movable weights.

20) Apply a coat of gear oil to bearing mounting surface of eccentric shaft SUBASSY.


- Install eccentric shaft SUBASSY to drum SUBASSY.



Eccentric shaft SUBASSY : 135 kg (298 lbs.)


**(NOTICE)**

- Put the movable weight at its outmost position.



(NOTICE)

- Insert eccentric shaft SUBASSY into vibrator bearing (7) while taking care not to tilt the bearing inner race.




21) Reassembly of axle shaft SUBASSY


- 21-1) Apply a coat of gear oil to vibrator bearing (42) mounting surface of axle shaft (41).
- Drive vibrator bearing into axle shaft.

(NOTICE)


- Take care not to damage the bearing when installing it.



21-2) Reverse axle shaft SUBASSY.

  $k_9$  Axle shaft SUBASSY : 90 kg (198 lbs.)


- Apply a coat of gear oil to roller bearing (38) inner race mounting surface of axle shaft (41).
- Drive roller bearing inner race into axle shaft.



## VIBRATORY DRUM • REAR AXLE


21-3) Apply grease to O-rings for plugs (14).

- Install plugs to axle shaft (41).
- Apply sufficient amount of lithium-based grease to rollers of roller bearing (38) inner race.




21-4) Apply a coat of gear oil to roller bearings (38) outer race mounting surface of housing (37).


- Drive roller bearing outer races into housing.
- Apply liquid packing to periphery of oil seal (39).
- Drive oil seal into housing.
- Apply grease to lip of oil seal.




21-5) Install lifting bolts (M12) to housing SUBASSY.




21-6) Install housing SUBASSY to axle shaft SUBASSY.

 Housing SUBASSY : 40 kg (88 lbs.)




21-7) Apply a coat of gear oil to roller bearing (38) outer race mounting surface of axle shaft.

- Apply sufficient amount of lithium-based grease to rollers of roller bearing inner race.
- Drive in roller bearing inner race until rollers come in contact with outer race.



21-8) Preload adjustment of roller bearing

- ① Install a shim of about 1 mm (0.04 in.).
- Secure cover (32) to axle shaft (41) with four bolts (30) and washers.




## VIBRATORY DRUM • REAR AXLE

- ② A gap will remain between end of axle shaft (41) and inside of cover (32).
- Tighten four bolts (30) to a torque of 108 N·m (80 lbf·ft).
  - Give housing (37) two to three turns.
  - Tighten bolts to a torque of 108 N·m (80 lbf·ft) again.
  - Repeat this work several times until tightening torque of bolts no longer fluctuates.


### (NOTICE)

- Tighten the bolts alternately in diagonal directions.



### (NOTICE)


- Push in the inner race while rotating the bearing. Otherwise, even strongly trying to push the inner race, the bearing rollers will not be pushed up and therefore bearing will not be seated.




- ③ Remove bolts (30).
- Remove cover (32).
  - Remove shim.

### (NOTICE)

- Do not turn the housing (37) after the cover is removed.




- ④ Without inserting shim, install cover (32) to axle shaft (41) with four bolts (30) and washers.




- ⑤ Using a thickness gauge, measure clearance “A”.

★ Preload adjusting shim thickness =  $A + 0.1 \text{ mm (0.004 in.)}$



- ⑥ Remove bolts (30).  
• Remove cover (32).




## VIBRATORY DRUM • REAR AXLE

- ⑦ Install shim (36) of preload adjusting shim thickness = "A + 0.1 mm (0.004 in.)".
- Secure cover (32) to axle shaft (41) with eight bolts (30) and washers.




(30) Bolts M14×40 : 167 N·m (123 lbf-ft)



- 21-9) Apply liquid packing to periphery of oil seal (33).


- Drive oil seal into cover (27).
- Apply grease to lip of oil seal.



- 21-10) Secure cover (27) to housing (37) with six bolts (34) and washers.




(34) Bolts M12×40 : 108 N·m (80 lbf-ft)






(NOTICE)

- The hole (1) in housing and breather mounting hole in cover, holes (2), (3) in housing and two cover mounting holes must be arranged as shown on the right.




22) Install lifting bolts (M16) to axle shaft SUBASSY.



23) Lift axle shaft SUBASSY.

 Axle shaft SUBASSY : 150 kg (331 lbs.)

- Apply grease to O-ring (40).
- Install O-ring to axle shaft (41).




## VIBRATORY DRUM • REAR AXLE

24) Lower axle shaft SUBASSY on mounting surface of drum (1).

### (NOTICE)


- Support the eccentric shaft with a pipe or the like, to prevent tilting of the vibrator bearing inner race during installation.
- Take care not to let O-ring to protrude from its groove.




25) Secure axle shaft SUBASSY with sixteen bolts (13) and washers.




(13) Bolts M16×50 : 265 N·m (195 lbf·ft)




26) Install a lifting bolt (M10) on shaft end of eccentric shaft SUBASSY.



27) Slowly lift eccentric shaft SUBASSY with a crane and check that there is an axial play of 1 to 3 mm (0.04 to 0.12 in.).




28) Install lifting bolts and nuts (M20) to holders (21) and (35).



29) Lower disc SUBASSY on mounting surface of housing (37).

$\mathfrak{J}_{kg}$  Disc SUBASSY : 135 kg (298 lbs.)



## VIBRATORY DRUM • REAR AXLE


30) Secure disc SUBASSY with sixteen bolts (25) and washers.




(25) Bolts M20×50 : 539 N·m (398 lbf·ft)

### (NOTICE)

- When installing the disc SUBASSY, the breather mounting hole in cover (27) must be perpendicular to the longer edge of the disc (15).




31) Drive two spring pins (12) into sleeve (11).




32) Apply grease to splined portion of sleeve (11) .

- Fit sleeve to splined portion on eccentric shaft SUBASSY end.





33) Apply grease to O-ring (28).

- Install O-ring to vibrator motor (29).



34) Secure vibrator motor (29) to cover (27) with two bolts (31) and washers.


 (29) Vibrator motor : 15 kg (33 lbs.)

 (31) Bolts M14×40 : 167 N·m (123 lbf·ft)

- Wind seal tape around to threaded portion of breather (26).
- Install breather to cover (27).

**(NOTICE)**

- The vibrator motor which have ports A and B must face the same direction as the side of the breather (26).
- Take care not to let O-ring to protrude from its groove.



35) Lay vibratory drum ASSY with plugs (14-1), (14-2), and (14-3) positioned as shown on the right.


- Hold with chocks.

 Vibratory drum ASSY

SV414D : 2,500 kg (5,512 lbs.)

SV414T : 2,470 kg (5,445 lbs.)

SV414TF : 3,765 kg (8,300 lbs.)




## VIBRATORY DRUM • REAR AXLE

36) Remove plugs (14-1) and (14-3).

- Supply gear oil from oil supply port.
- Check that oil drips from gauge port.


- Quantity of gear oil : 21 L (5.5 gal.)

- Reinstall plugs (14-1) and (14-3).





# 4. REAR AXLE

## 4-1. Rear Axle ASSY



- (1) Tire
- (2) Hub reduction gear
- (3) Nut : M22 P=1.5
- (4) Bolt (brake release)
- (5) Plug (brake filler and level gauge)
- (6) Plug (brake drain)
- (7) Brake
- (8) Differential
- (9) Air valve
- (10) Plug (hub reduction gear filler, level gauge and drain)
- (11) Parking brake release port [RBR] : M14 P=1.5
- (12) Parking brake release port [RBL] : M14 P=1.5
- (13) Plug (differential filler and level gauge)
- (14) Plug (differential drain)
- (15) Bolt : M20×220
- (16) Nut : M20

-  (3) Nut M22 P=1.5 : 785 N·m (579 lbf·ft)
-  (16) Nut M20 : 540 N·m (398 lbf·ft)

### Specifications


Tire size	:	14.9 - 24 - 8PR
Tire inflation pressure	:	177 kPa ( 26 psi )
Tire ASSY weight	D type	: 110 kg ( 243 lbs. )
	T, TF type	: 112 kg ( 247 lbs. )
Rear axle ASSY weight	D type	: 575 kg ( 1,268 lbs. )
	T, TF type	: 580 kg ( 1,279 lbs. )

**SECTION A-A**





### 4-2. Rear Axle Lubrication




SV201-1-06094

- (1) Filler port
- (2) Level port
- (3) Drain gauge

- Change oil : Gear oil API-grade GL4 SAE90 (See recommended lubrication.)
- Change oil quantity
  - Center housing : 7.3 L ( 1.9 gal. )
  - Hub reduction gear : 1.3 L×2 ( 0.33 gal.×2 )

### 4-3. Rear Axle Structure

#### 4-3-1. Center housing




SV201-1K-06002

- (1) O-ring
- (2) Bolt
- (3) Seal washer
- (4) Vent

- (5) Housing
- (6) Plug
- (7) Plug
- (8) Snap ring

- (9) Magnet plug
- (10) Cover


4-3-2. Differential



SV400-2-06053

- (1) Bolt
- (2) Ring nut
- (3) Taper roller bearing
- (4) Bolt
- (5) Differential carrier
- (6) No spin differential
- (7) Bolt
- (8) Bevel gear set
- (9) Ring nut
- (10) Bearing
- (11) Spacer
- (12) Shim
- (13) Shim


4-3-3. Hub reduction gear



SV414-06089

- |                   |                        |                          |
|-------------------|------------------------|--------------------------|
| (1) Half shaft    | (10) Stud              | (19) Wheel nit           |
| (2) Spring washer | (11) Plug              | (20) Stud                |
| (3) Bolt          | (12) Magnet plug       | (21) Nut                 |
| (4) Seal          | (13) Nut               | (22) Circlip             |
| (5) Seal          | (14) Axle case         | (23) Planet gear         |
| (6) Bearing       | (15) Circlip           | (24) Bearing             |
| (7) Wheel stad    | (16) Ring gear         | (25) Friction washer     |
| (8) Wheel hub     | (17) Ring gear support | (26) Planet gear carrier |
| (9) O-ring        | (18) Locking plate     | (27) Countersunk bolt    |

4-3-4. Brake



SV201-1K-06003

- (1) Spring
- (2) O-ring
- (3) Piston
- (4) O-ring
- (5) Ring
- (6) Dowel
- (7) Brake disc
- (8) Plug
- (9) Seal washer
- (10) Lock washer
- (11) Nut
- (12) Bolt
- (13) Plug



---

---

**BRAKE**




---

---







# 1. BRAKE PEDAL



DETAIL A



SECTION B-B


0418-62813-0-12540-B

- (1) Brake pedal
- (2) Foot brake switch
- (3) Spring
- (4) Nut : M10

- (5) Stopper bolt : M10×50
- (6) Stopper bolt : M10×50
- (7) Nut : M10



## 2. BRAKE HYDRAULIC PIPING



• The letters and numbers in the figure such as “VBA” and “TVB” show each port.  
 • Arrow “←→; →” symbols show the hose connection and the direction of the flow of the oil.



## 3. BRAKE SYSTEM

### 3-1. Description and Operation of Brake Circuit

#### Description

- Made up of parking brake switch pedal (1), foot brake switch (2), diode unit (3), F-R lever switch (4), pump neutral relay (A3) (5), pump neutral holding relay (A4) (6), parking brake solenoid valve (7) and brake (8). The foot brake switch is ON with the brake pedal released and OFF if pushed down on.

#### Operation

##### To release parking brake:


- When parking brake switch (1) is set to the OFF position, the contacts of parking brake switch (1) close the circuit to parking brake solenoid valve (7) and breaks the circuit to the brake indicator lamp.
- This leads the pressurized fluid through parking brake solenoid valve (7) to pistons (a) of brake (8) to compress springs (b). Brake is freed.

##### To apply parking brake (Brake pedal not depressed):

- If parking brake switch (6) is put in the ON position, the contacts of parking brake switch (6) break the circuit to parking brake solenoid valve (7) and close the brake indicator lamp circuit.
- This stops feeding the fluid from parking brake solenoid valve (7) to brake (8). Springs (b) move pistons (a) toward the brake discs and plates so that they make a close contact with each other. The brake is applied. The indicator lamp comes on simultaneously.

##### When brake pedal is pushed down on:

- If brake pedal is depressed, foot brake switch (2) is switched off to break the circuit to parking brake switch (1). This applies the brake even if parking brake switch is in the OFF position.




• The arrow (→) symbol shows the direction of the hydraulic oil flow.

SV414-07001

## 4. HYDRAULIC COMPONENT SPECIFICATIONS

### 4-1. Parking Brake Solenoid Valve



- (1) Solenoid
- (2) O-ring (1B P14)
- (3) Spool (J)
- (4) Body
- (5) Spring
- (6) Port P
- (7) Port A
- (8) Port T

**[BSP]** : 9/16-18UNF-2B

**[BSA]** : 9/16-18UNF-2B


**[BST]** : 9/16-18UNF-2B

#### Specifications

- Rated flow : 30 L/min ( 7.9 gal./min )
- Rated pressure : 4.9 MPa ( 710 psi ) (6, 7)
- : 0.5 MPa ( 72.5 psi ) (8)
- Weight : 1.5 kg ( 3.3 lbs. )

J-40146

## 4-2. Servo Bypass Solenoid Valve



- (1) Solenoid
- (2) O-ring (1B P14)
- (3) Spool (K)
- (4) Body
- (5) Spring
- (6) Port T : 9/16-18UNF-2B
- (7) Port A **[SBA]** : 9/16-18UNF-2B
- (8) Port P **[SBP]** : 9/16-18UNF-2B

### Specifications

- Rated flow : 30 L/min ( 7.9 gal./min )
- Rated pressure : 4.9 MPa ( 710 psi ) (7, 8)
- : 0.5 MPa ( 72.5 psi ) (6)
- Weight : 1.5 kg ( 3.3 lbs. )

K-40146





---

---

# **INSPECTION AND ADJUSTMENT**

---

---



# 1. INSPECTION AND ADJUSTMENT

## 1-1. Safety Precautions for Inspection and Adjustment

### WARNING

Unexpected machine movement may cause a serious accident. When inspecting the machine while the engine is running, always follow the instructions below.

- Park the machine on level, flat ground.
- Apply the parking brake.
- Set chocks in front and behind each drum or tire.
- Make sure that service personnel are given the appropriate information at the appropriate time.
- Make sure that no one can enter any hazardous area.

### CAUTION

Do not work on the hydraulic system while the engine is running and the system is hot and under pressure. Do not disconnect hydraulic hoses or fittings until the system has cooled and pressure has been properly relieved.

Before removing any plugs from the pressure measurement ports, always release any residual pressure from the piping and open the cap of the fluid tank to release and pressure.

### WARNING

Inadvertent starting the engine may cause a serious accident.

When inspecting the engine, make sure to exchange the appropriate cues and hand signal with the person at the operator station to avoid any accidents.

### CAUTION

Before inspecting inside of the engine compartment, always stop the engine.

Contact with the fan, V-belt or exhaust system parts while the engine is running may cause serious injury.

## 1-2. Preparation for Inspection and Adjustment

- Prepare the necessary measuring instruments. In addition, particularly when measuring pressure values, make sure to prepare the appropriate hoses, adapters and a plug removal tool for the pressure reading port.
- Make sure that the instruments to be used operate normally.

When handling the instruments, exercise sufficient caution not to drop or apply any impact to them. Doing so may adversely affect the calibration. Another important point is to inspect the instruments regularly. An instrument that does not start from the appropriate zero point may give an inaccurate reading.

## 1-3. Precautions for Inspection and Adjustment

- When performing inspections and adjustments, pay special attention to safety.
- For each inspection, always take three measurements for each measurement point. If the measurements significantly differ, the measurement method may be incorrect. In such a case, take measurements once again and calculate their average.

## 1-4. Warm-up

- Machinery will not exhibit their true performance under the cold condition. Before taking measurements, always warm up the engine and make sure that the fluid and engine coolant are warmed to their specified normal operating temperatures.

## 1-5. Inspection and Adjustment of Engine Related Items

- Refer to shop manual of engine manufacturer for inspection and adjustment of engine itself.

## 2. MEASUREMENT AND ADJUSTMENT OF PROPULSION CIRCUIT PRESSURE

### 2-1. Measurement



#### **⚠ WARNING**

Confirm that the parking brake works properly before measurement.

- Oil temperature during measurement :  $50 \pm 5^{\circ}\text{C}$  ( $122 \pm 9^{\circ}\text{F}$ )
- ① Remove plugs from couplings (1) and (2) of propulsion pump. Attach pressure gauge with hose (S) and connector (U) .
  - Coupling : 9/16-18UNF×M16
  - Adapter for hose (S) : M16 P=2.0
  - Pressure gauge connector (U) : M16×G3/8
  - High pressure gauge port (Forward) : (2)
  - High pressure gauge port (Reverse) : (1)
  - Pressure gauge : 0 to 50 MPa  
(0 to 7,250 psi)
- ② Confirm that F-R lever is "N".
- ③ Set propulsion speed select switch to "🐢".
- ④ Start the engine and set throttle switch to "FULL".
- ⑤ Establish a condition in which machine propulsion load becomes maximum.  
(Pressure does not build up unless propulsion load is applied.)
- ⑥ With propulsion load at maximum, slowly move F-R lever to the side to be measured.
- ⑦ Read pressure indicated by pressure gauge.
- ⑧ After measuring, promptly return F-R lever to "N".

★ **Maximum circuit pressure**  
(high pressure relief valve setting)

:  $41.8 \pm 1.0 \text{ MPa}$  ( $6,061 \pm 145 \text{ psi}$ )






- The numbers "1-9" and "1-11" appearing in above illustrations are consistent with lead line numbers shown in illustration of pump ASSY in "2-2. Hydraulic Component Specifications" (page 4-006).

## 2-2. Adjustment

- If measurement results indicate the pressure deviating from maximum circuit pressure range, make an adjustment in accordance with procedure described below.

- ① Check nut (2) of multifunction valve (1-1) or (1-4) for evidence of having loosened.
  - Multifunction valve (Forward) : (1-1)
  - Multifunction valve (Reverse) : (1-4)
- ② If there is evidence of nut having loosened, adjust multifunction valve so that pressure becomes within maximum circuit pressure range while watching pressure gauge.
  - To adjust pressure, loosen nut and turn adjustment screw (3).
  - Adjustment screw turned clockwise : Pressure rise
  - Adjustment screw turned counterclockwise : Pressure drop
  - Pressure change rate : 9 MPa/turn (1,305 psi/turn)
- ③ If there is no evidence of nut having loosened, remove multifunction valve.
- ④ Check removed multifunction valve for trapped dirt and scratches on its seat.
- ⑤ If trapped dirt is present, disassemble and clean multifunction valve.
- ⑥ If a scratch is found on seat, replace multifunction valve.
- ⑦ After adjustment, measure pressure again and check that pressure reaches maximum circuit pressure range.

	(1)	Nut	: 41 N·m (30 lbf·ft)
	(2)	Nut	: 20 N·m (16 lbf·ft)
	(1-1)	Multifunction valve	: 89 N·m (66 lbf·ft)
	(1-4)	Multifunction valve	: 89 N·m (66 lbf·ft)





### (NOTICE)

- **Carefully disassemble and reassemble after taking steps to prevent foreign material from getting in.**
- The numbers “1-1” and “1-4” appearing in above illustrations are consistent with lead line numbers shown in illustration of pump ASSY in “2-2. Hydraulic Component Specifications” (page 4-006).

### 3. MEASUREMENT AND ADJUSTMENT OF PROPULSION CHARGE CIRCUIT PRESSURE

- Since oil in charge circuit is supplied from steering circuit, confirm that steering operation is normal before measurement.
- Propulsion charge circuits and vibration charge circuits consist of parallel circuits. Thus, in order to measure whether propulsion charge circuit pressure is within standard value, use following operation to ensure that oil does not escape to the charge relief valve on vibrator pump side.

- ① Loosen nut (1) from charge relief valve (2-12) on vibrator pump side.
- ② Tighten adjustment screw (2) by 1/2 complete turns.
  - Adjustment screw turned clockwise : Pressure rise
  - Adjustment screw turned counterclockwise : Pressure drop
  - Pressure change rate : 0.54 MPa/ 1/2 turn (78.3 psi/ 1/2 turn)





- The number "2-12" appearing in above illustrations is consistent with lead line numbers shown in illustration of pump ASSY in "2-2. Hydraulic Component Specifications" (page 4-006).

### 3-1. Measurement

- Oil temperature during measurement :  $50 \pm 5^{\circ}\text{C}$  ( $122 \pm 9^{\circ}\text{F}$ )
- ① Remove plug from coupling (1) of propulsion pump.  
Attach pressure gauge with hose (S) and connector (U) .
  - Coupling : 9/16-18UNF×M16
  - Adapter for hose (S) : M16 P=2.0
  - Pressure gauge connector (U) : M16×G3/8
  - Pressure gauge : 0 to 5 MPa  
(0 to 725 psi)
- ② Confirm that F-R lever is “N”.
- ③ Apply parking brake by pressing parking brake switch button.
- ④ Start the engine and set throttle switch to “FULL”.
- ⑤ Read pressure indicated by pressure gauge.

★ **Standard charge relief valve setting**

:  $2.5 \pm 0.2 \text{ MPa}$  ( $363 \pm 29 \text{ psi}$ )



- The number “1-2” appearing in above illustrations is consistent with lead line numbers shown in illustration of pump ASSY in “2-2. Hydraulic Component Specifications” (page 4-006).

### 3-2. Adjustment

- If measurement results indicate the pressure deviating from standard charge relief pressure setting range, make an adjustment in accordance with procedure described below.

- ① Check nut (3) of charge relief valve (1-10) for evidence of having loosened.
- ② If there is evidence of nut having loosened, adjust charge relief valve so that pressure becomes within standard charge relief valve pressure setting range while watching pressure gauge.
- To adjust pressure, loosen nut and turn adjustment screw (4).

Adjustment screw turned clockwise

: Pressure rise

Adjustment screw turned counterclockwise

: Pressure drop

Pressure change rate : 0.39 MPa/turn (57 psi/turn)



- ③ If there is no evidence of nut having loosened, remove charge relief valve.
- ④ Check removed charge relief valve for trapped dirt and scratches on its seat.
- ⑤ If trapped dirt is present, disassemble and clean charge relief valve.
- ⑥ If a scratch is found on seat, replace charge relief valve.
- ⑦ After adjustment, measure pressure again and check that pressure reaches standard charge relief valve setting range.



(3) Nut : 52 N·m (38 lbf·ft)

**(NOTICE)**

- **Carefully disassemble and reassemble after taking steps to prevent foreign material from getting in.**




- The number “1-10” appearing in above illustrations is consistent with lead line numbers shown in illustration of pump ASSY in “2-2. Hydraulic Component Specifications” (page 4-006).



## 4. MEASUREMENT OF PROPULSION SERVO CIRCUIT PRESSURE


### 4-1. Measurement

- Oil temperature during measurement :  $50 \pm 5^{\circ}\text{C}$  ( $122 \pm 9^{\circ}\text{F}$ )
- ① Disconnect the hoses (1) and (2) from servo bypass solenoid valve. Attach pressure gauge through adapter (m).
  - Adapter (m) : G1/4
  - Pressure gauge : 0 to 5 MPa (0 to 725 psi)
- ② Confirm that F-R lever is "N".
- ③ Apply parking brake by pressing parking brake switch button.
- ④ Start the engine and set throttle switch to "FULL".
- ⑤ Operate F-R lever and then read pressure indicated by pressure gauge.
  - With parking brake (ON), measured pressures of (1) and (2) are the same.
  - With parking brake (OFF), measured pressures of (1) and (2) are different.



#### ★ Standard charge relief pressure setting



:  $2.5 \pm 0.2 \text{ MPa}$  ( $363 \pm 29 \text{ psi}$ )



## 5. MEASUREMENT OF MACHINE HIGH/LOW SPEED CHANGE CIRCUIT PRESSURE


- Since oil in speed change circuit is supplied from steering circuit, confirm that steering operation is normal before measurement.

### 5-1. Measurement of Propulsion Motor (F)


- Oil temperature during measurement :  $50 \pm 5^{\circ}\text{C}$  ( $122 \pm 9^{\circ}\text{F}$ )
- ① Remove plugs from propulsion motor (F) gauge ports (1) and (2). Attach pressure gauge with the adapter (h) .
  - Adapter (h) : 9/16-18UNF
  - Servo pressure gauge port (High) : (1)
  - Servo pressure gauge port (Low) : (7)
  - Pressure gauge : 0 to 5 MPa (0 to 725 psi)
- ② Confirm that F-R lever is "N".
- ③ Apply parking brake by pressing parking brake switch button.
- ④ Set speed select switch to "1" , "2" or "3" .
- ⑤ Start the engine and set throttle switch to "FULL".
- ⑥ Read pressure indicated by pressure gauge.

#### ★ Standard charge relief valve setting

:  $1.6 \pm 0.2$  MPa ( $232 \pm 29$  psi)





SV414-08005




PG001014

- The numbers "1" and "7" appearing in above illustrations are consistent with lead line numbers shown in illustration of propulsion motor (F) in "2-2-2. Propulsion hydraulic motor (F)" (page 4-008).


## 5-2. Measurement of Propulsion Motor (R)

- Oil temperature during measurement :  $50 \pm 5^{\circ}\text{C}$  ( $122 \pm 9^{\circ}\text{F}$ )
- ① Remove plugs from propulsion motor (R) gauge ports (1) and (2). Attach pressure gauge with the adapter (h) .
  - Adapter (h) : 9/16-18UNF
  - Servo pressure gauge port (Low) : (4)
  - Servo pressure gauge port (High) : (6)
  - Pressure gauge : 0 to 5 MPa (0 to 725 psi)
- ② Confirm that F-R lever is "N".
- ③ Apply parking brake by pressing parking brake switch button.
- ④ Set speed select switch to "1 , "2" or "3 .
- ⑤ Start the engine and set throttle switch to "FULL".
- ⑥ Read pressure indicated by pressure gauge.



### ★ Standard charge relief valve setting

:  $2.67 \pm 0.2 \text{ MPa}$  ( $387 \pm 29 \text{ psi}$ )



- The numbers "4" and "6" appearing in above illustrations are consistent with lead line numbers shown in illustration of propulsion motor (R) in "2-2-4. Propulsion hydraulic motor (R)" (page 4-011).

## 6. MEASUREMENT OF PARKING BRAKE RELEASE PRESSURE

- Since oil in charge circuit is supplied from steering circuit, confirm that steering operation is normal before measurement.

### 6-1. Measurement



- Oil temperature during measurement :  $50 \pm 5^{\circ}\text{C}$  ( $122 \pm 9^{\circ}\text{F}$ )

① Disconnect hose (1) from parking brake solenoid valve.

Attach pressure gauge through adapter (m).

- Adapter (m) : G1/4
  - Pressure gauge : 0 to 5 MPa (0 to 725 psi)
- ② Confirm that F-R lever is "N".
- ③ Apply parking brake by pressing parking brake switch button.
- ④ Start the engine and set throttle switch to "FULL".
- ⑤ Release parking brake by pressing parking brake switch button.
- ⑤ Read brake release pressure indicated by pressure gauge.

★ Brake release pressure : 1.5 to 3.0 MPa (218 to 435 psi)




## 7. MEASUREMENT AND INSPECTION OF VIBRATOR CIRCUIT PRESSURE

### 7-1. Measurement

#### **CAUTION**



Take care not to operate the vibratory drum for a longer period of time than necessary with the machine stationary. Otherwise, the vibrator bearing could be seized.

- Oil temperature during measurement :  $50 \pm 5^{\circ}\text{C}$  ( $122 \pm 9^{\circ}\text{F}$ )
- ① Remove plugs from couplings (1) and (2) of vibrator pump. Attach pressure gauge with hose (S) and connector (U).
  - Coupling : 9/16-18UNF×M16
  - Adapter for hose (S) : M16 P=2.0
  - Pressure gauge connector (U) : M16×G3/8
  - High pressure gauge port : (1)  
(Low amplitude)
  - High pressure gauge port : (2)  
(High amplitude)
  - Pressure gauge : 0 to 50 MPa  
(0 to 7,250 psi)
- ② Confirm that F-R lever is “N”.
- ③ Apply parking brake by pressing parking brake switch button.
- ④ Set vibration mode change switch to “”.
- ⑤ Start the engine and set throttle switch to “FULL”.
- ⑥ Press F-R lever vibration switch ON.
- ⑦ Read pressure gauge for maximum value of vibrator circuit pressure.
- ⑧ Turn F-R lever vibration switch OFF as soon as measurement is finished.

#### ★ Maximum circuit pressure

(high pressure relief valve setting)

:  $25.0 \pm 1.0$  MPa ( $3,625 \pm 145$  psi)



## 7-2. Inspection

- If measurement results indicate the pressure deviating from maximum circuit pressure range, make an inspection in accordance with procedure described below.



- ① Remove plug (3) and valve from high pressure relief valve port (2-1) or (2-5) of vibrator pump.
  - High pressure relief valve port : (2-5)  
(Low amplitude)
  - High pressure relief valve port : (2-1)  
(High amplitude)
- ② Check removed high pressure relief valve for trapped dirt and other abnormalities.
- ③ If trapped dirt is present, disassemble and clean high pressure relief valve.
- ④ If pressure still deviates from maximum circuit pressure range after valve is disassembled and cleaned, replace high pressure relief valve.
- ⑤ After inspection, measure pressure again and check that pressure reaches maximum circuit pressure range.



(3) Plug : 40 N·m (30 lbf-ft)

**(NOTICE)**

- **Carefully disassemble and reassemble after taking steps to prevent foreign material from getting in.**





- The numbers “2-1” and “2-5” appearing in above illustrations are consistent with lead line numbers shown in illustration of pump ASSY in “2-2. Hydraulic Component Specifications” (page 4-006).

## 8. MEASUREMENT AND ADJUSTMENT OF VIBRATOR CHARGE CIRCUIT PRESSURE

- Since oil in charge circuit is supplied from steering circuit, confirm that steering operation is normal before measurement.
- Propulsion charge circuits and vibration charge circuits consist of parallel circuits. Thus, in order to measure whether vibrator charge circuit pressure is within standard value, use following operation to ensure that oil does not escape to the charge relief valve on propulsion pump side.

- ① Loosen nut (3) from charge relief valve (1-10) on propulsion pump side.
- ② Tighten adjustment screw (4) by two complete turns.
  - Adjustment screw turned clockwise : Pressure rise
  - Adjustment screw turned counterclockwise : Pressure drop
  - Pressure change rate : 0.39 MPa/turn (57 psi/turn)





- The number “1-10” appearing in above illustrations is consistent with lead line numbers shown in illustration of pump ASSY in “2-2. Hydraulic Component Specifications” (page 4-006).

## 8-1. Measurement

- Oil temperature during measurement :  $50 \pm 5^{\circ}\text{C}$  ( $122 \pm 9^{\circ}\text{F}$ )
- ① Remove plug from coupling (1) of propulsion pump.  
Attach pressure gauge with hose (S) and connector (U) .
  - Coupling : 9/16-18UNF×M16
  - Adapter for hose (S) : M16 P=2.0
  - Pressure gauge connector (U) : M16×G3/8
  - Pressure gauge : 0 to 5 MPa (0 to 725 psi)
- ② Confirm that F-R lever is “N”.
- ③ Apply parking brake by pressing parking brake switch button.
- ④ Start the engine and set throttle switch to “FULL”.
- ⑤ Read pressure indicated by pressure gauge.

### ★ Standard charge relief valve setting

:  $2.5 \pm 0.2 \text{ MPa}$  ( $363 \pm 29 \text{ psi}$ )



- The number “1-2” appearing in above illustrations is consistent with lead line numbers shown in illustration of pump ASSY in “2-2. Hydraulic Component Specifications” (page 4-006).



## 8-2. Adjustment

- If measurement results indicate the pressure deviating from standard charge relief pressure setting range, make an adjustment in accordance with procedure described below.

- ① Check nut (1) of charge relief valve (2-12) for evidence of having loosened.
- ② If there is evidence of nut having loosened, adjust charge relief valve so that pressure becomes within standard charge relief valve pressure setting range while watching pressure gauge.
- To adjust pressure, loosen nut and turn adjustment screw (2).

Adjustment screw turned clockwise

: Pressure rise

Adjustment screw turned counterclockwise

: Pressure drop

Pressure change rate

: 0.54 MPa/ 1/2 turn (78.3 psi/ 1/2 turn)



- ③ If there is no evidence of nut having loosened, remove charge relief valve.
- ④ Check removed charge relief valve for trapped dirt and scratches on its seat.
- ⑤ If trapped dirt is present, disassemble and clean charge relief valve.
- ⑥ If a scratch is found on seat, replace charge relief valve.
- ⑦ After adjustment, measure pressure again and check that pressure reaches standard charge relief valve setting range.



(1) Nut : 40 N•m (30 lbf•ft)

### (NOTICE)

- **Carefully disassemble and reassemble after taking steps to prevent foreign material from getting in.**



- The number “2-12” appearing in above illustrations is consistent with lead line numbers shown in illustration of pump ASSY in “2-2. Hydraulic Component Specifications” (page 4-006).



## 9. MEASUREMENT OF VIBRATOR HIGH/LOW CHANGE CIRCUIT PRESSURE

### 9-1. Measurement

- Oil temperature during measurement :  $50 \pm 5^{\circ}\text{C}$  ( $122 \pm 9^{\circ}\text{F}$ )
- ① Remove plugs from servo pressure gauge ports (2-3) and (2-10). Attach pressure gauge with the adapter (h) .
  - Adapter (h) : 9/16-18UNF
  - Servo pressure gauge port (Low) : (2-10)
  - Servo pressure gauge port (High) : (2-3)
  - Pressure gauge : 0 to 5 MPa (0 to 725 psi)
- ② Confirm that F-R lever is "N".
- ③ Apply parking brake by pressing parking brake switch button.
- ④ Start the engine and set throttle switch to "FULL".
- ⑤ Set vibration select switch and then read pressure indicated by pressure gauge.
  - With vibration select switch is "○", measured pressures of (2-3) and (2-10) are same.
  - With vibration select switch is "∩" or "∪", measured pressures of (2-3) and (2-10) are different.

#### ★ Standard charge relief valve setting

:  $2.5 \pm 0.2$  MPa ( $363 \pm 29$  psi)



- The numbers "2-3" and "2-10" appearing in above illustrations are consistent with lead line numbers shown in illustration of pump ASSY in "2-2. Hydraulic Component Specifications" (page 4-006).

# 10. MEASUREMENT AND INSPECTION OF STEERING

## CIRCUIT PRESSURE



### 10-1. Measurement

#### **⚠ WARNING**

Make sure that there is no person around the articulated portion of the machine before operating the steering wheel.

- Oil temperature during measurement :  $50 \pm 5^{\circ}\text{C}$  ( $122 \pm 9^{\circ}\text{F}$ )
- ① Disconnect the hose (1) or (2) from steering cylinder.  
Attach pressure gauge through adapter (n) .
  - Adapter (n) : G3/8
  - Pressure gauge : 0 to 25 MPa (0 to 3,625 psi)
- ② Confirm that F-R lever is "N".
- ③ Apply parking brake by pressing parking brake switch button.
- ④ Start the engine and set throttle switch to "FULL".
- ⑤ Turn steering wheel to operate relief valve.
- ⑥ Read pressure indicated by pressure gauge.

★ **Standard maximum circuit pressure**  
(orbitroll relief pressure + charge relief pressure)  
:  $17.5 \pm 1.0 \text{ MPa}$  ( $2,538 \pm 145 \text{ psi}$ )




### 10-2. Inspection

- If measurement results indicate the pressure deviating from standard maximum circuit pressure range, make an inspection in accordance with procedure described below.
  - ① Remove relief valve (2) from orbitrol.
  - ② Check removed relief valve for trapped dirt, scratches on its seat and other abnormalities.
  - ③ If trapped dirt is present, disassemble and clean relief valve.
  - ④ If a scratch or any other abnormality is found on seat, replace relief valve.
  - ⑤ After inspection, measure pressure again and check that pressure reaches standard maximum circuit pressure range.

#### (NOTICE)

- **Carefully disassemble and reassemble after taking steps to prevent foreign material from getting in.**





# 11. MEASUREMENT OF PROPULSION PUMP CASE PRESSURE

## 11-1. Measurement

- Oil temperature during measurement :  $50 \pm 5^{\circ}\text{C}$  ( $122 \pm 9^{\circ}\text{F}$ )
- ① Disconnect hose (1) from propulsion pump. Attach pressure gauge through adapter (k) .
  - Adapter (k) : 12-4LOHL6G5TF  
(Parker part number)
  - Pressure gauge : 0 to 5 MPa (0 to 725 psi)
- ② Confirm that F-R lever is "N".
- ③ Apply parking brake by pressing parking brake switch button.
- ④ Set propulsion speed select switch to "1 🐢".
- ⑤ Start the engine and set throttle switch to "FULL".
- ⑥ Establish a condition in which machine propulsion load becomes maximum.  
(Pressure does not build up unless propulsion load is applied.)
- ⑦ With propulsion load at maximum, measure pressure when speed select switch is "1 🐢", "2" and "3 🐘" and F-R lever is "N", "F", and "R", respectively.

★ Allowable pump case pressure

: 0.3 MPa (43.5 psi) or less



## 12. MEASUREMENT OF PROPULSION MOTOR CASE PRESSURE

### 12-1. Measurement of Propulsion Motor (F)


- Oil temperature during measurement :  $50 \pm 5^{\circ}\text{C}$  ( $122 \pm 9^{\circ}\text{F}$ )

① Remove plug from drain port (1). Attach pressure gauge and adapter ① .

- Adapter ① : 7/8-14UNF
- Pressure gauge : 0 to 5 MPa (0 to 725 psi)

② Confirm that F-R lever is “N”.




③ Apply parking brake by pressing parking brake switch button.

④ Set propulsion speed select switch to “1 ”.

⑤ Start the engine and set throttle switch to “FULL”.


⑥ Establish a condition in which machine propulsion load becomes maximum.

(Pressure does not build up unless propulsion load is applied.)


⑦ With propulsion load at maximum, measure pressure when speed select switch is “1 ”, “2” and “3 ” and travel mode change switch is “” and F-R lever is “N”, “F”, and “R”, respectively.

#### ★ Allowable motor case pressure

: 0.3 MPa (43.5 psi) or less



SV414-08011



PG001022

## 12-2. Measurement of Propulsion Motor (R)


- Oil temperature during measurement :  $50 \pm 5^{\circ}\text{C}$  ( $122 \pm 9^{\circ}\text{F}$ )

① Remove plug from drain port (1). Attach pressure gauge and adapter (Z).

- Adapter (Z) : 1 1/16-12UN
- Pressure gauge : 0 to 5 MPa (0 to 725 psi)

② Confirm that F-R lever is "N".




③ Apply parking brake by pressing parking brake switch button.

④ Set propulsion speed select switch to "1" .

⑤ Start the engine and set throttle switch to "FULL".



⑥ Establish a condition in which machine propulsion load becomes maximum.

(Pressure does not build up unless propulsion load is applied.)

⑦ With propulsion load at maximum, measure pressure when speed select switch is "1" , "2" and "3"  and travel mode change switch is "

### ★ Allowable motor case pressure

: 0.3 MPa (43.5 psi) or less






# 13. MEASUREMENT OF VIBRATOR MOTOR CASE PRESSURE

## 13-1. Measurement


### ⚠ CAUTION

Take care not to operate the vibratory drum for a longer period of time than necessary with the machine stationary. Otherwise, the vibrator bearing could be seized.


- Oil temperature during measurement :  $50 \pm 5^{\circ}\text{C}$  ( $122 \pm 9^{\circ}\text{F}$ )
- ① Remove plug from drain port (1). Attach pressure gauge with adapter ① .
  - Adapter ① : 7/8-14UNF
  - Pressure gauge : 0 to 5 MPa (0 to 725 psi)
- ② Apply parking brake by pressing parking brake switch button.
- ③ Set vibration mode change switch to “”.
- ④ Start the engine and set throttle switch to “FULL”.
- ⑤ Press F-R lever vibration switch ON.
- ⑥ Measure pressure when vibration select switch is “” and “”, respectively.
- ⑦ Turn F-R lever vibration switch OFF as soon as measurement is finished.

#### ★ Allowable motor case pressure

: 0.17 MPa (24.7 psi) or less



SV412-08013



PG001022




# 14. ADJUSTMENT OF F-R LEVER LINKAGE

## 14-1. Adjustment

- In cases such as propulsion hydraulic pump is replaced, control cable is replaced or F-R lever does not move smoothly, make an adjustment in accordance with procedure described below.
- “N”, maximum “F”, and maximum “R” positions of F-R lever (1) are positioned by notches.


- ① Set F-R lever in “N”.
- ② Attach both ends of control cable (2).

★ Specified dimension a : 210 mm (8.27 in.)



- ③ Confirm the strokes of propulsion pump control lever (3).


★ Specified dimension b : 212 mm (8.35 in.)  
c : 25 mm (0.98 in.)




## 15. BRAKE ADJUSTMENT

### 15-1. Manually Releasing the Brake

- 1) Loosen nut (24) of bolt (25).
  - Loosen nut on the opposite side.




- 2) Tighten bolt (25), and press it into disc (16).
  - Do the same with bolt on the opposite side.




- 3) Alternately tighten bolts (25) 1/4 turn each, and release brake disc.

★ After bolt end makes contact with disc (16), strictly observe not tightening bolt (25) more than one complete turn.




## 15-2. Adjustment after Manual Release of Brake

- ① Remove bolt (25), nut (24), and seal washer (26).
- ② Replace seal washer (26) with a new one.
- ③ Apply grease to bolt (25) threads.
- ④ As shown on the right, install bolt (25), nut (24), and seal washer (26).




- ⑤ Adjust bolt (25) to the dimensions as shown on the right.
  - Similarly, adjust the bolt on the opposite side.

★ Specified dimension a:  $34^{+0.5}_0$  mm ( $1.34^{+0.02}_0$  in.)



- ⑥ Tighten nut (24), and firmly secure bolt (25).

★ When tightening nut (24), make sure that bolt (25) does not move. After securing bolt, check the dimensions of bolt again.





---

---

# **TROUBLESHOOTING**

---

---



# 1. TROUBLESHOOTING

## 1-1. Safety Precautions for Troubleshooting

### WARNING

Unexpected machine movement may cause a serious accident. When inspecting the machine while the engine is running, always follow the instructions below.

- Park the machine on level, flat ground.
- Apply the parking brake.
- Set chocks in front and behind each drum or tire.
- Make sure that service personnel are given the appropriate information at the appropriate time.
- Make sure that no one can enter any hazardous area.

### CAUTION

Do not work on the hydraulic system while the engine is running and the system is hot and under pressure. Do not disconnect hydraulic hoses or fittings until the system has cooled and pressure has been properly relieved.

Before removing any plugs from the pressure measurement ports, always release any residual pressure from the piping and open the cap of the fluid tank to release and pressure.

### WARNING

Inadvertent starting the engine may cause a serious accident.

When inspecting the engine, make sure to exchange the appropriate cues and hand signal with the person at the operator station to avoid any accidents.

### CAUTION

Before inspecting inside of the engine compartment, always stop the engine.

Contact with the fan, V-belt or exhaust system parts while the engine is running may cause serious injury.

## 1-2. Important Information for Troubleshooting

Before conducting troubleshooting, it is important to carefully read the operation manual and workshop manual and understand the electric circuits for each component as well as the structure and function of each system. Sufficient knowledge of the systems will enable you to identify a possible cause much faster. A fault or problem may seem to be related to many different factors. To identify the true cause, some experience is needed. To perform the appropriate troubleshooting, it is important to learn not only the normal operations of the systems but also the possible symptoms that may occur when an abnormal condition is present.

This chapter explains the possible causes and remedies for likely incidents taken from past experience.

### 1-3. Before Starting

The information in this section is provided to assist the troubleshooter in understanding the systems and quickly determine the causes when operating abnormalities occur.

The following steps are recommended:

1. If not familiar with the machine, study the Operator's Manual and this Shop Manual.
2. Check with the operator for full details of the trouble, ask questions.
3. Verify the trouble by warming up the machine and operating it. Check the problem yourself.
4. Identify the problem with either a mechanical, hydraulic or electrical system source.
5. Isolate the problem to a particular component or circuit.
6. Eliminate the simplest or easiest to check possibilities first to prevent unnecessary disassembly of components.
7. Following repair or replacement of any parts, perform operational tests to verify that the problem has been eliminated and the performance of all the systems is normal.



## 2. ELECTRICAL SYSTEM TROUBLESHOOTING

### 2-1. When Performing Electrical System Fault Diagnosis

#### **⚠ WARNING**


Be very careful because equipment can return to normal during an inspection and suddenly operate properly when a failure occurs due to a faulty contact or other such cause.

#### 2-1-1. Precautions to take during electrical circuit fault diagnosis

- When disconnecting or connecting a connector, be sure to turn the power supply OFF. (Electronic control parts such as the engine control unit, in particular, could be damaged internally.)
- Since connectors are not numbered, be sure to affix alignment marks so that you can restore them to their original condition.
- Before making a diagnosis, check related connectors for faulty connections. (Check by disconnecting and reconnecting related connectors several times.)
- Before proceeding to the next step, be sure to return the disconnected connectors to their original condition.
- When diagnosing a circuit (measuring the voltage, resistance, continuity and current), move related wiring and connectors several times, and check whether the tester's numerical values change. (If values change, faulty contact in the circuit is possible.)
- Do not ground the circuit of the control unit or apply voltage to it unless otherwise specified.
- For information of wire number, wire size, and wire color used in the sample circuit diagrams, refer to "1-1. Wire Numbers, Wire Sizes, Wire Colors and Connectors Shown in Electrical Circuit Diagram, Wiring Harness Layout and Wiring Harnesses" (P.5-001).

## 2-1-2. Inspection procedures using a tester


Some of the various inspection procedures are presented here for reference, using a sample circuit below.



TS-10001

### 1) Measuring resistance using tester

1-1) Measuring resistance of equipment A (measuring resistance between terminals 1 and 3)




TS-10002

#### Inspection procedure

- ① Disconnect the connector of equipment A.
- ② Connect the test probe (+) to connector terminal 1 of equipment A and the test probe (-) to connector terminal 3 of equipment A and measure the resistance. At this time, reversing the connector terminals between the probes (+) and (-) does not make any difference in the measurement.

- 1-2) Measuring resistance of harness (measuring resistance between terminal 1 of equipment A and terminal 2 of equipment B)



TS-10003

#### Inspection procedure


- ① Disconnect the connectors of equipment A and equipment B.
- ② Connect the test probe (+) to connector terminal 1 of equipment A and the test probe (-) to connector terminal 2 of equipment B and measure the resistance. At this time, reversing the connector terminals between the probes (+) and (-) does not make any difference in the measurement.

#### Criteria for harness defects

When there is no abnormality in the harness: Less than 10  $\Omega$  (measured value)

If there is any abnormality in the harness such as broken wire: 10  $\Omega$  or higher (measured value)

- 1-3) Measuring resistance of grounding wire (measuring resistance between terminal 5 of equipment B and ground)



TS-10004

#### Inspection procedure

- ① Disconnect the connector of equipment B.
- ② Connect the test probe (+) to connector terminal 5 of equipment B and the test probe (-) to a machine ground point (the bolt fastening the ground terminal or an unpainted portion on the body) and measure the resistance. At this time, reversing the connector terminals between the probes (+) and (-) does not make any difference in the measurement.


#### (NOTICE)

- When measuring the resistance, connect the test probes to both ends of the portion to be measured. Make also sure that no voltage is applied to the portion to be measured.
- When measuring the internal resistance of equipment, be sure first to disconnect all harnesses from the equipment.
- When measuring the resistance of a harness, disconnect the equipment connected to both ends of the harness.

## TROUBLESHOOTING

### 2) Measuring voltage and current flowing using tester

#### 2-1) Measuring voltage of equipment A (measuring voltage between terminals 1 and 3)




TS-10005


#### Inspection procedure

- ① Connect the connectors of equipment A and that of equipment B.
- ② Connect the test probe (+) to connector terminal 3 of equipment A and the test probe (-) to connector terminal 1 of equipment A and measure the voltage. Note that reversing the connector terminals between the probes (+) and (-) changes the result of the measurement. Be sure to connect the probe (+) to the power source side and the probe (-) to the ground side.


- Measurement using a test harness



- Measurement from the backside of connector



- Measurement on a lead cable



TS-10006

#### Measurement method


For measurement of voltage, connect the tester probes in parallel to the portion to be measured. Because the voltage can be measured only when the connector is connected in position, contact the tester probes to the terminals without disconnecting the connector. The following methods are available:

- Measurement using a test harness
  - Prepare the test harness for the measurement.
- Measurement from the backside of connector
  - Insert a wire from the backside of the connector.
- Measurement on a lead cable
  - Remove the bundling tape from the harness to separate each cable, and stick the needle into the relevant cable.

#### (NOTICE)

- Except for preparing the test harness, proper protection must be made after the measurement to prevent corrosion in the connector terminals or harnesses.

2-2) Measuring current flowing from equipment B to equipment A  
(measuring current between terminal 2 of equipment B and terminal 1 of equipment A)



TS-10007

**Inspection procedure**

- ① Disconnect the connector of equipment A and connect the test harness.
- ② Connect the test probe (+) to connector terminal 1 (harness side) of equipment A and the test probe (-) to connector terminal 1 (equipment side) of equipment A and measure the current. Note that reversing the connector terminals between the probes (+) and (-) changes the result of the measurement. Be sure to connect the probe (+) to the power source side and the probe (-) to the ground side.

**Measurement method**

When measuring the current, connect the tester in series to the portion to be measured. Because the current cannot be measured when the connector is connected in position, disconnect the connector to allow the test probe to connect between the terminals.

## 2-1-3. Inspection of electrical system

Operate the applicable switches and turn the relays ON and OFF. Ultimately, if the solenoid valve operates (makes a sound) and the pump runs, the electrical system is OK.

If there is a failure (fault), narrow the range of the inspection to the six broad steps described below.

### 1) Ground inspection

- Check for disconnected or loose ground. If rust or corrosion is present (which can cause faulty contact), remove the rust.

### 2) Fuse inspection

2-1) Check for blown fuses, disconnections and corrosion. (A fatigue open circuit cannot be identified visually. Use a tester for checking.)

#### 2-2) If a fuse is blown

Check whether a pump or valve (that is supposed to be protected by a blown fuse) burned, and whether there is a burning odor.

Especially if the pump and valve are not burned, check the harness for signs of burning. If it is burned, replace it.

If a fuse is blown and a relay along the pathway has failed, replace it. And if there is a timer, replace the timer, too. If a switch visually appears to be unsatisfactory (burned, melted, etc.) even though it operates, replace it.

- Simply replacing a fuse may not eliminate the true cause of a problem, and over current may flow again. Also, if over current secondarily causes an electrical path to fail (such as a wiring meltdown inside a solenoid valve), current will not flow. Thus, a fuse may not be blown out, but it also will not operate. If you do not know the location of burning or of an odor, investigate as described follows.

#### 2-3) How to find cause of failure when fuse blown is reproduced

- ① Turn the starter switch OFF, and remove the connector from the load (valve, pump).
- ② Referring to the circuit diagram, remove electrical parts that are connected to the circuit, such as relays, timers and diodes.
- ③ Turn the starter switch ON, and see whether the conditions can be reproduced (fuse is blown).
- ④ If a fuse is blown, a part such as a relay may have caused a short between the previous harness and ground (vehicle body). (Replace the harness.) If the conditions are not reproduced, check for signs of burning (odor) on the removed electrical parts.
- ⑤ If there is no problem, turn the starter switch OFF and reattach the parts.
- ⑥ Turn the starter switch ON and try again.
- ⑦ If a fuse is blown with this action, the problem was caused by a short between the harness and ground (vehicle body) that followed the attached electrical part. (Replace the harness.)
- ⑧ If the conditions are not reproduced, turn the starter switch OFF, and connect the loads (valve and pump) one at a time. Turn the starter switch ON and try again to see whether the fuse blown is reproduced.
- ⑨ If the fuse blown is reproduced, whatever was added at that time (including a harness added electrically) will be the cause of the failure.
  - Even if the fuse is not blown and the valve or pump is not burned, the valve or pump may be damaged electrically and may not operate. There may simply be a disconnection in the interior or an abnormal heat-up.
  - Even if the fuse is not blown, abnormal heat-up (hot enough to cause burns if touched) may occur if a relay, timer, diode or other semiconductor fails.

### 3) Connector inspection

- Is a connector disconnected or loose?
- Check that pins are not snapped or corroded.
- If faulty contact is suspected

Turn the starter switch OFF. Then disconnect and check the connectors (including relay and switch sockets).

If the terminal has no luster, faulty contact due to oxidation can be suspected. Therefore, polish the terminal by inserting and removing the connector (relay, switch) repeatedly at least five times. (Luster will return.)

### 4) Relay inspection (Check ON/OFF operation by sound.)

- Conduct without running the engine. (If you run the engine, you cannot hear the sound of operation.)

Sound heard : A relay failure occurred.

No sound heard : Using a tester, check the harness.

Sound heard : A relay failure occurred.

Still no sound : Using a tester, check the harness.

Continuity : Turn the starter switch OFF temporarily, disconnect the relay and check for continuity between the harness-side grounding terminal (color: black) and vehicle body ground. (If there is none, replace the harness.)

Voltage : With the relay disconnected, turn the starter switch ON and turn the operating switch ON. 24 V (or 12 V) (between vehicle body ground) should not reach the relay coil input terminal. Confirm this. Identify the location (section) to which 24 V (or 12 V) reaches. Then replace the harness or take other action.

### 5) Solenoid valve inspection (Check ON/OFF operation by sound.)

- Conduct without running the engine. (If you run the engine, you cannot hear the sound of operation.)

Sound heard : The electrical system is normal.

No sound heard : Check with a tester.

Continuity : ① Turn the starter switch OFF temporarily, disconnect the connector and check for continuity between the harness-side grounding terminal (color: black) and vehicle body ground. (If there is none, replace the harness.)

: ② Is the solenoid valve coil burnt?

(Turn the starter switch OFF, disconnect the connector and check the resistance between the solenoid valve terminals.)

Voltage : With the connector disconnected, turn the starter switch ON and check whether 24 V (or 12 V) exists between the harness-side connector and vehicle body ground.

If YES : Replace the valve.

If NO : Investigate and identify the location (section) to which 24 V (or 12 V) reaches. Then replace the harness or take other action.

### 6) Harness check

- If an incomplete disconnection inside the harness is suspected, wiggle (move) the harness during the relay inspection and solenoid valve inspection to see whether the relay (valve) operates incorrectly.
- Check for burned areas of the harness.
- Turn the starter switch OFF, disconnect the connector and check the continuity, referring to the circuit diagram and wiring coloring.



## 2-2. Fault Codes

### 2-2-1. Fault code list

Fault Code	SPN	FMI	Cummins Description	Effect
111	629	12	Engine Control Module Critical Internal Failure • Bad Intelligent Device or Component	Engine may not start or may be difficult to start.
115	612	2	Engine Magnetic Speed/Position Lost Both of Two Signals • Data Erratic, Intermittent, or Incorrect	The engine will shut down or will not start.
122	102	3	Intake Manifold 1 Pressure Sensor Circuit • Voltage above normal, or shorted to high source	Possible reduced engine performance.
123	102	4	Intake Manifold 1 Pressure Sensor Circuit • Voltage below normal, or shorted to low source	Possible reduced engine performance.
131	91	3	Accelerator Pedal or Lever Position Sensor 1 Circuit • Voltage above normal, or shorted to high source	The engine will operate in Limp Home mode.
132	91	4	Accelerator Pedal or Lever Position Sensor 1 Circuit • Voltage below normal, or shorted to low source	The engine will operate in Limp Home mode.
133	974	3	Remote Accelerator Pedal or Lever Position Sensor 1 Circuit • Voltage above normal, or shorted to high source	Remote accelerator will not operate.
134	974	4	Remote Accelerator Pedal or Lever Position Sensor 1 Circuit • Voltage below normal, or shorted to low source	Remote accelerator will not operate.
143	100	18	Engine Oil Rifle Pressure • Data Valid But Below Normal Operating Range • Moderately Severe Level	Possible reduced engine performance.
144	110	3	Engine Coolant Temperature 1 Sensor Circuit • Voltage above normal, or shorted to high source	Fan will stay ON if controlled by the engine control module (ECM).
145	110	4	Engine Coolant Temperature 1 Sensor Circuit • Voltage below normal, or shorted to low source	Fan will stay ON if controlled by the engine control module (ECM).
146	110	16	Engine Coolant Temperature • Data Valid But Above Normal Operating Range • Moderately Severe Level	Progressive power and/or speed derate increasing in severity from time of alert. If the Engine Protection Shutdown feature is enabled, the engine will shut down 30 seconds after the red STOP lamps starts flashing.
147	91	1	Accelerator Pedal or Lever Position 1 Sensor Circuit Frequency • Data valid but below normal operational range • Most Severe Level	The engine will operate in Limp Home mode.

## TROUBLESHOOTING

Fault Code	SPN	FMI	Cummins Description	Effect
148	91	0	Accelerator Pedal or Lever Position Sensor 1 • Data valid but above normal operational range • Most Severe Level	Severe derate in power output of the engine. Limp home power only.
151	110	0	Engine Coolant Temperature • Data valid but above normal operational range • Most Severe Level	Progressive power derate increasing in severity from time of alert. If engine protection shutdown feature is enabled, engine will shut down 30 seconds after red stop lamp starts flashing.
153	105	3	Intake Manifold 1 Temperature Sensor Circuit • Voltage above normal, or shorted to high source	Fan will stay ON if controlled by the engine control module (ECM).
154	105	4	Intake Manifold 1 Temperature Sensor Circuit • Voltage below normal, or shorted to low source	Fan will stay ON if controlled by the engine control module (ECM).
155	105	0	Intake Manifold 1 Temperature • Data valid but above normal operational range • Most Severe Level	Progressive power and/or speed derate increasing in severity from time of alert. If the Engine Protection Shutdown feature is enabled, the engine will shut down 30 seconds after the red STOP lamps starts flashing.
187	3510	4	Sensor Supply 2 Circuit • Voltage below normal, or shorted to low source	Possible reduced engine performance.
195	111	3	Coolant Level Sensor 1 Circuit • Voltage above normal, or shorted to high source	None on performance.
196	111	4	Coolant Level Sensor 1 Circuit • Voltage below normal, or shorted to low source	None on performance.
197	111	18	Coolant Level • Data Valid But Below Normal Operating Range • Moderately Severe Level	Possible reduced engine performance.
221	108	3	Barometric Pressure Sensor Circuit • Voltage above normal, or shorted to high source	None on performance.
222	108	4	Barometric Pressure Sensor Circuit • Voltage below normal, or shorted to low source	None on performance.
227	3510	3	Sensor Supply 2 Circuit • Voltage above normal, or shorted to high source	Possible reduced engine performance.
234	190	0	Engine Crankshaft Speed/Position • Data valid but above normal operational range • Most Severe Level	Possible reduced engine performance.
235	111	1	Coolant Level • Data valid but below normal operational range • Most Severe Level	Engine will be shut down.

Fault Code	SPN	FMI	Cummins Description	Effect
238	3511	4	Sensor Supply 3 Circuit • Voltage below normal, or shorted to low source	Engine may run rough, may stop running, may not start, or may be difficult to start.
239	3511	3	Sensor Supply 3 Circuit • Voltage above normal, or shorted to high source	Engine may run rough, may stop running, may not start, or may be difficult to start.
241	84	2	Wheel-Based Vehicle Speed • Data erratic, intermittent or incorrect	Engine speed limited to Maximum Engine Speed without VSS parameter value. Cruise Control, Gear-Down Protection, and Road Speed Governor will not work.
242	84	10	Wheel-Based Vehicle Speed Sensor Circuit tampering has been detected • Abnormal rate of change	Engine speed limited to Maximum Engine Speed without VSS parameter value. Cruise Control, Gear-Down Protection, and Road Speed Governor will not work.
245	647	4	Fan Control Circuit • Voltage below normal, or shorted to low source	The fan can stay on continuously or not run at all.
271	1347	4	Engine Fuel Pump Pressurizing Assembly 1 Circuit • Voltage below normal, or shorted to low source	Possible reduced engine performance.
272	1347	3	Engine Fuel Pump Pressurizing Assembly 1 Circuit • Voltage above normal, or shorted to high source	Engine may run rough, may stop running, may not start, or may be difficult to start.
285	639	9	SAE J1939 Multiplexing PGN Timeout Error • Abnormal update rate	At least one multiplexed device will not operate properly.
286	639	13	SAE J1939 Multiplexing Configuration Error • Out of Calibration	At least one multiplexed device will not operate properly.
287	91	19	SAE J1939 Multiplexing Configuration Error • Out of Calibration	At least one multiplexed device will not operate properly.
288	974	19	SAE J1939 Multiplexing Remote Accelerator Pedal or Lever Position Sensor System • Received Network Data In Error	Remote accelerator will not operate.
292	441	14	Auxiliary Temperature Sensor Input 1 • Special Instructions	Engine power derate.
293	441	3	Auxiliary Temperature Sensor Input 1 Circuit • Voltage above normal, or shorted to high source	None on performance.
294	441	4	Auxiliary Temperature Sensor Input 1 Circuit • Voltage below normal, or shorted to low source	None on performance.
296	1388	14	Auxiliary Pressure Sensor Input 2 • Special Instructions	Engine power derate.
322	651	5	Injector Solenoid Driver Cylinder 1 Circuit • Current below normal or open circuit	Possible reduced engine performance.
324	653	5	Injector Solenoid Driver Cylinder 3 Circuit • Current below normal or open circuit	Possible reduced engine performance.
331	652	5	Injector Solenoid Driver Cylinder 2 Circuit • Current below normal or open circuit	Possible reduced engine performance.

## TROUBLESHOOTING

Fault Code	SPN	FMI	Cummins Description	Effect
332	654	5	Injector Solenoid Driver Cylinder 4 Circuit • Current below normal or open circuit	Possible reduced engine performance.
343	629	12	Engine Control Module Warning Internal Hardware Failure • Bad intelligent device or component	Possible no noticeable performance effects or engine dying or hard starting. Fault information, trip information, and maintenance monitor data can be inaccurate.
351	3597	12	Injector Power Supply • Bad intelligent device or component	Possible reduced engine performance.
415	100	1	Engine Oil Rifle Pressure • Data valid but below normal operational range • Most Severe Level	Possible reduced engine performance.
418	97	15	Water in Fuel Indicator • Data Valid But Above Normal Operating Range • Least Severe Level	Possible loss of power, or hard starting.
428	97	3	Water in Fuel Indicator Sensor Circuit • Voltage above normal, or shorted to high source	None on performance.
429	97	4	Water in Fuel Indicator Sensor Circuit • Voltage below normal, or shorted to low source	Possible reduced engine performance.
431	558	2	Accelerator Pedal or Lever Idle Validation Switch • Data erratic, intermittent or incorrect	Engine will only idle.
432	558	13	Accelerator Pedal or Lever Idle Validation Switch Circuit • Out of Calibration	Engine will be shut down.
435	100	2	Engine Oil Rifle Pressure • Data erratic, intermittent or incorrect	None on performance.
441	168	18	Battery 1 Voltage • Data Valid But Below Normal Operating Range • Moderately Severe Level	Engine may run rough, may stop running, may not start, or may be difficult to start.
442	168	16	Battery 1 Voltage • Data Valid But Above Normal Operating Range • Moderately Severe Level	Possible electrical damage to electrical components.
449	157	0	Injector Metering Rail 1 Pressure • Data valid but above normal operational range • Most Severe Level	Possible reduced engine performance.
451	157	3	Injector Metering Rail 1 Pressure Sensor Circuit • Voltage above normal, or shorted to high source	Possible reduced engine performance.
452	157	4	Injector Metering Rail 1 Pressure Sensor Circuit • Voltage below normal, or shorted to low source	Possible reduced engine performance.

Fault Code	SPN	FMI	Cummins Description	Effect
523	611	2	Auxiliary Intermediate (PTO) Speed Switch Validation • Data erratic, intermittent or incorrect	Intermediate speed control switch may not operate correctly.
527	702	3	Auxiliary Input/Output 2 Circuit • Voltage above normal, or shorted to high source	None on performance.
528	93	2	Auxiliary Alternate Torque Validation Switch • Data erratic, intermittent or incorrect	Torque curve setting defaults to default curve.
529	703	3	Auxiliary Input/Output 3 Circuit • Voltage above normal, or shorted to high source	None on performance.
553	157	16	Injector Metering Rail 1 Pressure • Data Valid But Above Normal Operating Range • Moderately Severe Level	Possible reduced engine performance.
559	157	18	Injector Metering Rail 1 Pressure • Data Valid But Below Normal Operating Range • Moderately Severe Level	Engine may run rough, may stop running, may not start, or may be difficult to start.
584	677	3	Starter Relay Driver Circuit • Voltage above normal, or shorted to high source	Either the engine will not start or the engine will not have starter lockout protection.
585	677	4	Starter Relay Driver Circuit • Voltage below normal, or shorted to low source	Either the engine will not start or the engine will not have starter lockout protection.
599	640	14	Auxiliary Commanded Dual Output Shutdown • Special Instructions	Engine will be shut down.
649	1378	31	Engine Oil Change Interval • Condition Exists	None on performance.
689	190	2	Engine Crankshaft Speed/Position • Data erratic, intermittent or incorrect	Possible reduced engine performance.
691	1172	3	Turbocharger 1 Compressor Intake Temperature Circuit • Voltage above normal, or shorted to high source	Possible reduced engine performance.
692	1172	4	Turbocharger 1 Compressor Intake Temperature Circuit • Voltage below normal, or shorted to low source	Possible reduced engine performance.
697	1136	3	Engine ECU Temperature Sensor Circuit • Voltage above normal, or shorted to high source	None on performance.
698	1136	4	Engine ECU Temperature Sensor Circuit • Voltage below normal, or shorted to low source	None on performance.
731	723	7	Engine Speed / Position Camshaft and Crankshaft Misalignment • Mechanical system not responding or out of adjustment	Possible reduced engine performance.

## TROUBLESHOOTING

Fault Code	SPN	FMI	Cummins Description	Effect
741	1176	3	Turbocharger 1 Compressor Intake Pressure Circuit • Voltage Above Normal or Shorted to High Source	Possible reduced engine performance.
742	1176	4	Turbocharger 1 Compressor Intake Pressure Circuit • Voltage Below Normal or Shorted to Low Source	Possible reduced engine performance.
743	1176	2	Turbocharger 1 Compressor Intake Pressure • Data Erratic, Intermittent, or Incorrect	Possible reduced engine performance.
778	723	2	Engine Camshaft Speed / Position Sensor • Data erratic, intermittent or incorrect	Possible reduced engine performance.
1117	3597	2	Power Supply Lost With Ignition On • Data erratic, intermittent or incorrect	Possible reduced engine performance.
1239	2623	3	Accelerator Pedal or Lever Position Sensor 2 Circuit • Voltage above normal, or shorted to high source	The engine will operate in Limp Home mode.
1241	2623	4	Accelerator Pedal or Lever Position Sensor 2 Circuit • Voltage below normal, or shorted to low source	The engine will operate in Limp Home mode.
1242	91	2	Accelerator Pedal or Lever Position Sensor 1 • Data erratic, intermittent or incorrect	Engine will only idle.
1515	91	19	SAE J1939 Multiplexed Accelerator Pedal or Lever Sensor System • Received Network Data In Error	Engine will only idle.
1539	1387	3	Auxiliary Pressure Sensor Input 1 Circuit • Voltage above normal, or shorted to high source	None on performance.
1621	1387	4	Auxiliary Pressure Sensor Input 1 Circuit • Voltage below normal, or shorted to low source	None on performance.
1695	3513	3	Sensor Supply 5 • Voltage above normal, or shorted to high source	The engine will operate in Limp Home mode.
1696	3513	4	Sensor Supply 5 • Voltage below normal, or shorted to low source	The engine will operate in Limp Home mode.
1852	97	16	Water in Fuel Indicator • Data Valid But Above Normal Operating Range • Moderately Severe Level	None on performance.
1866	411	2	Exhaust Gas Recirculation Differential Pressure • Data erratic	Possible reduced engine performance.
1896	2791	13	EGR Valve Controller • Out of Calibration	Possible reduced engine performance.
2185	3512	3	Sensor Supply 4 Circuit • Voltage above normal, or shorted to high source	Engine will only idle.

Fault Code	SPN	FMI	Cummins Description	Effect
2186	3512	4	Sensor Supply 4 Circuit • Voltage below normal, or shorted to low source	Engine will only idle.
2271	27	3	EGR Valve Position Circuit • Voltage above normal, or shorted to high source	EGR valve actuation will be disabled.
2272	27	4	EGR Valve Position Circuit • Voltage below normal, or shorted to low source	Possible reduced engine performance.
2273	411	3	Exhaust Gas Recirculation Differential Pressure Sensor Circuit • Voltage above normal, or shorted to high source	Possible reduced engine performance.
2274	411	4	Exhaust Gas Recirculation Differential Pressure Sensor Circuit • Voltage below normal, or shorted to low source	Possible reduced engine performance.
2311	633	31	Electronic Fuel Injection Control Valve Circuit • Condition Exists	Possible reduced engine performance.
2321	190	2	Engine Crankshaft Speed/Position • Data erratic, intermittent or incorrect	Possible reduced engine performance.
2322	723	2	Engine Camshaft Speed / Position Sensor • Data erratic, intermittent or incorrect	None on performance.
2349	2791	5	EGR Valve Control Circuit • Current Below Normal or Open Circuit	Possible reduced engine performance.
2351	2791	4	EGR Valve Control Circuit • Voltage below normal, or shorted to low source	Possible reduced engine performance.
2352	2791	3	EGR Valve Control Circuit • Voltage above normal, or shorted to high source	Possible reduced engine performance.
2353	2791	6	EGR Valve Control Circuit • Current Above Normal or Grounded Circuit	Possible reduced engine performance.
2357	2791	7	EGR Valve Control Circuit • Mechanical System Not Responding or Out of Adjustment	Possible reduced engine performance.
2375	412	3	Exhaust Gas Recirculation Temperature Sensor Circuit • Voltage above normal, or shorted to high source	Possible reduced engine performance.
2376	412	4	Exhaust Gas Recirculation Temperature Sensor Circuit • Voltage below normal, or shorted to low source	Possible reduced engine performance.
2377	647	3	Fan Control Circuit • Voltage above normal, or shorted to high source	The fan can stay on continuously or not run at all.
2442	651	13	Injector Solenoid Driver Cylinder 1 • Out of Calibration	Possible reduced engine performance.
2443	652	13	Injector Solenoid Driver Cylinder 2 • Out of Calibration	Possible reduced engine performance.

## TROUBLESHOOTING

Fault Code	SPN	FMI	Cummins Description	Effect
2444	653	13	Injector Solenoid Driver Cylinder 3 • Out of Calibration	Possible reduced engine performance.
2445	654	13	Injector Solenoid Driver Cylinder 4 • Out of Calibration	Possible reduced engine performance.
2448	111	17	Coolant Level • Data Valid But Below Normal Operating Range • Least Severe Level	None on performance.
2555	729	3	Engine Intake Air Heater 1 Circuit • Voltage above normal, or shorted to high source	The intake air heaters can be ON or OFF all the time.
2556	729	4	Engine Intake Air Heater 1 Circuit • Voltage below normal, or shorted to low source	The intake air heaters can be ON or OFF all the time.
2557	697	3	Auxiliary PWM Driver 1 Circuit • Voltage above normal, or shorted to high source	None on performance.
2558	697	4	Auxiliary PWM Driver 1 Circuit • Voltage below normal, or shorted to low source	None on performance.
2571	263	3	Engine Charge Air Cooler Outlet Temperature • Voltage Above Normal or Shorted to High Source	None on performance.
2572	263	4	Engine Charge Air Cooler Outlet Temperature • Voltage Below Normal or Shorted to Low Source	None on performance.
2963	110	15	Engine Coolant Temperature • Data Valid But Above Normal Operating Range • Least Severe Level	Progressive power and/or speed derate increasing in severity from time of alert. If the Engine Protection Shutdown feature is enabled, the engine will shut down 30 seconds after the red STOP lamps starts flashing.
2964	105	15	Intake Manifold 1 Temperature • Data Valid But Above Normal Operating Range • Least Severe Level	Possible reduced engine performance.
3186	1623	9	Tachograph Output Shaft Speed • Abnormal update rate	None on performance.
3213	1623	19	Tachograph Output Shaft Speed • Received Network Data In Error	None on performance.
3326	91	9	SAE J1939 Multiplexed Accelerator Pedal or Lever Sensor System • Abnormal update rate	Engine will only idle.
3328	191	9	Transmission Output Shaft Speed • Abnormal update rate	None on performance.
3341	107	16	Engine Air Filter Differential Pressure • Data Valid But Above Normal Operating Range • Moderately Severe Level	Possible reduced engine performance.
3418	191	19	Transmission Output Shaft Speed • Received Network Data In Error	None on performance.



Fault Code	SPN	FMI	Cummins Description	Effect
3525	84	19	Wheel-Based Vehicle Speed • Received Network Data In Error	Engine speed limited to Maximum Engine Speed without VSS parameter value. Cruise Control, Gear-Down Protection, and Road Speed Governor will not work.
3526	84	9	Wheel-Based Vehicle Speed • Abnormal update rate	None on performance.
3527	558	19	Accelerator Pedal or Lever Idle Validation Switch • Received Network Data In Error	Engine will only idle.
3528	558	9	Accelerator Pedal or Lever Idle Validation Switch • Abnormal update rate	Engine will only idle.
3641	748	9	Transmission Output Retarder • Abnormal update rate	None on performance.
3697	630	12	Engine Control Module Calibration Memory • Bad intelligent device or component	Engine may not start or may be difficult to start.
3714	1569	31	Engine Protection Torque Derate • Condition Exists	Possible reduced engine performance.
3727	5571	7	High Pressure Common Rail Fuel Pressure Relief Valve • Mechanical system not responding or out of adjustment	Possible reduced engine performance.
3741	5571	0	High Pressure Common Rail Fuel Pressure Relief Valve • Data valid but above normal operational range • Most Severe Level	Engine may run rough, may stop running, may not start, or may be difficult to start.
3765	442	3	Auxiliary Temperature Sensor Input 2 Circuit • Voltage Above Normal or Shorted to High Source	None on performance.
3766	442	4	Auxiliary Temperature Sensor Input 2 Circuit • Voltage Below Normal or Shorted to Low Source	None on performance.
4642	97	0	Water in Fuel Indicator • Data Valid But Above Normal Operating Range • Most Severe Level	Progressive power and/or speed derate increasing in severity from time of alert. If the Engine Protection Shutdown feature is enabled, the engine will shut down 10 seconds after the red STOP lamps starts flashing.
4734	701	14	Auxiliary Input/Output 1 • Special Instructions	Engine power derate.
4789	1639	0	Fan Speed • Data Valid but Above Normal Operational Range • Most Severe Level	Possible reduced engine performance.
4791	1639	1	Fan Speed • Data Valid but Below Normal Operational Range • Most Severe Level	Possible reduced engine performance.

## TROUBLESHOOTING


Fault Code	SPN	FMI	Cummins Description	Effect
5183	6799	3	Engine Fan Blade Pitch Position Sensor Circuit • Voltage Above Normal or Shorted to High Source	None on performance.
5184	6799	4	Engine Fan Blade Pitch Position Sensor Circuit • Voltage Below Normal or Shorted to Low Source	None on performance.
5185	6799	7	Engine Fan Blade Pitch • Mechanical System Not Responding or Out of Adjustment	None on performance.
5576	107	15	Engine Air Filter Differential Pressure • Data Valid But Above Normal Operating Range • Least Severe Level	Possible reduced engine performance.
6228	920	3	Audible Alarm Circuit • Voltage Above Normal or Shorted to High Source	None on performance.
6229	920	4	Audible Alarm Circuit • Voltage Below Normal or Shorted to Low Source	None on performance.
6231	741	3	Transmission 1 Forward Solenoid Valve Driver Circuit • Voltage Above Normal or Shorted to High Source	None on performance.
6232	741	4	Transmission 1 Forward Solenoid Valve Driver Circuit • Voltage Below Normal or Shorted to Low Source	None on performance.
6233	4216	3	Transmission 1 Reverse Solenoid Valve Driver Circuit • Voltage Above Normal or Shorted to High Source	None on performance.
6234	4216	4	Transmission 1 Reverse Solenoid Valve Driver Circuit • Voltage Below Normal or Shorted to Low Source	None on performance.
6235	768	3	Transmission Range High Actuator Circuit • Voltage Above Normal or Shorted to High Source	None on performance.
6236	768	4	Transmission Range High Actuator Circuit • Voltage Below Normal or Shorted to Low Source	None on performance.
6242	520973	3	Forklift Mast Actuator Driver Circuit • Voltage Above Normal or Shorted to High Source	None on performance.
6243	520973	4	Forklift Mast Actuator Driver Circuit • Voltage Below Normal or Shorted to Low Source	None on performance.

### (NOTICE)

- For details, refer to “Service information” of engine manufacturer.



Fig.: 2-3-1



## 2-3. Engine

Check following items before troubleshooting.

- No blown fuses and power is applied up to fuses.
- Check any ground circuit which belongs to components to be checked.
- Engine warning lamp or engine stop lamp must not be lighting. If engine warning lamp or engine stop lamp lights, refer to troubleshooting of engine manufacturer.


### 2-3-1. Engine will not start (Starter motor does not run) 1/3

- F-R lever must be in "N".
- Parking brake switch must be applied.
- Brake pedal is not depressed.

#### Reference Fig.: 2-3-1

Check point	Check/Cause	Action
1. Battery	<ul style="list-style-type: none"> <li>• Measure battery voltage or specific gravity. Standard voltage : 12 V or more Standard gravity : 1.26 or more</li> <li>• If value is below standard, battery capacity is insufficient.</li> </ul>	Charge or replace battery.
2. Starter Switch	<ul style="list-style-type: none"> <li>• Check continuity between O-O according to starter switch connection table. Switch is OK if there is continuity between connection O-O.</li> <li>• If there is no continuity, starter switch is faulty.</li> </ul>	Replace starter switch.
3. Starter Motor	<p>(1) When starter switch is ON, measure voltage between starter motor terminal B and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is START, measure voltage between starter motor terminal S and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above items (1) and (2) are OK and starter motor does not run, starter motor is faulty.</li> </ul>	Replace starter motor.
4. Starter Relay	<p>(1) When starter switch is ON, measure voltage between starter relay terminal inlet wire RB and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is START, measure voltage between starter relay terminal inlet wire RW and chassis ground. Standard voltage : 12 V or more</p> <p>(3) When starter switch is START, measure voltage between starter relay terminal outlet wire R and chassis ground Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above items (1) and (2) are OK and item (3) is NG, starter relay is faulty.</li> </ul>	Replace starter relay.

Fig.: 2-3-1



SV414-09003


**2-3-1. Engine will not start (Starter motor does not run) 2/3**

- F-R lever must be in "N".
- Parking brake switch must be applied.
- Brake pedal is not depressed.

**Reference Fig.: 2-3-1**

Check point	Check/Cause	Action
5. Battery Relay	<p>(1) When starter switch is OFF, measure voltage between battery relay primary terminal COM and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON, measure voltage between battery relay coil terminal BR inlet wire BR and coil ground terminal E. Standard voltage : 12 V or more</p> <p>(3) When starter switch is ON, measure voltage between battery relay secondary terminal NO and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above items (1) and (2) are OK and item (3) is NG, battery relay is faulty.</li> </ul>	Replace battery relay.
6. F-R Lever Switch	<p>(1) When starter switch is ON, measure voltage between F-R lever switch terminal COM inlet wire R and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON, measure voltage between F-R lever switch terminal NC outlet wire W and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above item (1) is OK and item (2) is NG, F-R lever switch is faulty.</li> </ul>	Replace F-R lever switch.
7. Interlock Relay (A1)	<p>(1) When starter switch is ON, measure voltage between interlock relay terminal 3 inlet wire Lg and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON, measure voltage between interlock relay terminal 1 inlet wire W and chassis ground. Standard voltage : 12 V or more</p> <p>(3) When starter switch is ON, measure voltage between interlock relay terminal 5 outlet wire LgR and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above items (1) and (2) are OK and item (3) is NG, interlock relay is faulty.</li> </ul>	Replace interlock relay (A1).
8. Foot Brake Switch	<p>(1) When starter switch is ON, measure voltage between foot brake switch terminal COM inlet wire R and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON, measure voltage between foot brake switch terminal NO outlet wire LgR and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above item (1) is OK and item (2) is NG, foot brake switch is faulty.</li> </ul>	Replace foot brake switch.

Fig.: 2-3-1






**2-3-1. Engine will not start (Starter motor does not run) 3/3**

- F-R lever must be in "N".
- Parking brake switch must be applied.
- Brake pedal is not depressed.

**Reference Fig.: 2-3-1**

Check point	Check/Cause	Action
9. Parking Brake Switch	<p>(1) When starter switch is ON, measure voltage between parking brake switch terminal 1 inlet wire LgR and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON, measure voltage between parking brake switch terminal 2 outlet wire BrY and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above item (1) is OK and item (2) is NG, parking brake switch is faulty.</li> </ul>	Replace parking brake switch.
10. Parking Interlock Relay (A2)	<p>(1) When starter switch is ON, measure voltage between parking interlock relay terminal 3 inlet wire LgR and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON, measure voltage between parking interlock relay terminal 1 inlet wire BrY and chassis ground. Standard voltage : 12 V or more</p> <p>(3) When starter switch is ON, measure voltage between parking interlock relay terminal 5 outlet wire BW and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above items (1) and (2) are OK and item (3) is NG, parking interlock relay is faulty.</li> </ul>	Replace parking interlock relay (A2).
11. Starter Lockout Relay (A5)	<p>(1) When starter switch is ON, measure voltage between starter lockout relay terminal 3 inlet wire W and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON, measure voltage between starter lockout relay terminal 1 inlet wire LgY and chassis ground. Standard voltage : 12 V or more</p> <p>(3) When starter switch is ON, measure voltage between starter lockout relay terminal 5 outlet wire RW and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above items (1) and (2) are OK and item (3) is NG, starter lockout relay is faulty.</li> </ul>	Replace starter lockout relay (A5).
12. Harness Connecting Between Terminals	<ul style="list-style-type: none"> <li>• Measure resistance of harness connecting between terminals. Standard resistance : 10 Ω or less</li> <li>• If resistance is abnormal, harness is faulty.</li> </ul>	Repair or replace harness.

Fig.: 2-3-1



**2-3-2. No charging**

Reference Fig.: 2-3-1


Check point	Check/Cause	Action
1. Alternator	<ul style="list-style-type: none"> <li>• After starting engine, measure voltage between alternator terminal B+ and chassis ground. Standard voltage : At least intermediate engine speed, 14 V or more</li> <li>• If voltage is lower than standard, alternator is faulty.</li> <li>• If voltage is normal and battery is not charged, battery is faulty.</li> </ul>	Replace alternator or battery.

**2-3-3. Grid heater dose not work (Engine starting performance is bad in cold weather)**

Reference Fig. : 2-3-1

Check point	Check/Cause	Action
1. Grid Heater	<ul style="list-style-type: none"> <li>• When starter switch is ON, measure voltage between grid heater inlet wire and chassis ground. Standard voltage : 12 V or more</li> <li>• If voltage is normal, grid heater is faulty.</li> </ul>	Replace grid heater.
2. Grid Heater Relay	<p>(1) When starter switch is ON, measure voltage between grid heater relay terminal 3 inlet wire and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON, measure voltage between grid heater relay terminal 1 inlet wire and chassis ground. Standard voltage : 12 V or more</p> <p>(3) When starter switch is ON, measure voltage between grid heater relay terminal 5 outlet wire and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above items (1) and (2) are OK and item (3) is NG, grid heater relay is faulty.</li> </ul>	Replace grid heater relay.
3. Harness Connecting Between Terminals	<ul style="list-style-type: none"> <li>• Measure resistance of harness connecting between terminals. Standard resistance : 10 <math>\Omega</math> or less</li> <li>• If resistance is abnormal, harness is faulty.</li> </ul> <p><b>(NOTICE)</b></p> <ul style="list-style-type: none"> <li>• <b>If any abnormality is found in shielded twisted wires, repair is not approved. Be sure to replace them.</b></li> </ul>	Repair or replace harness.

Fig.: 2-3-1



SV414-09003

## 2-3-4. Starter motor runs even when F-R lever is not at “N” and parking brake is not applied

Reference Fig. : 2-3-1


Check point	Check/Cause	Action
1. F-R Lever Switch	<ul style="list-style-type: none"> <li>When starter switch is OFF and F-R lever is “F” or “R”, check continuity between F-R lever switch terminal COM wire R and terminal NC wire W. There is no continuity in normal condition.</li> <li>If there is continuity, F-R lever switch is faulty.</li> </ul>	Replace F-R lever switch.
2. Parking Brake Switch	<ul style="list-style-type: none"> <li>When starter switch is OFF and parking brake switch is released position, check continuity between parking brake switch terminal 1 and 2. There is no continuity in normal condition.</li> <li>If there is continuity, parking brake switch is faulty.</li> </ul>	Replace parking brake switch.

## 2-3-5. Engine speed cannot be switched

Reference Fig. : 2-3-1

Check point	Check/Cause	Action
1. Throttle Switch	<ol style="list-style-type: none"> <li>When throttle switch is “IDLE”, check continuity between throttle switch terminals 1 and 2, 4 and 6. There is continuity in normal condition.</li> <li>When throttle switch is “MID”, check continuity between throttle switch terminals 1 and 3, 4 and 6. There is continuity in normal condition.</li> <li>When throttle switch is “FULL”, check continuity between throttle switch terminals 1 and 3, 4 and 5. There is continuity in normal condition.</li> </ol> <ul style="list-style-type: none"> <li>If above item (1), (2) or (3) is NG, throttle switch is faulty.</li> </ul>	Replace throttle switch.
2. Throttle Relay (A6)	<ol style="list-style-type: none"> <li>When starter switch is ON and throttle switch is “FULL”, measure voltage between throttle relay terminal 1 inlet wire RW and chassis ground. Standard voltage : 12 V or more</li> <li>When starter switch is ON and throttle switch is “FULL”, measure voltage between throttle relay terminal 3 inlet wire WG and chassis ground. Standard voltage : 12 V or more</li> <li>When starter switch is ON and throttle switch is “FULL”, measure voltage between throttle relay terminal 5 outlet wire LW and chassis ground. Standard voltage : 12 V or more</li> <li>When starter switch is ON and throttle switch is “MID”, measure voltage between throttle relay terminal 4 outlet wire WL and chassis ground. Standard voltage : 12 V or more</li> </ol> <ul style="list-style-type: none"> <li>If above items (1) and (2) are OK and item (3) or (4) is NG, throttle relay is faulty.</li> </ul>	Replace throttle relay (A6).
3. Harness Connecting Between Terminals	<ul style="list-style-type: none"> <li>Measure resistance of harness connecting between terminals. Standard resistance : 10 Ω or less</li> <li>If resistance is abnormal, harness is faulty.</li> </ul>	Repair or replace harness.

Fig.: 2-4-1



## 2-4. Propulsion

Check following items before troubleshooting.

- No blown fuses and power is applied up to fuses.
- When measuring voltage and current without disconnecting connectors, refer to “Measuring voltage and current flowing using tester” (P.9-006 to P.9-008).
- Check any ground circuit which belongs to components to be checked.


### 2-4-1. Machine moves neither forward nor backward 1/2

- Parking brake switch must be released.
- Brake pedal is not depressed.

**Reference Fig.:** 2-4-1

Check point	Check/Cause	Action
1. Servo Bypass Solenoid	<ul style="list-style-type: none"> <li>• Disconnect harness and measure resistance of coil. Standard resistance : <math>12.3 \pm 1.2 \Omega</math></li> <li>• If measured resistance is abnormal, servo bypass solenoid is faulty.</li> </ul>	Replace servo bypass solenoid.
2. Parking Brake Solenoid	<ul style="list-style-type: none"> <li>• Disconnect harness and measure resistance of coil. Standard resistance : <math>12.3 \pm 1.2 \Omega</math></li> <li>• If measured resistance is abnormal, parking brake solenoid is faulty.</li> </ul>	Replace parking brake solenoid.
3. Pump Neutral Relay (A3)	<p>(1) When starter switch is ON, measure voltage between pump neutral relay terminal 1 inlet wire BrW and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON, measure voltage between pump neutral relay terminal 3 inlet wire GW and chassis ground. Standard voltage : 12 V or more</p> <p>(3) When starter switch is ON, measure voltage between pump neutral relay terminal 5 outlet wire LY and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above items (1) and (2) are OK and item (3) is NG, pump neutral relay is faulty.</li> </ul>	Replace pump neutral relay (A3).
4. Pump Neutral Holding Relay (A4)	<p>(1) When starter switch is ON and F-R lever is “F” or “R”, measure voltage between pump neutral holding relay terminal 1 inlet wire LY and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON and F-R lever is “F” or “R”, measure voltage between pump neutral holding relay terminal 3 inlet wire R and chassis ground. Standard voltage : 12 V or more</p> <p>(3) When starter switch is ON and F-R lever is “F” or “R”, measure voltage between pump neutral holding relay terminal 5 outlet wire GW and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above items (1) and (2) are OK and item (3) is NG, pump neutral holding relay is faulty.</li> </ul>	Replace pump neutral holding relay (A4).

Fig.: 2-4-1






**2-4-1. Machine moves neither forward nor backward 2/2**

- Parking brake switch must be released.
- Brake pedal is not depressed.

**Reference Fig.: 2-4-1**

Check point	Check/Cause	Action
5. Diode Unit	<p>(1) When starter switch is ON and F-R lever is "N", measure voltage between diode unit terminal I inlet wire W and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON and F-R lever is "N", measure voltage between diode unit terminal H outlet wire GW and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above item (1) is OK and item (2) is NG, diode unit is faulty.</li> </ul>	Replace diode unit.
6. F-R Lever Switch	<p>(1) When starter switch is ON, measure voltage between F-R lever switch terminal COM inlet wire R and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON and F-R lever is "N", measure voltage between F-R lever switch terminal NC outlet wire W and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above item (1) is OK and item (2) is NG, F-R lever switch is faulty.</li> </ul>	Replace F-R lever switch.
7. Foot Brake Switch	<p>(1) When starter switch is ON, measure voltage between foot brake switch terminal COM inlet wire R and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON, measure voltage between foot brake switch terminal NO outlet wire LgR and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above item (1) is OK and item (2) is NG, foot brake switch is faulty.</li> </ul>	Replace foot brake switch.
8. Parking Brake Switch	<p>(1) When starter switch is ON, measure voltage between parking brake switch terminal 1 inlet wire LgR and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON, measure voltage between parking brake switch terminal 3 outlet wire BrW and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above item (1) is OK and item (2) is NG, parking brake switch is faulty.</li> </ul>	Replace parking brake switch.
9. Harness Connecting Between Terminals	<ul style="list-style-type: none"> <li>• Measure resistance of harness connecting between terminals. Standard resistance : 10 <math>\Omega</math> or less</li> <li>• If resistance is abnormal, harness is faulty.</li> </ul>	Repair or replace harness.

Fig.: 2-4-1




## 2-4-2. Machine speed cannot be changed

- Speed select switch must be “”.

### Reference Fig.: 2-4-1

Check point	Check/Cause	Action
1. Speed Change Solenoid (F)	<ul style="list-style-type: none"> <li>• Disconnect harness and measure resistance of coil. Standard resistance : <math>12.3 \pm 1.2 \Omega</math></li> <li>• If measured resistance is abnormal, speed change solenoid (F) is faulty.</li> </ul>	Replace speed change solenoid (F).
2. Speed Change Solenoid (R)	<ul style="list-style-type: none"> <li>• Disconnect harness and measure resistance of coil. Standard resistance : <math>5.1 \Omega</math></li> <li>• If measured resistance is abnormal, speed change solenoid (R) is faulty.</li> </ul>	Replace speed change solenoid (R).
3. Speed Select Switch	<p>(1) When starter switch is ON, measure voltage between speed select switch terminal 1, 4 inlet wire L and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON, measure voltage between speed select switch terminal 3 outlet wire G and chassis ground. Standard voltage : 12 V or more</p> <p>(3) When starter switch is ON, measure voltage between speed select switch terminal 5 outlet wire LW and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above item (1) is OK and item (2) or (3) is NG, speed select switch is faulty.</li> </ul>	Replace speed select switch.
4. Harness Connecting Between Terminals	<ul style="list-style-type: none"> <li>• Measure resistance of harness connecting between terminals. Standard resistance : <math>10 \Omega</math> or less</li> <li>• If resistance is abnormal, harness is faulty.</li> </ul>	Repair or replace harness.

Fig.: 2-4-1




## 2-4-3. Travel mode cannot be changed 1/2

### Reference Fig.: 2-4-1

Check point	Check/Cause	Action
1. Speed Change Solenoid (F)	<ul style="list-style-type: none"> <li>• Disconnect harness and measure resistance of coil. Standard resistance : <math>12.3 \pm 1.2 \Omega</math></li> <li>• If measured resistance is abnormal, speed change solenoid (F) is faulty.</li> </ul>	Replace speed change solenoid (F).
2. Speed Change Solenoid (R)	<ul style="list-style-type: none"> <li>• Disconnect harness and measure resistance of coil. Standard resistance : <math>5.1 \Omega</math></li> <li>• If measured resistance is abnormal, speed change solenoid (R) is faulty.</li> </ul>	Replace speed change solenoid (R).
3. Speed Select Switch	<p>(1) When starter switch is ON, measure voltage between speed select switch terminal 1, 4 inlet wire L and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON and speed select switch is "🐢", measure voltage between speed select switch terminal wires and chassis ground.</p> <ul style="list-style-type: none"> <li>• Speed select switch terminal 2 and chassis ground.</li> <li>• Speed select switch terminal 6 outlet wire BrR and chassis ground.</li> </ul> <p>Standard voltage : 12 V or more</p> <p>(3) When starter switch is ON and speed select switch is "TRAVEL MODE", measure voltage between speed select switch terminal wires and chassis ground.</p> <ul style="list-style-type: none"> <li>• Speed select switch terminal 3 outlet wire G and chassis ground.</li> <li>• Speed select switch terminal 6 outlet wire BrR and chassis ground.</li> </ul> <p>Standard voltage : 12 V or more</p> <p>(4) When starter switch is ON and speed select switch is "🐢", measure voltage between speed select switch terminal wires and chassis ground.</p> <ul style="list-style-type: none"> <li>• Speed select switch terminal 3 outlet wire G and chassis ground.</li> <li>• Speed select switch terminal 5 outlet wire LW and chassis ground.</li> </ul> <p>Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above item (1) is OK and item (2), (3) or (4) is NG, speed select switch is faulty.</li> </ul>	Replace speed select switch.

Fig.: 2-4-1



## 2-4-3. Travel mode cannot be changed 2/2

Reference Fig.: 2-4-1




Check point	Check/Cause	Action
4. Travel Mode Relay (A7)	<p>(1) When starter switch is ON and travel mode select switch is "TRAVEL MODE", measure voltage between travel mode relay terminal 1 inlet wire BrR and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON and travel mode select switch is "TRAVEL MODE", measure voltage between travel mode relay terminal 3 inlet wire G and chassis ground. Standard voltage : 12 V or more</p> <p>(3) When starter switch is ON and travel mode select switch is "TRAVEL MODE", measure voltage between travel mode relay terminal 5 outlet wire LR and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above items (1) and (2) are OK and item (3) is NG, travel mode relay is faulty.</li> </ul>	Replace travel mode relay (A7).
5. Travel Mode Change Switch	<p>(1) When starter switch is ON, measure voltage between travel mode change switch terminal 1 inlet wire LR and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON and travel mode change switch is "", measure voltage between travel mode change switch terminal 3 inlet wire LW and chassis ground. Standard voltage : 12 V or more</p> <p>(3) When starter switch is ON and travel mode change switch is "", measure voltage between travel mode change switch terminal 2 inlet wire WR and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above item (1) is OK and item (2) or (3) is NG, travel mode change switch is faulty.</li> </ul>	Replace travel mode change switch.
6. Harness Connecting Between Terminals	<ul style="list-style-type: none"> <li>• Measure resistance of harness connecting between terminals. Standard resistance : 10 Ω or less</li> <li>• If resistance is abnormal, harness is faulty.</li> </ul>	Repair or replace harness.

Fig.: 2-4-1






**2-4-4. Brake cannot be released 1/2**

- Parking brake switch must be released.
- Brake pedal is not depressed.

**Reference Fig.: 2-4-1**

Check point	Check/Cause	Action
1. Parking Brake Solenoid	<ul style="list-style-type: none"> <li>• Disconnect harness and measure resistance of coil. Standard resistance : <math>12.3 \pm 1.2 \Omega</math></li> <li>• If measured resistance is abnormal, parking brake solenoid is faulty.</li> </ul>	Replace parking brake solenoid.
2. Pump Neutral Relay (A3)	<ol style="list-style-type: none"> <li>(1) When starter switch is ON, measure voltage between pump neutral relay terminal 1 inlet wire BrW and chassis ground. Standard voltage : 12 V or more</li> <li>(2) When starter switch is ON, measure voltage between pump neutral relay terminal 3 inlet wire GW and chassis ground. Standard voltage : 12 V or more</li> <li>(3) When starter switch is ON, measure voltage between pump neutral relay terminal 5 outlet wire LY and chassis ground. Standard voltage : 12 V or more</li> </ol> <ul style="list-style-type: none"> <li>• If above items (1) and (2) are OK and item (3) is NG, pump neutral relay is faulty.</li> </ul>	Replace pump neutral relay (A3).
3. Pump Neutral Holding Relay (A4)	<ol style="list-style-type: none"> <li>(1) When starter switch is ON, measure voltage between pump neutral holding relay terminal 1 inlet wire LY and chassis ground. Standard voltage : 12 V or more</li> <li>(2) When starter switch is ON, measure voltage between pump neutral holding relay terminal 3 inlet wire R and chassis ground. Standard voltage : 12 V or more</li> <li>(3) When starter switch is ON, measure voltage between pump neutral holding relay terminal 5 outlet wire GW and chassis ground. Standard voltage : 12 V or more</li> </ol> <ul style="list-style-type: none"> <li>• If above items (1) and (2) are OK and item (3) is NG, pump neutral holding relay is faulty.</li> </ul>	Replace pump neutral holding relay (A4).
4. Foot Brake Switch	<ol style="list-style-type: none"> <li>(1) When starter switch is ON, measure voltage between foot brake switch terminal COM inlet wire R and chassis ground. Standard voltage : 12 V or more</li> <li>(2) When starter switch is ON, measure voltage between foot brake switch terminal NO outlet wire LgR and chassis ground. Standard voltage : 12 V or more</li> </ol> <ul style="list-style-type: none"> <li>• If above item (1) is OK and item (2) is NG, foot brake switch is faulty.</li> </ul>	Replace foot brake switch.

Fig.: 2-4-1




**2-4-4. Brake cannot be released 2/2**

- Parking brake switch must be released.
- Brake pedal is not depressed.

**Reference Fig.: 2-4-1**

Check point	Check/Cause	Action
5. Parking Brake Switch	<p>(1) When starter switch is ON, measure voltage between parking brake switch terminal 1 inlet wire LgR and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON, measure voltage between parking brake switch terminal 3 outlet wire BrW and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above item (1) is OK and item (2) is NG, parking brake switch is faulty.</li> </ul>	Replace parking brake switch.
6. Harness Connecting Between Terminals	<ul style="list-style-type: none"> <li>• Measure resistance of harness connecting between terminals. Standard resistance : 10 <math>\Omega</math> or less</li> <li>• If resistance is abnormal, harness is faulty.</li> </ul>	Repair or replace harness.

Fig.: 2-4-1




**2-4-5. Brake does not work**

- Parking brake switch must be applied.
- Brake pedal is depressed.

**Reference Fig.: 2-4-1**

Check point	Check/Cause	Action
1. Parking Brake Solenoid	<ul style="list-style-type: none"> <li>• Disconnect harness and measure resistance of coil. Standard resistance : <math>12.3 \pm 1.2 \Omega</math></li> <li>• If measured resistance is abnormal, parking brake solenoid is faulty.</li> </ul>	Replace parking brake solenoid.
2. Parking Brake Switch	<ul style="list-style-type: none"> <li>• When starter switch is ON, measure voltage between parking brake switch terminal 3 outlet wire BrW and chassis ground. There is no electricity in normal condition.</li> <li>• If there is electricity, parking brake switch is faulty.</li> </ul>	Replace parking brake switch.
3. Foot Brake Switch	<ul style="list-style-type: none"> <li>• When starter switch is ON, measure voltage between foot brake switch terminal NO outlet wire LgR and chassis ground. There is no electricity in normal condition.</li> <li>• If there is electricity, foot brake switch is faulty.</li> </ul>	Replace foot brake switch.
4. Pump Neutral Relay (A3)	<p>(1) When starter switch is ON, measure voltage between pump neutral relay terminal 1 inlet wire BrW and chassis ground. There is no electricity in normal condition.</p> <p>(2) When starter switch is ON, measure voltage between pump neutral relay terminal 5 outlet wire LY and chassis ground. There is no electricity in normal condition.</p> <ul style="list-style-type: none"> <li>• If above items (1) is OK and item (2) is NG, pump neutral relay is faulty.</li> </ul>	Replace pump neutral relay (A3).
5. Pump Neutral Holding Relay (A4)	<p>(1) When starter switch is ON, measure voltage between pump neutral holding relay terminal 1 inlet wire LY and chassis ground. There is no electricity in normal condition.</p> <p>(2) When starter switch is ON and F-R lever is "F" or "R", measure voltage between pump neutral holding relay terminal 5 outlet wire GW and chassis ground. There is no electricity in normal condition.</p> <ul style="list-style-type: none"> <li>• If above items (1) is OK and item (2) is NG, pump neutral holding relay is faulty.</li> </ul>	Replace pump neutral holding relay (A4).
5. Harness Connecting Between Terminals	<ul style="list-style-type: none"> <li>• Measure resistance of harness connecting between terminals. Standard resistance : <math>10 \Omega</math> or less</li> <li>• If resistance is abnormal, harness is faulty.</li> </ul>	Repair or replace harness.

Fig.: 2-5-1



## 2-5. Vibration

Check following items before troubleshooting.

- No blown fuses and power is applied up to fuses.
- Throttle switch must be “FULL”.
- Check any ground circuit which belongs to components to be checked.


### 2-5-1. No vibration occurs

- Vibration mode change switch must be “CONT”.
- Vibration select switch must not be “○”.

**Reference Fig.: 2-5-1**

Check point	Check/Cause	Action
1. Vibrator Solenoid	<ul style="list-style-type: none"> <li>• Disconnect harness and measure resistance of coil. Standard resistance : 5.1 Ω</li> <li>• If resistance is abnormal, vibrator solenoid is faulty.</li> </ul>	Replace vibrator solenoid.
2. Vibration Select Switch	<p>(1) When starter switch is ON, measure voltage between vibration select switch terminal 1, 4 inlet wire Y and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON and vibration select switch is “”, measure voltage between vibration select switch terminal 2 outlet wire YB and chassis ground. Standard voltage : 12 V or more</p> <p>(3) When starter switch is ON and vibration select switch is “”, measure voltage between vibration select switch terminal 5 outlet wire YR and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above item (1) is OK and item (2) or (3) is NG, vibration select switch is faulty.</li> </ul>	Replace vibration select switch.
3. Throttle Switch	<p>(1) When starter switch is ON, measure voltage between throttle switch terminal 4 inlet wire RY and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON, measure voltage between throttle switch terminal 5 outlet wire RW and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above item (1) is OK and item (2) is NG, throttle switch is faulty.</li> </ul>	Replace throttle switch.
4. Vibration Mode Change Switch	<p>(1) When starter switch is ON, measure voltage between vibration mode change switch terminal 1 inlet wire RW and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON, measure voltage between vibration mode change switch terminal 2 outlet wire Y and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above item (1) is OK and item (2) is NG, vibration mode change switch is faulty.</li> </ul>	Replace vibration mode change switch.
5. Harness Connecting Between Terminals	<ul style="list-style-type: none"> <li>• Measure resistance of harness connecting between terminals. Standard resistance : 10 Ω or less</li> <li>• If resistance is abnormal, harness is faulty.</li> </ul>	Repair or replace harness.

Fig.: 2-5-1





## 2-5-2. Amplitude does not change (Remains either Low or High)

- Vibration mode change switch must be "CONT".

### Reference Fig.: 2-5-1





Check point	Check/Cause	Action
1. Vibrator Solenoid	<ul style="list-style-type: none"> <li>• Disconnect harness and measure resistance of coil. Standard resistance : 5.1 <math>\Omega</math></li> <li>• If resistance is abnormal, vibrator solenoid is faulty.</li> </ul>	Replace vibrator solenoid.
2. Vibration Select Switch	<p>(1) When starter switch is ON, measure voltage between vibration select switch terminal 1, 4 inlet wire Y and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON and vibration select switch is "  ", measure voltage between vibration select switch terminal 2 outlet wire YB and chassis ground. Standard voltage : 12 V or more</p> <p>(3) When starter switch is ON and vibration select switch is "  ", measure voltage between vibration select switch terminal 5 outlet wire YR and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above item (1) is OK and item (2) or (3) is NG, vibration select switch is faulty.</li> </ul>	Replace vibration select switch.
3. Harness Connecting Between Terminals	<ul style="list-style-type: none"> <li>• Measure resistance of harness connecting between terminals. Standard resistance : 10 <math>\Omega</math> or less</li> <li>• If resistance is abnormal, harness is faulty.</li> </ul>	Repair or replace harness.

Fig.: 2-5-1





**2-5-3. Vibration mode cannot be switched (F-R lever vibration switch does not work)**

- Vibration mode change switch must be “” (manual mode).
- Vibration select switch must not be “○”.

**Reference Fig.: 2-5-1**

Check point	Check/Cause	Action
1. F-R Lever Vibration Switch	<p>(1) When starter switch is ON, measure voltage between F-R lever vibration switch terminal 1 inlet wire RG and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON and F-R lever vibration switch is pressed once, measure voltage between F-R lever vibration switch terminal 2 outlet wire Y and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above item (1) is OK and item (2) is NG, F-R lever vibration switch is faulty.</li> </ul>	Replace F-R lever vibration switch.
2. Vibration Mode Change Switch	<p>(1) When starter switch is ON, measure voltage between vibration mode change switch terminal 1 inlet wire RW and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON, measure voltage between vibration mode change switch terminal 3 outlet wire RG and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above item (1) is OK and item (2) is NG, vibration mode change switch is faulty.</li> </ul>	Replace vibration mode change switch.
3. Harness Connecting Between Terminals	<ul style="list-style-type: none"> <li>• Measure resistance of harness connecting between terminals. Standard resistance : 10 Ω or less</li> <li>• If resistance is abnormal, harness is faulty.</li> </ul>	Repair or replace harness.

Fig.: 2-6-1



## 2-6. Lighting

Check following items before troubleshooting.



- No blown fuses and power is applied up to fuses.
- When measuring voltage and current without disconnecting connectors, refer to “Measuring voltage and current flowing using tester” (P.9-006 to P.9-008).
- Check any ground circuit which belongs to components to be checked.

### 2-6-1. Illumination of combination meter does not light

Reference Fig. : 2-6-1

Check point	Check/Cause	Action
1. Harness	<ul style="list-style-type: none"> <li>• Measure resistance between battery relay terminal NO wire WR and combination meter connector terminal wire No.41 wire RG. Standard resistance : 10 <math>\Omega</math> or less</li> <li>• If resistance is abnormal, harness is faulty.</li> </ul>	Repair or replace harness.
2. Combination Meter (Combination meter illumination)	<p>(1) When starter switch is ON, measure voltage between combination meter terminal wires and ground terminal wire.</p> <ul style="list-style-type: none"> <li>• Continuous power (+) terminal wire No.70 inlet wire WR and ground (-) terminal wire No.X wire B</li> <li>• Power (+) terminal wire No.35 inlet wire YW and ground (-) terminal wire No.X wire B Standard voltage : 12 V or more</li> </ul> <p>(2) When starter switch is ON, measure voltage between combination meter Panel light terminal wire No.41 inlet wire RG and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above items (1) and (2) are OK and combination meter does not turn on, combination meter is faulty.</li> </ul>	Replace combination meter.

Fig.: 2-6-1





## 2-6-2. Combination meter warning lamp or indicator lamp is abnormal

Reference Fig. : 2-6-1

Check point	Check/Cause	Action
1. Harness	<ul style="list-style-type: none"> <li>• Disconnect connectors between combination meter and lamp check relay.</li> <li>• Measure resistance between terminals and chassis ground.               <ul style="list-style-type: none"> <li>• Combination meter connector terminal wire No. 32 wire BY and chassis ground</li> <li>• Lamp check relay terminal 3 wire BY and chassis ground</li> </ul> <p style="margin-left: 40px;">Standard resistance: 100 kΩ or more</p> </li> <li>• If resistance is abnormal, harness is faulty.</li> </ul>	Repair or replace harness.
2. Lamp Check Relay (A9)	<p>(1) When starter switch is ON, measure voltage between lamp check relay terminal 1 outlet wire LgW and chassis ground. Standard voltage : 12 V or more</p> <p>(2) After starting engine, measure voltage between lamp check relay terminal 2 inlet wire LB and chassis ground. Standard voltage : 12 V or more</p> <p>(3) After starting engine, check continuity between lamp check relay terminal 3 inlet wire BY and chassis ground. There is no continuity in normal condition.</p> <ul style="list-style-type: none"> <li>• If above items (1) and (2) are OK and item (3) is NG, lamp check relay is faulty.</li> <li>• If above item (1) is OK and item (2) is NG, alternator is faulty.</li> </ul>	Repair or replace lamp check relay (A9) or alternator.
3. Combination Meter (Lamp check)	<p>(1) When starter switch is ON, measure voltage between combination meter terminal wires and ground terminal wire.</p> <ul style="list-style-type: none"> <li>• Continuous power (+) terminal wire No.70 inlet wire WR and ground (-) terminal wire No.X wire B</li> <li>• Power (+) terminal wire No.35 inlet wire YW and ground (-) terminal wire No.X wire B</li> </ul> <p style="margin-left: 40px;">Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON, check that parking brake indicator lamp, hydraulic oil filter warning lamp and charge warning lamp illuminate and then go out after starting engine.</p> <ul style="list-style-type: none"> <li>• If above item (1) is OK and item (2) is NG, combination meter is faulty.</li> </ul> <p><b>(NOTICE)</b></p> <ul style="list-style-type: none"> <li>• <b>Since engine cannot start unless parking brake switch is applied, parking brake indicator lamp does not go out even after starting engine.</b></li> </ul>	Replace combination meter.

Fig.: 2-6-1





**2-6-3. Hour meter is abnormal**

Reference Fig. : 2-6-1



Check point	Check/Cause	Action
1. Combination Meter (Hour meter)	<p>(1) When starter switch is ON, measure voltage between combination meter terminal wires and ground terminal wire.</p> <ul style="list-style-type: none"> <li>• Continuous power (+) terminal wire No.70 inlet wire WR and ground (-) terminal wire No.X wire B</li> <li>• Power (+) terminal wire No.35 inlet wire YW and ground (-) terminal wire No.X wire B</li> </ul> <p>Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON, measure voltage between combination meter hour meter terminal wire No.35 inlet wire YW and chassis ground.</p> <p>Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above item is OK and tachometer reading is NG, combination meter is faulty.</li> </ul>	Replace combination meter.

**2-6-4. Fuel meter is abnormal**

Reference Fig. : 2-6-1

Check point	Check/Cause	Action
1. Fuel Gauge Unit	<ul style="list-style-type: none"> <li>• Disconnect harness and measure resistance of fuel gauge unit.</li> </ul> <p>Standard resistance :</p> <p>13.5 <math>\Omega</math> (with float in "F")</p> <p>80.0 <math>\Omega</math> (with float in "E")</p> <ul style="list-style-type: none"> <li>• If resistance is abnormal, fuel gauge unit is faulty.</li> </ul>	Replace fuel gauge unit.
2. Combination Meter (Fuel meter)	<ul style="list-style-type: none"> <li>• When starter switch is ON, measure voltage between combination meter terminal wires and ground terminal wire.</li> </ul> <ul style="list-style-type: none"> <li>• Continuous power (+) terminal wire No.70 inlet wire WR and ground (-) terminal wire No.X wire B</li> <li>• Power (+) terminal wire No.35 inlet wire YW and ground (-) terminal wire No.X wire B</li> </ul> <p>Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If no abnormality is found, combination meter is faulty.</li> </ul>	Replace combination meter.
3. Harness Connecting Between Terminals	<ul style="list-style-type: none"> <li>• Measure resistance of harness connecting between terminals.</li> </ul> <p>Standard resistance : 10 <math>\Omega</math> or less</p> <ul style="list-style-type: none"> <li>• If resistance is abnormal, harness is faulty.</li> </ul>	Repair or replace harness.

Fig.: 2-6-1




## 2-6-5. Hydraulic oil filter warning lamp remains ON

Reference Fig. : 2-6-1

Check point	Check/Cause	Action
1. Harness	<ul style="list-style-type: none"> <li>• Disconnect connectors between hydraulic oil filter switch 1, 2 and combination meter.</li> <li>• Measure resistance between terminal and chassis ground.               <ul style="list-style-type: none"> <li>• Hydraulic oil filter switch 1 or 2 terminal wire Y and chassis ground.</li> <li>• Combination meter connector terminal wire No. 22 wire Y and chassis ground.</li> </ul> <p style="margin-left: 40px;">Standard resistance : 100 kΩ or more</p> </li> <li>• If resistance is abnormal, harness is faulty.</li> </ul>	Repair or replace harness.
2. Hydraulic Oil Filter Switch 1 or 2	<ul style="list-style-type: none"> <li>• When starter switch is OFF, check continuity between hydraulic oil filter switch 1 or 2 terminal inlet wire Y and chassis ground.               <p style="margin-left: 20px;">There is no continuity in normal condition.</p> </li> <li>• If there is continuity, hydraulic oil filter switch 1 or 2 is faulty.</li> </ul>	Replace hydraulic oil filter switch 1 or 2.
3. Combination Meter (Hydraulic oil filter warning)	<p>(1) When starter switch is ON, measure voltage between combination meter terminal wires and ground terminal wire.</p> <ul style="list-style-type: none"> <li>• Continuous power (+) terminal wire No.70 inlet wire WR and ground (-) terminal wire No.X wire B</li> <li>• Power (+) terminal wire No.35 inlet wire YW and ground (-) terminal wire No.X wire B</li> </ul> <p style="margin-left: 40px;">Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON, measure voltage between combination meter hydraulic filter terminal outlet wire No.22 wire Y and chassis ground.</p> <p style="margin-left: 40px;">Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above items (1) and (2) are OK but hydraulic oil filter warning lamp remains on after starting engine, combination meter is faulty.</li> </ul>	Replace combination meter.

Fig.: 2-6-2




## 2-6-6. Vibration indicator lamp does not light

- Check that vibrator can be operated.
- Vibration mode change switch must be "CONT".

### Reference Fig. : 2-6-2

Check point	Check/Cause	Action
1. Harness	<p>(1) Measure resistance between vibration select switch terminal 5 wire YR and diode unit terminal E wire YR. Standard resistance : 10 Ω or less</p> <p>(2) Measure resistance between vibration select switch terminal 2 wire YB and diode unit terminal A wire YB. Standard resistance : 10 Ω or less</p> <p>(3) Measure resistance between diode unit terminal F wire Br and combination meter connector terminal wire No. 31 wire Br. Standard resistance : 10 Ω or less</p> <ul style="list-style-type: none"> <li>• If above item (1), (2) or (3) is NG, harness is faulty.</li> </ul>	Repair or replace harness.
2. Diode Unit	<p>(1) When starter switch is ON and vibration select switch is "√^", measure voltage between diode unit terminal A inlet wire YB and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON and vibration select switch is "√^", measure voltage between diode unit terminal E inlet wire YR and chassis ground. Standard voltage : 12 V or more</p> <p>(3) When starter switch is ON, measure voltage between diode unit terminal F outlet wire Br and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above items (1) and (2) are OK and item (3) is NG, diode unit is faulty.</li> </ul>	Replace diode unit.
3. Combination Meter (Vibration indicator lamp)	<p>(1) When starter switch is ON, measure voltage between combination meter terminal wires and ground terminal wire.</p> <ul style="list-style-type: none"> <li>• Continuous power (+) terminal wire No.70 inlet wire WR and ground (-) terminal wire No.X wire B</li> <li>• Power (+) terminal wire No.35 inlet wire YW and ground (-) terminal wire No.X wire B</li> </ul> <p>Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON and vibration select switch is "√^" or "√^", measure voltage between combination meter vibration terminal wire No. 31 inlet wire Br and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above items (1) and (2) are OK and vibration indicator lamp does not light, combination meter is faulty.</li> </ul>	Replace combination meter.

Fig.: 2-6-2




**2-6-7. Parking brake indicator lamp does not light**

Reference Fig. : 2-6-2

Check point	Check/Cause	Action
1. Harness	<ul style="list-style-type: none"> <li>• Measure resistance between parking brake switch terminal 4 wire GR and combination meter connector terminal wire No. 38 wire GR. Standard resistance : 10 Ω or less</li> <li>• If resistance is abnormal, harness is faulty.</li> </ul>	Repair or replace harness.
2. Parking Brake Switch	<ul style="list-style-type: none"> <li>• When parking brake is applied, check continuity between parking brake switch terminal 4 and 5. There is continuity in normal condition.</li> <li>• If there is no continuity, parking brake switch is faulty.</li> </ul>	Replace parking brake switch.
3. Combination Meter (Parking brake indicator lamp)	<p>(1) When starter switch is ON, measure voltage between combination meter terminal wires and ground terminal wire.</p> <ul style="list-style-type: none"> <li>• Continuous power (+) terminal wire No.70 inlet wire WR and ground (-) terminal wire No.X wire B</li> <li>• Power (+) terminal wire No.35 inlet wire YW and ground (-) terminal wire No.X wire B</li> </ul> <p>Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON and parking brake is applied, check continuity between combination meter parking brake terminal wire No.38 inlet wire GR and chassis ground.</p> <p>There is continuity in normal condition.</p> <ul style="list-style-type: none"> <li>• If above items (1) and (2) are OK and parking brake indicator lamp does not light, combination meter is faulty.</li> </ul>	Replace combination meter.

Fig.: 2-6-3





**2-6-8. Horn does not sound**

Reference Fig. : 2-6-3

Check point	Check/Cause	Action
1. Horn	<ul style="list-style-type: none"> <li>• Disconnect horn and directly connect battery positive terminal to horn terminal wire LgW side and negative terminal to horn terminal wire B side.</li> <li>• If horn does not sound, horn is faulty.</li> </ul>	Replace horn.
2. Horn Relay (A8)	<p>(1) When starter switch is ON, measure voltage between horn relay terminal 1, 3 inlet wire RY and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON and horn switch pressed, measure voltage between horn relay terminal 5 outlet wire LgW and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above item (1) is OK and item (2) is NG, horn relay is faulty.</li> </ul>	Replace horn relay (A8).
3. Horn Switch	<ul style="list-style-type: none"> <li>• When horn switch is ON, check continuity between horn switch terminals. There is continuity in normal condition.</li> <li>• If there is no continuity, horn switch is faulty.</li> </ul>	Replace horn switch.
4. Harness Connecting Between Terminals	<ul style="list-style-type: none"> <li>• Measure resistance of harness connecting between terminals. Standard resistance : 10 Ω or less</li> <li>• If resistance is abnormal, harness is faulty.</li> </ul>	Repair or replace harness.

**2-6-9. Backup buzzer does not sound**

Reference Fig. : 2-6-3

Check point	Check/Cause	Action
1. Backup Buzzer	<ul style="list-style-type: none"> <li>• Disconnect backup buzzer and directly connect battery positive terminal to backup buzzer terminal wire GB side and negative terminal to backup buzzer terminal wire B side.</li> <li>• If backup buzzer does not sound, backup buzzer is faulty.</li> </ul>	Replace backup buzzer.
2. Backup Buzzer Switch	<p>(1) When starter switch is ON, measure voltage between backup buzzer switch terminal COM inlet wire R and chassis ground. Standard voltage : 12 V or more</p> <p>(2) When starter switch is ON and F-R lever is "R" , measure voltage between backup buzzer switch terminal NO outlet wire GB and chassis ground. Standard voltage : 12 V or more</p> <ul style="list-style-type: none"> <li>• If above item (1) is OK and item (2) is NG, backup buzzer switch is faulty.</li> </ul>	Replace backup buzzer switch.
3. Harness Connecting Between Terminals	<ul style="list-style-type: none"> <li>• Measure resistance of harness connecting between terminals. Standard resistance : 10 Ω or less</li> <li>• If resistance is abnormal, harness is faulty.</li> </ul>	Repair or replace harness.

## 3. HYDRAULIC SYSTEM TROUBLESHOOTING

### 3-1. When Performing Hydraulic System Troubleshooting

- The largest factor in the majority of failures of hydraulic devices operating under conditions of higher pressure and greater precision is the entry of dirt (foreign substances) into the hydraulic circuit. Particular caution is required when supplying hydraulic oil or when disassembling and assembling hydraulic devices.

#### 1) Pay attention to the work environment.

As much as possible, avoid performing tasks such as supplying hydraulic oil, replacing filters and repair work on rainy days, when there is strong wind, or in locations where there is much dust.

#### 2) Disassembly and maintenance work in the field

There is the danger of dust entry when disassembly and maintenance work for hydraulic components is performed in the field. In addition, because performance verification after repairs are completed is difficult, replacement of the entire assembly is preferred. Perform disassembly and maintenance of hydraulic components in a special room protected from dust, and use special testers to verify the performance.

#### 3) Sealing of openings

Use caps, tape, plastic bags or other means to seal the openings of removed pipes and components in order to prevent foreign substances from entering. Never leave the openings exposed or put a shop cloth into them. There is the danger of foreign substances entering or of leaking oil causing environmental contamination. Do not dispose of waste oil on-site. Either deliver it to the customer and request disposal or take it back with you and dispose of it.

#### 4) Prevent entry of foreign substances when supplying oil.

Take care that foreign substances do not enter when supplying hydraulic oil. Clean the oil supply port and the area around it, as well as the supply pump, oilcan and other items. A more reliable method is to use oil cleaning equipment, which can filter out the contamination that occurred during storage.

#### 5) Change hydraulic oil while the temperature is still high.

All oils, including hydraulic oil, flow more readily when they are warm. Higher temperatures also make it easier to eject the sludge and other substances outside the circuit together with the oil. For these reasons, oil changes should be performed while the oil temperature is high. When changing the oil, it is necessary to drain out as much of the old hydraulic oil as possible. (In addition to the hydraulic oil tank, also drain the oil from the filter and circuit drain plugs.) If old hydraulic oil remains in the system, the contaminants and sludge in the old oil will mix with the new oil and shorten the hydraulic oil lifetime.

## 3-2. Propulsion System

If a problem occurs in the propulsion systems such as the propulsion pump, propulsion motor and brakes, determine the cause and carry out action as required, according to the following general troubleshooting items.

### (NOTICE)

- When checking whether or not the pressure is correct, refer to the pressure standard value for each hydraulic circuit.

### 3-2-1. Machine moves neither forward nor backward 1/2

Check point	Cause	Check/Action
1. Oil Level of Hydraulic Oil Tank	Oil level in hydraulic oil tank is low.	Fill tank until correct oil level is obtained.
2. Bypass Valve	Bypass valve is open.	Close bypass valve.
3. F-R Lever Linkage	F-R lever linkage is faulty.	Check and adjust F-R lever linkage or replace it if necessary.
4. Charge Circuit Pressure	Propulsion pump does not discharge oil because charge pressure is low.	<ul style="list-style-type: none"> <li>• Measure charge pressure.</li> <li>• If low, check and adjust charge relief valve or replace it if necessary.</li> </ul>
	Insufficient steering • charge pump discharge.	Repair steering • charge pump or replace it if necessary.
	Charge pressure decreases due to internal leakage of solenoid valve connecting oil supply circuit with charge circuit. <ul style="list-style-type: none"> <li>• Parking brake solenoid valve</li> <li>• Speed change solenoid valve</li> </ul>	<ul style="list-style-type: none"> <li>• When solenoid is energized, check if oil flows in return circuit to tank.</li> <li>• If oil is flowing, repair solenoid valve or replace it if necessary.</li> </ul>
5. Servo Bypass Solenoid Valve	If spool of servo bypass solenoid valve is stuck, pressure in both sides of servo cylinder chamber is equalized. This causes propulsion pump unable to discharge oil.	<ul style="list-style-type: none"> <li>• Measure pressure in servo cylinder chambers.</li> <li>• If pressure is equal in both chambers, repair servo bypass solenoid valve or replace it if necessary.</li> </ul>
6. Suction Filter for Steering • Charge Pump	Steering • charge pump flow is reduced due to clogged filter.	Clean suction filter or replace it if necessary.
7. Propulsion Circuit Pressure	Circuit does not obtain required pressure because setting pressure of high pressure relief is low.	<ul style="list-style-type: none"> <li>• Measure propulsion circuit pressure.</li> <li>• If low, check and adjust multifunction valve or replace it if necessary.</li> </ul>
8. Propulsion Motor	Propulsion circuit pressure is not held in propulsion motor case.	If pressure in propulsion motor case is not within allowable range, repair propulsion motor or replace it if necessary.
	Internal leakage of propulsion motor.	<ul style="list-style-type: none"> <li>• Measure drain quantity from propulsion motor.</li> <li>• If drain quantity is larger than standard value, repair propulsion motor or replace it if necessary.</li> </ul>

**3-2-1. Machine moves neither forward nor backward 2/2**

Check point	Cause	Check/Action
9. Propulsion Pump	Discharge flow rate is insufficient due to efficiency degradation of propulsion pump.	<ul style="list-style-type: none"> <li>• Measure discharge flow rate of propulsion pump with flow meter.</li> <li>• If discharge flow rate is not within specified range, repair propulsion pump or replace it if necessary.</li> </ul>
	Discharge flow rate is insufficient due to wear of propulsion pump drive shaft splines.	Replace propulsion pump.
	Propulsion circuit pressure is not held in propulsion pump case.	If pressure in propulsion pump case is not within allowable range, repair propulsion pump or replace it if necessary.
10. Parking Brake Solenoid Valve	Brake remains applied because spool of parking brake solenoid valve does not shift.	Repair parking brake solenoid valve or replace it if necessary.
11. Brake Inlet Pressure	Brake cannot be released because brake inlet pressure is low.	<ul style="list-style-type: none"> <li>• Measure brake release pressure.</li> <li>• If low, repair or replace propulsion motor.</li> </ul>
12. Rear Axle	Sticking of disc brakes causes brakes to remain applied.	<ul style="list-style-type: none"> <li>• Replace disc brakes.</li> </ul>
13. Flange	Drive torque is not transmitted to pump due to faulty flange.	Replace flange.

**3-2-2. Machine moves in one direction only (forward or backward)**

Check point	Cause	Check/Action
1. F-R Lever Linkage	F-R lever linkage is faulty.	Check and adjust F-R lever linkage or replace it if necessary.
2. Multifunction Valve	Low circuit pressure due to incorrect high pressure relief setting or internal leakage of multifunction valve.	<ul style="list-style-type: none"> <li>• Interchange two multifunction valves.</li> <li>• If faulty condition is accordingly reversed, check and adjust multifunction valve or replace it if necessary.</li> </ul>

**3-2-3. Slow machine speed or small drive force 1/2**

Check point	Cause	Check/Action
1. Bypass Valve	Bypass valve is slightly open.	Close bypass valve completely.
2. F-R Lever Linkage	F-R lever linkage is faulty.	Check and adjust F-R lever linkage or replace it if necessary.
3. Charge Circuit Pressure	Stroke of propulsion pump swash plate is small because charge pressure is low, decreasing discharge rate of propulsion pump.	<ul style="list-style-type: none"> <li>• Measure charge pressure.</li> <li>• If low, check and adjust charge relief valve or replace it if necessary.</li> </ul>
	Insufficient steering • charge pump discharge.	Repair steering • charge pump or replace it if necessary.
	Charge pressure decreases due to internal leakage of solenoid valve connecting oil supply circuit with charge circuit. <ul style="list-style-type: none"> <li>• Parking brake solenoid valve</li> <li>• Speed change solenoid valve</li> </ul>	<ul style="list-style-type: none"> <li>• When solenoid is energized, check if oil flows in return circuit to tank.</li> <li>• If oil is flowing, repair solenoid valve or replace it if necessary.</li> </ul>
4. Suction Filter for Steering • Charge Pump	Flow rate of steering • charge pump decreases as well as charge pressure decreases due to clogged filter.	Clean suction filter or replace it if necessary.

**3-2-3. Slow machine speed or small drive force 2/2**

Check point	Cause	Check/Action
5. Propulsion Motor	Propulsion motor inlet pressure is low.	<ul style="list-style-type: none"> <li>• Measure propulsion motor inlet pressure.</li> <li>• If low, check and adjust multifunction valve or replace it if necessary.</li> </ul>
	Propulsion circuit pressure is not held in propulsion motor case.	If pressure in propulsion motor case is not within allowable range, repair propulsion motor or replace it if necessary.
	Output of propulsion motor decreases and number of revolutions decreases due to internal leakage of propulsion motor.	<ul style="list-style-type: none"> <li>• Measure drain quantity from propulsion motor.</li> <li>• If drain quantity is larger than standard value, repair propulsion motor or replace it if necessary.</li> </ul>
6. Propulsion Pump	Discharge flow rate is insufficient due to efficiency degradation of propulsion pump.	<ul style="list-style-type: none"> <li>• Measure discharge flow rate of propulsion pump with flow meter.</li> <li>• If discharge flow rate is not within specified range, repair propulsion pump or replace it if necessary.</li> </ul>
	Discharge flow rate is insufficient due to wear of propulsion pump drive shaft splines.	Replace propulsion pump.
	Propulsion circuit pressure is not held in propulsion pump case.	If pressure in propulsion pump case is not within allowable range, repair propulsion pump or replace it if necessary.

**3-2-4. Machine speed cannot be switched**

Check point	Cause	Check/Action
1. Charge Circuit Pressure	Insufficient steering • charge pump discharge.	Repair steering • charge pump or replace it if necessary.
	Charge pressure decreases due to internal leakage of solenoid valve connecting oil supply circuit with charge circuit. <ul style="list-style-type: none"> <li>• Parking brake solenoid valve</li> <li>• Speed change solenoid valve</li> </ul>	<ul style="list-style-type: none"> <li>• When solenoid is energized, check if oil flows in return circuit to tank.</li> <li>• If oil is flowing, repair solenoid valve or replace it if necessary.</li> </ul>
2. Speed Change Solenoid Valve	Machine speed does not change because spool of speed change solenoid valve does not change.	Repair speed change solenoid valve or replace it if necessary.
3. Propulsion Motor Swash Plate Stroke Cylinder	Faulty propulsion motor swash plate stroke cylinder.	Repair propulsion motor or replace it if necessary.

**3-2-5. Machine does not stop completely with F-R lever in “N”**

Check point	Cause	Check/Action
1. F-R lever Linkage	F-R lever linkage is faulty.	Check and adjust F-R lever linkage or replace it if necessary.
2. Servo Control Valve	Servo control valve neutral position adjustment failure.	Check and adjust servo control valve or replace it if necessary.
3. Servo Cylinder	Faulty servo cylinder or faulty pump swash plate setting.	Repair propulsion pump or replace it if necessary.

**3-2-6. Propulsion system is overheating**

Check point	Cause	Check/Action
1. Oil Level of Hydraulic Oil Tank	Oil level in hydraulic oil tank is low.	Fill tank until correct oil level is obtained.
2. Oil Cooler	Cooling efficiency is reduced due to clogged oil cooler fins.	Clean oil cooler fins.
3. Flushing Valve	Hydraulic oil in propulsion closed circuit is insufficiently cooled due to flushing valve shuttle spool sticking.	Repair flushing valve or replace it if necessary.
	Hydraulic oil in propulsion closed circuit is insufficiently cooled because flushing valve relief setting pressure is excessively high.	Check dust or damage in flushing relief valve and replace it if necessary.
	Hydraulic oil in propulsion closed circuit is insufficiently cooled due to flushing valve relief valve poppet sticking.	Clean flushing relief valve or replace it if necessary.
4. Propulsion Circuit Pressure	If circuit pressure setting is excessively low, relief valve opens, causing temperature of hydraulic oil in circuit to rise.	<ul style="list-style-type: none"> <li>• Measure propulsion circuit pressure.</li> <li>• If low, increase relief setting pressure.</li> </ul>
	If load is excessively heavy, relief valve opens, causing temperature of hydraulic oil in circuit to rise.	<ul style="list-style-type: none"> <li>• Measure propulsion circuit pressure.</li> <li>• If high, decrease propulsion load.</li> </ul>
5. Suction Filter for Steering • Charge Pump	Load of steering • charge pump increases due to clogged filter, causing temperature of hydraulic oil in circuit to rise.	Clean suction filter or replace it if necessary.
6. Hydraulic Oil Filter 1	Charge circuit pressure increases due to clogged filter.	Clean hydraulic oil filter 1 or replace it if necessary.

**3-2-7. Abnormal noise from propulsion system**

Check point	Cause	Check/Action
1. Roller Bearings	Roller bearings supporting front drum are damaged.	Replace roller bearings.
2. Gear Box (front motor)	Reduction gear of gear box is damaged.	Replace reduction gear.
3. Rear Axle	Rear axle gear is damaged.	Replace rear axle gear.
4. Hydraulic Hose Clamp	Vibrator sound of hydraulic hose is generated because clamp securing hydraulic hose is loose.	Tighten bolts of loose hydraulic hose clamp to specified torque.
5. Suction Filter for Steering • Charge Pump	Cavitation is occurring in steering • charge pump due to clogged filter.	Clean suction filter or replace it if necessary.
6. Charge Circuit Pressure	If charge pressure is low, brake cannot be released completely, which causes brake drag.	<ul style="list-style-type: none"> <li>• Measure charge pressure.</li> <li>• If low, check and adjust charge relief valve or replace it if necessary.</li> </ul>
7. Propulsion Motor	Internal bearing of propulsion motor is damaged.	Repair propulsion motor or replace it if necessary.

### 3-3. Vibrator System

If a problem occurs in the vibrator systems such as the vibrator pump, vibrator motor and vibrator solenoid valve, determine the cause and carry out action as required, according to the following general troubleshooting items.

**(NOTICE)**

- **When checking whether or not the pressure is correct, refer to the pressure standard value for each hydraulic circuit.**

#### 3-3-1. No vibration

Check point	Cause	Check/Action
1. Oil Level of Hydraulic Oil Tank	Oil level in hydraulic oil tank is low.	Fill tank until correct oil level is obtained.
2. Charge Circuit Pressure	Vibrator pump does not discharge oil due to low charge pressure.	<ul style="list-style-type: none"> <li>• Measure charge pressure.</li> <li>• If low, check and adjust charge relief valve or replace it if necessary.</li> </ul>
	Insufficient steering • charge pump discharge.	Repair steering • charge pump or replace it if necessary.
	Charge pressure decreases due to internal leakage of solenoid valve connecting oil supply circuit with charge circuit. <ul style="list-style-type: none"> <li>• Parking brake solenoid valve</li> <li>• Speed change solenoid valve</li> </ul>	<ul style="list-style-type: none"> <li>• When solenoid is energized, check if oil flows in return circuit to tank.</li> <li>• If oil is flowing, repair solenoid valve or replace it if necessary.</li> </ul>
3. Vibrator Solenoid Valve	Vibrator pump cannot discharge oil because spool of vibrator solenoid valve does not shift.	Repair vibrator solenoid valve or replace them if necessary.
4. Suction Filter for Steering • Charge Pump	Steering • charge pump flow is reduced due to clogged filler.	Clean suction filter or replace it if necessary.
5. Vibrator Circuit Pressure	Circuit does not obtain required pressure because setting pressure of high pressure check relief is low.	<ul style="list-style-type: none"> <li>• Measure vibrator circuit pressure.</li> <li>• If low, check and clean high pressure relief valve or replace it if necessary.</li> </ul>
6. Vibrator Motor	Vibrator circuit pressure is not held in vibrator motor case.	If pressure in vibrator motor case is not within allowable range, repair vibrator motor or replace it if necessary.
	Internal leakage of vibrator motor.	<ul style="list-style-type: none"> <li>• Measure drain quantity from vibrator motor.</li> <li>• If drain quantity is larger than standard value, repair vibrator motor or replace it if necessary.</li> </ul>
	Output torque is not transmitted due to worn spline of vibrator motor output shaft.	Replace vibrator motor.
7. Vibrator Pump	Insufficient discharge rate from vibrator pump due to reduced efficiency of vibrator pump.	<ul style="list-style-type: none"> <li>• Measure discharge flow rate of vibrator pump with flow meter.</li> <li>• If discharge flow rate is not within specified range, repair vibrator pump or replace it if necessary.</li> </ul>
	Insufficient pump discharge due to wear of vibrator pump drive shaft spline.	Replace vibrator pump.
	Vibrator circuit pressure is not held in vibrator pump case.	If pressure in vibrator pump case is not within allowable range, repair vibrator pump or replace it if necessary.

**3-3-2. Vibrator frequency is too low**

Check point	Cause	Check/Action
1. Oil Level of Hydraulic Oil Tank	Oil level in hydraulic oil tank is low.	Fill tank until correct oil level is obtained.
2. Charge Circuit Pressure	Stroke of vibrator pump swash plate is small because charge pressure is low, decreasing discharge rate of vibrator pump.	<ul style="list-style-type: none"> <li>• Measure charge pressure.</li> <li>• If low, check and adjust charge relief valve or replace it if necessary.</li> </ul>
	Insufficient steering • charge pump discharge.	Repair steering • charge pump or replace it if necessary.
	Charge pressure decreases due to internal leakage of solenoid valve connecting oil supply circuit with charge circuit. <ul style="list-style-type: none"> <li>• Parking brake solenoid valve</li> <li>• Speed change solenoid valve</li> </ul>	<ul style="list-style-type: none"> <li>• When solenoid is energized, check if oil flows in return circuit to tank.</li> <li>• If oil is flowing, repair solenoid valve or replace it if necessary.</li> </ul>
3. Suction Filter for Steering • charge Pump	Flow rate of steering • charge pump decreases as well as charge pressure decreases due to clogged filter.	Clean suction filter or replace it if necessary.
4. Vibrator Motor	Vibrator motor inlet pressure is low.	<ul style="list-style-type: none"> <li>• Measure vibrator motor inlet pressure.</li> <li>• If low, check and clean high pressure relief valve or replace it if necessary.</li> </ul>
	Vibrator circuit pressure is not held in vibrator motor case.	If pressure in vibrator motor case is not within allowable range, repair vibrator motor or replace it if necessary.
	Decrease in vibrator motor rpm due to internal leakage in vibrator motor.	<ul style="list-style-type: none"> <li>• Measure drain quantity from vibrator motor.</li> <li>• If drain quantity is larger than standard value, repair vibrator motor or replace it if necessary.</li> </ul>
5. Vibrator Pump	Insufficient discharge rate from vibrator pump due to reduced efficiency of vibrator pump.	<ul style="list-style-type: none"> <li>• Measure discharge flow rate of vibrator pump with flow meter.</li> <li>• If discharge flow rate is not within specified range, repair vibrator pump or replace it if necessary.</li> </ul>
	Insufficient pump discharge due to wear of vibrator pump drive shaft spline.	Replace vibrator pump.
	Vibrator circuit pressure is not held in vibrator pump case.	If pressure in vibrator pump case is not within allowable range, repair vibrator pump or replace it if necessary.

**3-3-3. Amplitude does not switch between high and low**

Check point	Cause	Check/Action
1. Vibrator Solenoid Valve	Vibrator solenoid valve spool shifts only in one direction.	Repair vibrator solenoid valve or replace it if necessary.



**3-3-4. Vibrator does not stop**

Check point	Cause	Check/Action
1. Vibrator Solenoid Valve	Vibrator solenoid valve spool does not return to neutral position.	Repair vibrator solenoid valve or replace it if necessary.
2. Vibrator Pump	Vibrator pump swash plate does not return to neutral position.	Repair vibrator pump or replace it if necessary.

**3-3-5. Vibrator system is overheating**

Check point	Cause	Check/Action
1. Oil Level of Hydraulic Oil Tank	Oil level in hydraulic oil tank is low.	Fill tank until correct oil level is obtained.
2. Oil Cooler	Cooling efficiency is reduced due to clogged oil cooler fins.	Clean oil cooler fins.
3. Vibrator Circuit Pressure	If circuit pressure setting is excessively low, relief valve opens, causing temperature of hydraulic oil in circuit to rise.	<ul style="list-style-type: none"> <li>• Measure vibrator circuit pressure.</li> <li>• If low, check and clean relief valve or replace it if necessary.</li> </ul>
	If load is excessively heavy, relief valve opens, causing temperature of hydraulic oil in circuit to rise.	<ul style="list-style-type: none"> <li>• Measure vibrator circuit pressure.</li> <li>• If high, decrease vibration load.</li> </ul>
4. Suction Filter for Steering • Charge Pump	Load of steering • charge pump increases due to clogged filter, causing temperature of hydraulic oil in circuit to rise.	Clean suction filter or replace it if necessary.
5. Hydraulic Oil Filter 1	Charge circuit pressure increases due to clogged filter.	Clean hydraulic oil filter 1 or replace it if necessary.

**3-3-6. Abnormal noise from vibrator system**

Check point	Cause	Check/Action
1. Vibrator Bearings	Vibrator bearings supporting eccentric shaft are damaged.	Replace vibrator bearings.
2. Hydraulic Hose Clamp	Vibrator sound of hydraulic hose is generated because clamp securing hydraulic hose is loose.	Tighten bolts of loose hydraulic hose clamp to specified torque.
3. Suction Filter for Steering • Charge Pump	Cavitation is occurring in steering • charge pump due to clogged filter.	Clean suction filter or replace it if necessary.
4. Vibrator Motor	Internal bearing of vibrator motor is damaged.	Repair vibrator motor or replace it if necessary.

### 3-4. Steering System

If a problem occurs in the steering systems such as the steering pump and orbitrol, determine the cause and carry out action as required, according to the following general troubleshooting items.

**(NOTICE)**

- When checking whether or not the pressure is correct, refer to the pressure standard value for each hydraulic circuit.

#### 3-4-1. Steering wheel is hard to turn

Check point	Cause	Check/Action
1. Oil Level of Hydraulic Oil Tank	Oil level in hydraulic oil tank is low.	Fill tank until correct oil level is obtained.
2. Orbitrol	Relief valve is open or setting pressure is low.	<ul style="list-style-type: none"> <li>• Measure steering circuit pressure.</li> <li>• If low, check and clean relief valve or replace it if necessary.</li> </ul>
	Flow to steering cylinder circuit is insufficient due to leakage from check valve.	Check and clean check valve or replace it if necessary.
	Spool and sleeve of orbitrol are contaminated or clearance is incorrect.	Check and clean orbitrol or replace it if necessary.
3. Steering Circuit Pressure	Pressure in return circuit from orbitrol increases due to clogged charging hydraulic oil filter 1.	Clean hydraulic oil filter 1 or replace it if necessary.
4. Steering Cylinder	Cylinder thrust decreases due to internal leakage of steering cylinder.	Repair steering cylinder or replace it if necessary.
5. Suction Filter for Steering • Charge Pump	Steering • charge pump discharge rate decreases due to clogged filter.	Clean suction filter or replace it if necessary.
6. Steering • Charge Pump	Discharging pressure is insufficient due to efficiency degradation of steering • charge pump.	<ul style="list-style-type: none"> <li>• Measure steering circuit pressure.</li> <li>• If low, replace steering • charge pump.</li> </ul>
7. Steering Column	Column shaft and orbitrol shaft center are misaligned.	Align column shaft with orbitrol shaft center or replace it if necessary.
	Column shaft bearing is worn or damaged.	Repair column shaft or replace it if necessary.

#### 3-4-2. Steering response is slow

Check point	Cause	Check/Action
1. Oil Level of Hydraulic Oil Tank	Oil level in hydraulic oil tank is low.	Fill tank until correct oil level is obtained.
2. Orbitrol	Oil is bypassing because relief valve is open.	<ul style="list-style-type: none"> <li>• Measure steering circuit pressure.</li> <li>• If low, check and clean relief valve or replace it if necessary.</li> </ul>
3. Steering Cylinder	Internal leakage of steering cylinder.	Repair steering cylinder or replace it if necessary.
4. Suction Filter for Steering • Charge Pump	Steering • charge pump discharge rate decreases due to clogged filter.	Clean suction filter or replace it if necessary.
5. Steering • Charge Pump	Discharging pressure is insufficient due to efficiency degradation of steering • charge pump.	<ul style="list-style-type: none"> <li>• Measure steering circuit pressure.</li> <li>• If low, replace steering • charge pump.</li> </ul>

**3-4-3. Steering wheel backlash or play is large**

Check point	Cause	Check/Action
1. Steering Column	Spline of column shaft or orbitrol is worn.	Replace column shaft or orbitrol.
	Column shaft bearings are worn.	Replace column shaft bearings.
2. Steering Wheel	Serration (spline) of wheel or column shaft is worn.	Replace wheel or column shaft.

**3-4-4. Steering system is overheating**

Check point	Cause	Check/Action
1. Oil Level of Hydraulic Oil Tank	Oil level in hydraulic oil tank is low.	Fill tank until correct oil level is obtained.
2. Oil Cooler	Cooling efficiency is reduced due to clogged oil cooler fins.	Clean oil cooler fins.
3. Steering Circuit Pressure	If circuit pressure setting is excessively low, relief valve is open, causing temperature of hydraulic oil in circuit to rise.	<ul style="list-style-type: none"> <li>• Measure steering circuit pressure.</li> <li>• If low, replace relief valve.</li> </ul>
	If load is excessively heavy, relief valve is open, causing temperature of hydraulic oil in circuit to rise.	<ul style="list-style-type: none"> <li>• Measure steering circuit pressure.</li> <li>• If high, decrease steering load.</li> </ul>
4. Suction Filter for Steering • Charge Pump	Load of steering pump increases due to clogged filter, causing temperature of hydraulic oil in circuit to rise.	Clean suction filter or replace it if necessary.

**3-4-5. Abnormal noise from steering system**

Check point	Cause	Check/Action
1. Oil Level of Hydraulic Oil Tank	Pump suction pressure is high because oil level of hydraulic oil tank is low, causing cavitation in steering circuit system.	Fill tank until correct oil level is obtained.
2. Steering Circuit	Cavitation is caused by air in circuit.	Bleed circuit.
3. Hydraulic Hose Clamp	Vibrator sound of hydraulic hose is generated because clamp securing hydraulic hose is loose.	Tighten bolts of loose hydraulic hose clamp to specified torque.
4. Suction Filter for Steering • Charge Pump	Cavitation is occurring in steering • charge pump due to clogged filter.	Clean suction filter or replace it if necessary.





**SV414**  
**SHOP MANUAL**

**SAKAI HEAVY INDUSTRIES, LTD.**

**Head office:** Seiwa Bldg., 4-8, Shibadaimon 1-chome,  
Minato-ku, Tokyo, Japan

**Telephone:** +81-3-3434-3401

**Global Service Division:** 2500 Takayanagi, Kuki-shi, Saitama, Japan

**Telephone:** +81-480-52-1111