




Read this handbook thoroughly and understand the whole information contained before attempt to operate, inspect and service your machine!

OPERATING & MAINTENANCE INSTRUCTIONS



MODEL

SV510-II Series

SV510D-II SV510TF-II

SV510T-II SV510TB-II

From VSV16 - 30143

SAKAI[®]

PREFACE

This Operation & Maintenance Instruction manual serves as a guide for the use of your SAKAI SV510-II Series Vibrating Roller for those who are new to the Machine, and also those who have experience using the Machine and want to refresh themselves.


Read this manual thoroughly and fully understand the information before attempting to operate, inspect, service and/or repair your machine. Keep this handbook accessible at any time when using the machine.

The main subjects of this manual are:

(1) Basic safety precautions, (2) Operation, (3) Daily maintenance and (4) Specifications.

For operation and maintenance of the engine, refer to the Engine Instruction Manual furnished separately.

Descriptions in this manual can differ from the instructions of your machine due to the result of investigation and improvement in its design and construction. If you have any inquiry regarding your Machine or this manual, contact the Sakai distributor in your area.



CONTENTS

PREFACE	
MACHINE AND ENGINE IDENTIFICATION NUMBERS	1
SAFETY NOTICES	2
1. BASIC PRECAUTIONS FOR SAFETY	4
1.1 General Precautions	4
1.2 Preparation for Safe Operation	6
1.3 Before Starting the Engine	7
1.4 After Starting the Engine	8
1.5 During operation.....	8
1.6 Loading and Unloading	10
1.7 Transportation	11
1.8 Handling the Battery.....	11
1.9 Towing.....	12
1.10 Before Servicing.....	13
1.11 During Servicing.....	14
1.12 Safety Decals	16
2. OPERATION.....	18
2.1 Instruments and Controls	18
2.1.1 Operator's station	18
2.1.2 Gauges, indicator lamps and warning lamps.....	19
2.1.3 Switches	21
2.1.4 Operating levers / pedals.....	24
2.1.5 Unloader valve.....	25
2.1.6 Fuse box.....	26
2.2 Handling and Adjustments	26
2.2.1 Seat adjustment.....	26
2.2.2 Scraper adjustment and replacement.....	26
2.2.3 Disengaging the brake when towing.....	28
2.3 Operation	29
2.3.1 Before-starting inspection	29
2.3.2 Starting the engine	30
2.3.3 After starting the engine	31
2.3.4 Traveling	32
2.3.5 Stopping / Parking	33
2.3.6 Stopping the engine.....	34
2.3.7 Check after stopping the engine.....	34
2.4 Vibratory Operation	35


2.5	Precautions for Work.....	37
2.5.1	Compaction operation	37
2.5.2	When going downhill	37
2.5.3	On a slope	37
2.6	Applicable Jobs	38
2.7	After Operation.....	39
2.8	Loading and Unloading	40
2.8.1	Use of a trailer equipped with a winch.....	40
2.8.2	Self-propelling.....	41
2.9	After Loading the Machine	42
2.10	Transportation	42
2.11	Operation in Cold Weather.....	42
2.11.1	Fuel oil and grease	42
2.11.2	Coolant	43
2.11.3	Battery	44
2.12	When the Cold Season is Over.....	45
2.13	For a Long Storage Period.....	45
2.14	During the Storage Period.....	45
2.15	When the Battery Has Discharged.....	46
2.15.1	Connection and disconnection of booster cables	46
3.	PERIODICAL MAINTENANCE.....	48
3.1	Precautions	48
3.1.1	Lifting the machine on a hoist.....	50
3.2	Walk-around Checking	51
3.3	Periodical Maintenance Points.....	52
3.4	Maintenance Procedure	54
(1)	Every 10 hours or daily.....	54
(2)	Every 50 hours	55
(3)	Every 250 hours	57
(4)	Every 500 hours	59
(5)	Every 1000 hours	60
(6)	As required	63
3.5	Capacities and Lubricants Specification.....	65
3.6	Electric Wiring Diagram.....	67
4.	SPECIFICATIONS	69

MACHINE AND ENGINE IDENTIFICATION NUMBERS

When ordering parts or making inquiries about your machine, the following information is requested:


(1) Machine model

Indicated on the dashboard in the operator's station.




(2) Machine serial number

SV510D-II	⇒	VSV16 - 30○○○
SV510T-II	⇒	VSV16 - 30○○○
SV510TF-II	⇒	VSV16 - 30○○○
SV510TB-II	⇒	VSV16 - 30○○○



(3) Engine serial number



⚠ WARNING: Negligence of these instructions can lead to accidents.

1. BASIC PRECAUTIONS FOR SAFETY

■ Do not use a machine which has not been serviced correctly at regular intervals.

- Before working, perform necessary inspections. Start operation only after making certain the machine is in good operating condition. If found to be abnormal, report to the responsible person and have the fault corrected. Operate the machine after making sure that it is safe to operate.


■ Do not allow anyone to enter the work area except for authorized personnel.

- Always conduct the work paying attention to the workers around the machine.



■ Be careful of hot parts.

- After your machine has operated for some time, the coolant, engine oil and hydraulic fluid will become hot and the pressure will build up. If, in this state, you try to remove the filler caps, drain the oil or replace the filters, you can get burned. Perform this work in accordance with the correct procedures with the machine cooled down.
- To remove the radiator cap, slowly loosen the cap to relieve the pressure with the engine shut down and the coolant cooled down. (For the radiator cap with a lever, lift the lever to release the trapped pressure.)
- When removing the filler cap on the hydraulic tank, release the trapped pressure by turning it out slowly to prevent the oil from gushing out.
- Do not touch the muffler while the engine is running or immediately after it has been shut down. You can get burned.




■ Be careful with fire.

- The fuel, oil, and anti-freeze will catch fire if open flames or ignition sources are used close to them. Particularly, the fuel is highly flammable.




- Do not smoke or use a match or cigarette lighter close to inflammables (combustibles).
- When refueling, stop the engine and do not smoke.
- The filler caps of the fuel and oil tanks must be kept tight.



⚠ **WARNING:** Negligence of these instructions can lead to accidents.

1. BASIC PRECAUTIONS FOR SAFETY

- Know the stopping distance.
 - When traveling on a road, bear in mind the stopping distance. Avoid excessive speed, and abrupt starting and stopping, and moving in a zigzag direction.



1.3 Before Starting the Engine


- **Adjust the operator's seat to your most effective operating position.**
 - Sit on the operator's seat. Adjust the seat so that your back will make contact with the seat back when the brake pedal is depressed to the full extent. Check to be sure that the brake pedal can be fully depressed without difficulty when you twist your body for reverse run.
- **Secure good visibility (with cabin)**
 - Keep the windowpane clean.
 - Lock the windows and doors no matter whether they are open or closed.
 - Do not leave the doors half-closed.
- **Secure forward and backward visibilities.**
 - Adjust the rear view mirrors and under mirrors for good visibility. If dirty, clean them. If damaged, replace.
- **Check that the horn, lamps and gauges work correctly.**
- **Before starting, make certain that each lever is in the neutral position and the parking brake is applied.**
- **When starting, sound the horn.**
 - Before starting the engine. Make sure there is no one in the immediate vicinity and there are no obstructions around the machine.



1. BASIC PRECAUTIONS FOR SAFETY

■ Pay attention to ventilation.

- Exhaust fumes are dangerous if breathed in. When starting the engine in an enclosed area, provide good ventilation with windows and doors opened.




■ Do not stand close to the exhaust gas pipe opening.

- Exhaust fumes can make you nauseous.

1.4 After Starting the Engine

■ Secure safety around the machine.

- Ensure that the area around the machine is clear of personnel and obstructions. Pay particular attention to dead spaces. Before starting, sound the horn.



■ Warm up the Engine

- Do not put your machine into motion immediately after the engine has started, let it idle for several minutes until it is at operating temperature.

■ Have a trial run.

- Make a test run in a safe place to check that there are no abnormal signs. If found to be abnormal, rectify the fault before traveling again.
- Listen for unusual sounds, and check for abnormal temperature rise. If abnormal, park the machine in a safe location and find the source of trouble before operating.

1.5 During Operation

■ No other person but the operator

- This machine is a one-man roller. Do not allow anyone to get on. Only the operator is allowed on this machine while it is running or in operation. Radios are not permitted.

■ Before mounting, be sure areas around the machine are safe.

- Before getting on the machine, make certain that there are no obstacles around the machine and no workers under it. If some workers are present or close to the machine, tell them that the machine is about to move, warning them to stay away from it.

⚠ WARNING: Negligence of these instructions can lead to accidents.


1. BASIC PRECAUTIONS FOR SAFETY

■ Do not try to get on or off a moving machine.

- Get on or off the machine after making sure it has come to a complete stop.

■ To go uphill or downhill, run at low speeds. Do not attempt to shift speeds while traveling on a grade.

- Shifting speeds on a slope can cause unexpected running down the slope.
- Going down hill at speeds other than low range can cause the machine to run down violently.




■ Refrain from inattentive driving.

- Inattentive driving or driving relying on guess work can cause an accident. Use extreme care for workers present in the path of the roller or around it. In case of danger, stop and sound the horn, and proceed when the area is clear of personnel or obstructions.

■ When changing the direction of travel, secure the safety on the path in the travel direction.

■ Keep everyone away from the pinch points.

- When making turns, do not allow anyone to come close to the pinch point.



■ At night, carefully drive the machine.


- Nighttime driving tends to frustrate the sense of distance. Carefully drive the machine at a speed suited to illumination. Keep the headlamps and flood lamps lighted. If necessary, provide extra lighting in the work area.

■ Repair as soon as possible if found to be defective.

- If the machine is found to be faulty, stop the machine and repair. Do not operate the machine until the problem is corrected. When any warning lamp indicates faulty operation, inspect the machine after moving it to the nearest safe location.


1. BASIC PRECAUTIONS FOR SAFETY

- Do not operate the machine except from the operator's seat. Do not drive in a standing posture.
- While making turns, do not run at abnormally high speed and do not turn the steering wheel abruptly and sharply.
- For the traveling on structures such as a bridge, make certain that they can support your machine. Before traveling on the structure, you must know the load capacity of the structure and the load weight of the machine you are operating to insure safe travel across the structure.
- Do not make turns on a slope and do not travel across sidehill. If necessary to do so, go down straight along the slope to the flat ground, move sideways and go up straight to the destination.




■ When parking.

- Select level and hard ground. If necessary to park on a slope, block the front of the drums on the downside of the slope.
- When required to park on the public road, provide necessary markings such as flag, barriers and illumination. However, be sure they do not obstruct traffic.
- When getting off the machine, stop the engine and remove the key from the ignition switch.



1.6 Loading and Unloading

- Loading and unloading can accompany any danger. Use extreme care.
- Select level and hard ground leaving a sufficient distance from the shoulder.
- Use sturdy ramps with proper width, length and thickness which allow safe loading and unloading. If they deflect considerably under load, apply wooden blocks to reinforce the ramps.



⚠ WARNING: Negligence of these instructions can lead to accidents.

1. BASIC PRECAUTIONS FOR SAFETY

- To prevent your machine from crosswise slippage, keep the ramps free from oil, mud, debris, etc. The drum must also be free from extraneous matter that can cause slippage.
- Do not steer your machine on the ramps. If the machine is facing in the wrong direction, allow it to dismount from the ramps, correct the direction and try again.
- Do not use kinked, twisted or damaged wireropes for crane or winch operation. Use ones with ample strength.
- When loading is complete, fix the machine with wooden blocks placed under the drums and chains fastened to the machine.


1.7 Transportation

- Follow required regulations.
- Select a transporting route according to the overall width, overall height and gross weight of the trailer with the roller loaded.

1.8 Handling the Battery

■ When handling the battery:

- Battery electrolyte contains sulphuric acid. It will destroy clothing and skin. If it touches your clothing or skin, flush with large quantities of water.
- In case of eye contact, flush with clean water and seek medical help.
- If swallowed, drink large amount of water, milk, beaten egg or vegetable oil, and get medical help.
- Wear safety goggles when handling the battery.
- Wear safety goggles, full face shield, rubber gloves and rubber apron when adding fluids to the battery.
- The battery generates flammable gases that can cause an explosion. Do not smoke close to the battery. Keep the battery away from flames, sparks and ignition sources.




⚠ WARNING

Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm.

Wash hand after handling.


1. BASIC PRECAUTIONS FOR SAFETY

- Inspect or handle the battery with the engine shut down and the starter key in the OFF position.
- Keep metallic items such as tools away from the battery terminals.
- Loose terminals can cause sparks leading to an explosion. Secure the terminals tightly.



■ Jump-starting the engine.

- Wear safety goggles when jump-starting the machine.
- When starting from another machine, do not allow the two machines to make contact with each other.
- When connecting the battery cables, start with the positive terminal. For disconnection, start with the negative one.
- Do not allow a tool to bridge between the positive terminal and machine body. This can generate dangerous sparks.
- Do not connect the booster cable to wrong terminal. NEVER connect the positive terminal to the negative.
- Final connection to the engine block of the disabled machine can cause sparks. The connecting point should be as far as possible from the battery.




1.9 Towing

- To tow the machine, use wire ropes with ample strength.
- Do not perform towing on a slope.
- Do not use towing ropes twisted, kinked or damaged.
- Do not stride towing cables.
- Keep everyone away from the space between the machine and the towing vehicle when connecting the two.
- Align the connecting portions of the machine and towing vehicle straight when coupling the machine.

1.10 Before Servicing


■ Attach warning tags when servicing the machine.

- Serious accidents can occur if the machine is unexpectedly started or controls carelessly touched by an unauthorized person.
- Attach a warning tag at a clearly visible location in the operator's station and insure the key has been removed from the ignition switch.



■ Use proper tools.

- It is very dangerous to use damaged or deteriorated tools or to use tools for other purposes than intended. Use correct tools for their intended use only.




■ Change safety-related parts at regular intervals.

- Replace fuel hose and high pressure hydraulic hoses regularly to prevent fire. Replace high pressure hoses of the power steering system every two years.
 - ☆ Change these parts at regular intervals even if found to be normal. They will deteriorate as time goes on.
 - ☆ Change any hose found to be abnormal even if it is within its recommended service interval.

■ Inspect or service your machine with the engine stopped.

- If required to keep the engine running in such a case as radiator interior cleaning, perform the work with two persons. One of them should sit on the operator's seat getting ready for shutting down the engine. He must take care not to touch any of controls carelessly. Maintenance personnel must exercise extreme caution not to make contact with moving parts.



1. BASIC PRECAUTIONS FOR SAFETY

■ Supplying fuel and oils


- Spilled fuel or oil will be slippery. Wipe up immediately. Keep the filler caps tight. Do not use fuel for flushing oil. Handle fuel and oil in a well ventilated area.

■ Check the coolant level in the radiator.

- To check the coolant level, shut down the engine and allow the engine and radiator to cool down.

■ Lighting

- For inspecting the level of the fuel oil, coolant and battery, use burn-proof lighting. Failure to use this type of lighting can result in an explosion.



1.11 During servicing

■ Keep unauthorized persons away

- During service, do not allow persons not concerned to enter the work area, particularly when grinding or welding operation is performed or heavy hammers are being used.




■ Keep your machine clean

- Spilled oil, grease or scattered debris are dangerous. Always keep your machine clean. Moisture that penetrates into the electrical system can cause malfunctions. Do not use water to clean sensors, connectors and the operator's station.

■ When repairing the electrical system

- For repairing the electrical system or for conducting welding, disconnect the negative cable from the battery to shut off the electricity.



■ Carefully handle high pressure hoses.

- Do not try to bend or hit hoses against a hard object. Do not use hoses or pipes that are bent or damaged. They will burst.
- Replace damaged fuel hose and hydraulic hoses. An oil or hydraulic fluid spill can cause a fire.

⚠ WARNING: Negligence of these instructions can lead to accidents.

1. BASIC PRECAUTIONS FOR SAFETY


■ Be careful of high pressure hydraulic fluid.

- Bear in mind that the hydraulic systems are under pressure, when engine is running or engine is shut down. Do not perform adding, draining, inspection or servicing of the hydraulic systems until the internal pressure has been relieved.

Hydraulic fluid leaking through a fine hole at high pressure can penetrate your skin and eyes.


Inspect leakage by holding piece of cardboard close to the suspected leaks wearing goggles (safety glasses).

If injected by high pressure oil, get medical help immediately.




■ Be careful of hot parts

- After the machine has been operated for some time, the coolant, engine oil and hydraulic fluid will become hot.
- Removing the radiator cap or draining the coolant or oil can burn you. Perform this work in accordance with correct procedures after the systems have cooled down.




■ Use care when inspecting or servicing the fan or belts when in motion

- Secure loose clothing and keep articles away that could get caught in moving parts.
- Do not let your body or tools make contact with the fan blades or belts. They can be cut seriously.




■ Used oil disposal

- Do not throw used oil into a drain or waterway. Drain the oil from the machine into a proper container. Do not drain directly on the ground.
- Obey all local, state and federal environment regulations for the proper disposal of oil, fuel, coolant, battery electrolyte or any other fluids.



■ Exercise extreme care when replacing and repairing tires


- Disassembly, repair and reassembly of tires require special facility and knowledge. Have them repaired at work shop specialized in handling tires.
- Improperly fitted rim can separate if the tire is inflated. When inflating tires, do not work in front of the rim. Use correct inflation pressure.
- When dismounting a tire, chock other tires for safety.
- When welding job is carried out near the tires, use extreme care, as this can cause an explosion of the tires.



2. OPERATION

2.1 Instruments and Controls

2.1.1 Operator's station




- | | | |
|---------------------------------|----------------------------------|---|
| ① Horn switch button | ⑦ Steering wheel | ⑬ Throttle lever |
| ② Combination meter | ⑧ Vibratiator switch | ⑭ Forward-reverse (F-R) lever
(For vibratiator switch) |
| ③ Parking brake switch | ⑨ Vibration selector switch | *⑮ Leveling blade lift lever |
| ④ Brake pedal | ⑩ Speed change switch | |
| ⑤ Starter switch | ⑪ Lamp switch (OPTION) | |
| ⑥ Turn signal lever
(OPTION) | ⑫ Rotary lamp switch
(OPTION) | |

NOTE: *For SV510TB-II only.

2.1.2 Gauges, indicator lamps and warning lamps


For safe execution of your job, fully understand the role and function of the systems involved.

Combination meter



Tachometer


Indicates the engine RPM. The hour meter shows total operating hours. The service interval recommendation in this manual should be based upon the hour meter readings.



Tachometer/Hour meter

Temperature gauge

Indicates the coolant temperature. Zone close to symbol H indicates overheating. In case of overheating, run the engine at idling for about ten minutes before shutting it down. Then determine the cause.




Temperature gauge

Fuel gauge

Indicates the fuel level in the tank.

E: The tank is empty.


F: The tank is full.








Fuel gauge

2. OPERATION

Monitor display



★ Indicator lamps [    ]

Light up when corresponding systems have been operated.

★ Warning lamps [  ]

Go on when the starter switch is turned to the ON position and go off when the engine has started. If any of these light up while the engine is running, this indicates a faulty condition. Stop the engine and trace the source of trouble.

★ Bulb failure check

= Warning lamps and parking brake indicator lamp =

They should go on when the starter switch is turned to the ON position.

If not, corresponding bulb has burnt out.

CAUTION:

Hydraulic oil filter warning lamp may go on when the engine rpm is increased before the engine has been warmed up enough. Keep the engine idling until the lamp goes off, before starting your work.

2.1.3 Switches

Starter switch


Starts and stops the engine.

HEAT: When the engine is cold, hold the starter switch in the HEAT position, the heater indicator lamp will go on. Stay in that position until the indicator lamp goes off. Release the switch key when the indicator lamp goes off. The key will automatically return to the OFF position. Turn the key to the START position to start the engine.

OFF: The key can be removed in this position. All the electric systems are switched off. To shut down the engine, move the key to this position.

ON: The charging circuit and lamp circuit are charged with electricity. Let the key stay in this position after the engine has started.


START: The engine is cranked and gets started. The moment the engine has started, release the key. It will automatically return to the ON position.





Lamp switch (OPTION)


Has three positions.

OFF: All lamps are switched off.

: Each gauge lamp and the headlamps become bright.

: In addition, the flood lamps become bright.

At this time, an icon  on monitor display will go on.




Turn signal lever (OPTION)

Turn signal lamp flashes when the turn signal lever is operated.

Left turn: Move the lever forward.

Right turn: Move the lever backward.



NOTE: The lever does not return to the OFF position even if the steering wheel is turned back.

2. OPERATION

Parking brake switch

If switch (P) is pressed down, the parking brake applies with the indicator lamp (P) on the monitor display lighted up.

When pressed again, the brake is released and the indicator lamp goes off.

⚠ WARNING


- To disengage the brake, be sure to press the button again instead of pulling it.
- When dismounting from the machine, press the button to apply the brake without fail.

⚠ CAUTION

- Never pull the switch UP.


IMPORTANT

- In an emergency, apply brake by pressing the parking brake switch button.



Horn switch button

Pressing the button at the center of the steering wheel makes the horn sound.




Rotary lamp switch (OPTION)

Press switch (L) to operate the rotary lamp mounted on top of the canopy. To turn off the rotary lamp, press the switch again.


⚠ CAUTION

- Never pull the switch UP.





Vibrator switch

By means of vibrator switch located on the panel to the right of operator seat, selection of vibration amplitude and On-Off is made.

 position: Turning the vibration switch clockwise causes the vibration to start with high amplitude.

OFF position: Vibration is shut down.

 position: Turning the vibrator switch counter clockwise causes vibration to start with low amplitude.






Vibrator switch


NOTE: For vibratory rolling, run the engine at 1,800 rpm or higher.

Vibration Selector Switch


Selection can be made between the vibrator switch installed to the forward-reverse lever and the other one located on the panel to the right of operator seat.

 position: Vibration can be turned ON or OFF with the switch located on the forward-reverse lever. Pressing this switch causes the vibration to start and pressing it again to stop. This vibrator switch on the lever should be used with the vibrator switch on the panel placed at  or  position.

CONT position: Have this switch placed at this position when vibration is not to be actuated.



Vibration selector switch



Vibrator switch



IMPORTANT


- Do not operate the vibrator on a hard area such as cement concrete pavement surface or the ground covered by thick steel sheets.
- Keep the vibrator stopped when the machine is at rest.
- Shut off the vibrator immediately when the machine has been caught in the mud during vibratory operation.

2. OPERATION

Speed change switch

Selects two vehicle speed ranges.


	 (Low)	 (High)
Speed	0~6 (0~3.7)	0~10 (0~6.2)
	km / h (mile / h)	



2.1.4 Operating levers / pedals

Forward reverse lever (F-R lever) with vibration switch

Moving the F-R lever forward or backward makes the machine travel forward or backward respectively. The neutral position brings the machine to a stop. The vehicle speed increases or decreases in proportion to the lever displacement.



Provided at the knob of the lever is the vibration switch for turning on or off the vibration.


IMPORTANT

- For normal braking, return the F-R lever back to neutral.
- In an emergency, depress the brake pedal or press the parking brake button.

Throttle lever

Shifts the engine RPM.

The engine RPM increases when moved toward the operator.



Brake pedal

In an emergency, push down on the pedal to the full extent, and the machine will come to a sudden stop.

NOTE: Depressing the brake pedal all the way causes reversible travel lever to return to neutral position (N) as well.

IMPORTANT

Do not use the pedal wherever practicable except for an emergency.

2.1.5 Unloader valve


The unloader valve disengages the drive, playing a role like a clutch. Use this valve for towing the machine when the engine is disabled or when troubles have developed in the hydraulic drive.

For towing:

Turn the knob counter-clockwise (Unload).

For normal traveling:

Turn the knob clockwise (Onload).

**⚠ WARNING**

- On a slope, chock the wheels and use extreme care when handling the unloader lever and towing the machine.
- Be sure to apply the parking brake when operating the unloader lever.

NOTE: For normal travel, be sure to hold the unloader in the ONLOAD position.


2. OPERATION

2.1.6 Fuse box

⚠ WARNING

When changing a fuse, cut the power supply by turning the starter switch to the OFF position.

Fuses protect electrical components and wiring from burning. Change any fuse which has become powder-coated due to deterioration or which has a play between it and fuse holder. To replace fuses, take off the cover. Be sure to use fuses of correct capacity.




2.2 Handling and Adjustments

2.2.1 Seat adjustment

Adjust the seat for your best operating position. Move the lever as shown by arrow. With the lever held in that position, slide the seat forward or backward as desired. When properly adjusted, release the lever.

Adjust your seat position to suit you as follows:

- 1) Pull the lever ① and adjust seat position longitudinally.
- 2) Turn the backrest adjust dial ② for optimum angle.
- 3) Move the suspension lever ③ to select suitable suspension for your body weight.




⚠ WARNING

The adjustment will be necessary when operating the machine first or when operators are alternated.

2.2.2 Scraper adjustment and replacement


SV510D-II

- 1) Clearance adjustment of scraper ①
 - a) Loosen bolts and nuts ② at 8 locations.
 - b) Provide a clearance of 20 mm (3/4 ") between scraper and the drum.
 - c) Retighten bolts and nuts ② at 8 locations.
- 2) Clearance adjustment of scraper ③
 - a) Loosen bolts and nuts ④ at 8 locations.
 - b) Provide a clearance of 20 mm (3/4 ") between scraper and the drum.
 - c) Retighten bolts and nuts ④ at 8 locations.



SV510T-II

- 1) Clearance adjustment of scraper ①
 - a) Loosen bolts and nuts ② (4 locations) and ④ (16 locations).
 - b) Provide a clearance of 20 mm (3/4 in) between scrapers and the drum.
 - c) Retighten bolts and nuts ② (4 locations) and ④ (16 locations).



- 2) Replacement of scrapers
(Front side: 9 pieces, rear side: 8 pieces)
 - a) Remove bolts and nuts ③ and ④.
 - b) Replace scrapers ① with new ones.
 - c) Provide a clearance of 20 mm (3/4 in) between scrapers and the drum.
 - d) Refit and retighten bolts and nuts ③ and ④.

2. OPERATION


2.2.3 Disengaging the brake when towing

⚠ WARNING

- On a slope, chock the drums and prepare for towing before disengaging the brake.
- Avoid a long-distance towing.


For towing the machine when the engine is disabled or when troubles have developed in the hydraulic system for propulsion, disengage the brake as instructed below:

- ① Release of brake: (on rear axle)
Loosen lock nut (B), then tighten bolts (2 on each side) alternately until resistance gets greater.
- ② After completion of towing, return bolts to original positions (until the distance between bolt head and reducer face becomes 34 mm [1 ¼ in.]).
Finally, lock the bolt (A) with the nut (B).



⚠ WARNING

- Do not try to release the brake immediately after a hot engine has been stopped. Let the oil cool down.
- For the brake disengagement, wear hard hat, safety goggles and safety gloves.



2.3 Operation

⚠ WARNING

- This machine is a one-man roller.
- Operate the machine from the operator's seat.

2.3.1 Before-starting inspection

(1) Check that the steering lock bar is in the carrying position.

⚠ WARNING


Make sure that the steering lock bar is connected in the carrying position before putting the machine in motion. Steering is impossible if the bar is in the steering lock position.

The bar is located at the left of the center of the machine.


To unlock the bar:

- ① Remove the spring pin.
- ② Pull out the lock pin.
- ③ Set the bar in the carrying position.

NOTE: Retain the lock bar in the locked position by inserting the lock pin into the lock holes. Fix the lock pin with the spring pin.



(2) Check that the F-R lever and is in the neutral position (N).



NOTE: The engine does not start if the F-R lever is not in the neutral position.


2. OPERATION

2.3.2 Starting the engine



⚠ WARNING

Check that the F-R lever is in the neutral position, and sound the horn when starting the engine after making certain that there are no one and no objects close to the machine.


- (1) Set the throttle lever in a position slightly higher than IDLING.




- (2) Turn the starter switch to the ON position and check that the warning lamps and parking brake indicator lamp on the monitor display are on.



- (3) For cold weather starting, turn the starter switch to the HEAT position to let the glow indicator become bright. Stay in this position till the glow indicator goes off. Then turn the switch to the START position



(4) Turning the key to the START position makes the engine start. Release the key the moment the engine has started. The key will automatically return to the ON position.



⚠ CAUTION

- Do not allow the starter key to stay in the START position for more than 15 seconds.
- If the engine does not start, allow an interval before trying again.
- Check that the warning lamps on the monitor display go off immediately after the engine is started. If any of these warning lamps becomes bright while the engine is running, shut down the machine, determine the cause and rectify the fault.

2.3.3 After starting the engine

Try not to move to operation immediately after starting but observe the following:

IMPORTANT

Avoid increasing the engine speed abruptly before warming-up run is completed.

- ① Run the engine at around 1,200 rpm for about 5 minutes to warm it up. Warming-up run allows the lubricating oil to reach the vital parts of the engine and hydraulic system, while gradually bringing up the engine oil and hydraulic oil to the working temperature.
- ② After the warm-up operation, check that:
 - Temperature gaugePointer falls near the center zone.
 - Fuel gaugePointer falls between the E and F marks
 - Charge lampHas gone off.
 - Engine oil pressure warning lampHas gone off.
- ③ Check for the color of exhaust gas, listen for unusual sounds and vibration. If abnormal, determine the cause and correct the problem.

2. OPERATION

2.3.4 Traveling



⚠ CAUTION

While travelling, do not turn the starter switch OFF.


⚠ WARNING

When starting, operate the horn after securing the safety around the machine.

(1) Select the desired speed by the speed change switch.

	 (Low)	 (High)
Speed	0~6 (0~3.7)	0~10 (0~6.2)


km / h (mile / h)




⚠ WARNING

On a steep slope, run the machine at low speed.


(2) Speed up the engine by pulling the throttle lever towards you.

(3) Press down the parking brake switch button to release the brake. Check that indicator lamp  on the monitor display goes off.



(4) Move the F-R lever in the direction to travel, and the machine will begin traveling.

CAUTION
Avoid abrupt operation of the F-R lever.



NOTE: The travel speed can be controlled by the throttle lever and F-R lever.

WARNING
Pay extreme attention to the area behind the machine when backing, since the space just behind it tends to be a blind spot.

2.3.5 Stopping / Parking


WARNING

- Avoid abrupt braking. Try to leave enough time for braking.
- Avoid parking on a grade.
- If necessary to park on a grade, block the wheel to prevent unexpected moving down the grade.


(1) Bring the F-R lever to the neutral position (N), and the machine will come to a halt.

CAUTION

- For normal braking, move the F-R lever back to the neutral position. In an emergency, depress the brake pedal.




(2) Press the parking switch button securely, and check that indicator lamp (P) illuminates.



2. OPERATION

2.3.6 Stopping the engine

- (1) Gradually cool down the engine at low idling for about 5 minutes.




IMPORTANT

- Do not bring a hot engine to a sudden stop except for an emergency. This will shorten the life of its component parts.
- Do not also allow an overheated engine to come to a sudden stop, but run it at middle idling speed for gradual cooling down.

- (2) Turn the starter key to the OFF position to stop the engine.

CAUTION

Do not turn the starter switch OFF while the machine is in motion.



- (3) Remove the starter key.

WARNING


- When dismantling from the machine, apply the brake by pressing the parking switch button. If necessary to park on a grade, block the wheels to prevent unexpected moving down the grade.
- Never forget to remove the starter key.

2.3.7 Check after stopping the engine


- 1) Perform the walk-around checks for oil and water leakage, abnormal signs around the drums.
- 2) Fill the fuel tank.
- 3) Remove waste paper if any from the engine compartment, as this will pose a possible fire hazard.
- 4) Scrape mud or other materials from and around the drums.

2.4 Vibratory Operation


(1) Run the engine at 1,800 rpm or higher by operating the throttle lever.




(2) Amplitude of vibration is selectable and turned on and off with the vibration switch (A) located on control panel to the right of operator seat.

 position: Turning the vibration switch clockwise causes the vibration to start with high amplitude.

OFF position: Vibration is shut down.




 position: Turning the vibration switch counter clockwise causes vibration to start with low amplitude.




Vibrator switch (A)

NOTE: For vibratory rolling, run the engine at 1,800 rpm or higher.


Also, by means of vibration selector switch (B), the selection can be made between the vibration switch (C) installed to the forward-reverse lever and the other one located on the panel to the right of operator seat.

 position: Vibration can be turned ON or OFF with the switch located on the forward-reverse lever. Pressing this switch causes the vibration to start and pressing it again to stop. This vibration switch on the lever should be used with the vibration switch on the panel placed at  or  position.



Vibration selector switch (B)

CONT position: Have this switch placed at this position when vibration is not to be actuated.



Vibration switch (C)

(3) Proper speed for vibratory compaction is 2 ~ 5 km/h (1.2 ~ 3 mph), however select speeds depending upon job requirement.

IMPORTANT


- Keep the vibrator shut off when the machine is not rolling.
- Stop vibration if the machine has encountered a running difficulty, for example, when it gets stuck in the mud.

2. OPERATION

Leveling blade lift lever (SV510TB-II)

Moves the blade vertically. The lever has 4 positions for "Lift", "Hold", "Lower" and "Float".

The lever has four positions; RAISE, HOLD, LOWER and FLOAT.



Raise: To raise the blade, pull the lever backward. The lever automatically returns to the Hold position when released.

Hold: When this position is selected, the blade stays in any position.

Lower: To lower the blade, push the lever forward. The lever automatically returns to the Hold position when released.

Float: Push the lever forward to its full extent. In this position, the blade becomes free to ride up and down over the ground, following the ground configuration as the machine travels. The lever stays in the Float position even if it is released.

2.5 Precautions for Work

2.5.1 Compaction operation

■ Do not operate the vibrator on hard location

- Do not work the vibrator on a hard surface such as concrete pavement, as this can cause the machine to jump and give abnormal shock load. Damage to shock isolators will result.

■ Change the direction of travel gently.

- When changing the direction of travel during asphalt mix compaction, slowly shift the F-R lever.

2.5.2 When going downhill

■ Use the F-R lever.

- Run slowly by the operation of the F-R lever even if the travel distance is short.

■ Use the engine brake

- Go downhill by applying the engine brake along with the F-R lever operation.

▲ WARNING

- When going uphill, run at low speed. Do not attempt to shift speeds during travelling. The machine can slip down the slope.
- When going downhill, adjust the travel speed not to allow the engine speed to exceed 2,500 rpm.

2.5.3 On a slope

■ Working on a sidehill

- Work in an uphill/downhill direction, and avoid working on sidehill with the machine inclining sideways.

2.6 Applicable Jobs

1) This machine is mainly used for:

- Static compacting work
- Vibratory compacting work

2) Road rollers do a variety of jobs as listed below.

This machine most effectively handles works or materials marked ☆.

Work

- Asphalt road paving
- Dust removal treatment for road
- ☆ Road improvement
- ☆ Embankment construction
- ☆ Dam construction
- Construction of forestry and farm roads
- Foundation building
- Construction of sidewalk, shoulder and gutter foundation

Material to be compacted

- Asphalt pavement
- ☆ Crusher run
- ☆ Cement concrete
- ☆ Sands
- ☆ Soils
- ☆ Slag
- ☆ Soft rock



Layers to be compacted

- Surface course, Binder course
- ☆ Base course
- ☆ Subgrade
- ☆ Embankment
- Shoulder
- Sidewalk

2.7 After Operation

Check for the coolant temperature, engine oil pressure and fuel level.

Follow the procedures below to prevent the machine from falling into an unworkable condition the following morning caused by muds and other extraneous matter on the drum, or frozen drums:

- 1) Remove muds and water from the machine. Muds can get into the seals together with water drops on the hydraulic cylinder piston rod. Damaged seals will result.
- 2) Park the machine on a hard and dry surface. If such a place is not available, cover the ground with hard plates.
- 3) Low temperature will cause a significant reduction of battery efficiency. Cover batteries or take them off from the machine and store in a warm place for the following day's operation.

2.8 Loading and Unloading

⚠ WARNING

- Use sturdy ramps with proper width, length and thickness which allow safe loading and unloading.
- If the ramps bend under considerably under the load, apply wooden blocks to reinforce them.
- Loading should be conducted on a level and hard ground. Leave a sufficient distance between the machine and the shoulder.
- To prevent slippage on the ramps, keep the drums free from mud, oils, etc. The ramps must also be free of grease, oil and ice.
- Do not steer the machine on the ramps. If the machine is facing in the wrong direction, allow it to dismount from the ramps and correct the direction.

For loading and unloading, use ramps or a proper loading stand.

2.8.1 Use of a trailer equipped with a winch

⚠ WARNING


Placing the unloader valve in UNLOAD position disrupts the power for traction. Do not enter the areas ahead of and behind the machine. It is very dangerous.

(1) Engage the trailer brake and chock its wheels. Fix the ramps so that the machine and trailer are completely aligned.


☆ The angle between the ramps and ground must be less than 15 degrees.

☆ Leave a proper space between the ramps according to the width of the roller drum.

(2) Decide the correct direction of run and make the machine run forward to the ramps.




- (3) Draw the wire rope from the trailer winch and put its hook on the hooking point ① or ② (One each on right and left) of the roller.
- (4) Place the unloader valve located at the operator's station to the UNLOAD position (See "Unloader valve" on page 25).
- (5) With the engine running at idle, perform loading by means of the trailer winch.
- (6) When the loading is completed, set the unloader lever back in the ONLOAD position.
- (7) Place the machine correctly on the trailer.



2.8.2 Self-propelling


- (1) Engage the trailer brake and chock its wheels. Fix the ramps so that the machine and trailer are completely aligned.
 - ☆ The angle between the ramps and ground must be less than 15 degrees.
 - ☆ Leave a proper space between the ramps according to the width of the roller drum.



- (2) Decide the correct direction of run and conduct loading or unloading at low speed.

For loading, run forward at low speed.

For unloading, run backward at low speed.



- (3) Place the machine correctly on the trailer.

2.9 After Loading the Machine

When the machine has been placed properly on the trailer, tie it down as follows:

- 1) Press the parking switch button to apply the parking brake. Place wooden blocks under the drums to prevent movement.
- 2) Fix the machine with ropes tied at the front and rear towing hook holes. Particularly, pay attention to sidewise skidding.

2.10 Transportation

WARNING

To decide the transporting route, check the width of the road, height and weight (including the roller) of the trailer.

For transportation, obey traffic regulations.

2.11 Operation in Cold Weather

In cold weather, take the following measures to prevent troubles such as starting difficulty and coolant freeze-up.

2.11.1 Fuel oil and grease

Use fuel and oil with low viscosity. See "Rating" on page 65.

2.11.2 Coolant

⚠ WARNING

Do not bring an open flame to the antifreeze or do not smoke when handling it. It is inflammable.

⚠ CAUTION

NEVER use methanol-, ethanol- and propanol-base antifreeze.

Use soft water for coolant.

In freezing weather, add antifreeze to the coolant referring to the table below. Select the most suitable mix ratio according to the lowest temperature in the job location.

Ambient temperature	-33°C (-27.4°F)	-26°C (-14.8°F)	-20°C (-4°F)	-16°C (3.2°F)	-11°C (12.2°F)
Amount of anti-freeze	11 ℓ (2.9gal)	10 ℓ (2.6gal)	9 ℓ (2.4gal)	8 ℓ (2.1gal)	7 ℓ (1.8gal)
Amount of coolant	11 ℓ (2.9gal)	12 ℓ (3.2gal)	13 ℓ (3.4gal)	14 ℓ (3.7gal)	15 ℓ (4.0gal)
Ratio	50%	45%	40%	35%	30%

IMPORTANT

Use of a high consistency antifreeze coolant in summer time can cause the engine to overheat depending upon job conditions. Use a coolant with the water-antifreeze ratio of 30.

2. OPERATION

2.11.3 Battery

⚠ WARNING

- Batteries generate explosive gases. Do not use an open flame close to batteries.
- The battery electrolyte is corrosive. Keep the electrolyte away from your eyes and skin. If you are affected by the electrolyte, flush with large quantities of water and get medical help.

At low temperature, batteries are less efficient. The level of charge is lowered and batteries will tend to freeze. Maintain batteries full charged wherever practicable, and give attention to heat insulation at night for the next day's operation.

For the level of charge, check the specific gravity of electrolyte and use the following table of conversion.

Level of charge (%)	Temperature			
	20°C (68°F)	0°C (32°F)	-10°C (14°F)	-20°C (-4°F)
100	1.28	1.29	1.30	1.31
90	1.26	1.27	1.28	1.29
80	1.24	1.25	1.26	1.27
75	1.23	1.24	1.25	1.26

2.12 When the Cold Season is Over

When winter is over and the warm season has come, proceed as follows:

- 1) Change oil and fuel with those for use in warm season referring to "Rating" on page 65.
- 2) If AF-PT antifreeze is in use, drain the coolant completely, wash clean inside the cooling system, and then fill with clean water (city water).

2.13 For a Long Storage Period

For leaving the machine unused for longer than one month, proceed as follows:

- 1) Store the machine in a closed area after cleaning.
- 2) Conduct oiling, greasing and changing of oil.
- 3) Grease lubricate the exposed portion of hydraulic cylinder piston rods.
- 4) Cover the battery after disconnecting the negative cable or take off the battery from the machine and store in a safe place.
- 5) If the temperature is expected to go down below 0°C (32°F), add antifreeze to the coolant.
- 6) With F-R lever placed at neutral position (N) and vibrator switch at OFF position, have the parking brake engaged.
- 7) Chock the machine.
- 8) Remove the starter switch key.

2.14 During the Storage Period

WARNING

If necessary to operate the machine for anti-corrosive purpose in closed area, ensure good ventilation keeping windows and doors open to prevent gas poisoning.


- During storage, operate the machine at least once a month to prevent the oil films on the lubricated parts from deteriorating and to charge the batteries.
- To prevent the brake linings from sticking to the brake drum, disengage the brake once a month. Exercise care not to allow the machine to move unexpectedly.

2.15 When the Battery Has Discharged


⚠ WARNING

- To check and handle the batteries, keep the engine stopped with the starter switch in the OFF position.
- The batteries give off explosive gases. Do not smoke close to the batteries. Keep flames and sparks away from the batteries.
- The electrolyte is very corrosive and will harm your clothing or skin. If the electrolyte has come into contact with your clothing or skin, flush with sufficient amount of water. In case the electrolyte has gotten into your eyes, flush with water and get medical help.
- To disconnect the battery cables, start with the negative terminal(ground). When connecting, start with the positive terminal . Do not allow a metallic item to bridge between the positive terminal and machine body. This can generate sparks, causing an explosion.
- Loose battery terminals can cause sparks. An explosion will result. When connecting the terminals, make certain that they are tight.

Disconnect with negative cable first



Connect with positive cable first




2.15.1 Connection and disconnection of booster cables

When jump-starting the engine, connect the booster cables as follows:


■ Connection of booster cables

- (1) Connect one end of the positive booster cable (A) to the positive (+) terminal of the battery on the machine.
- (2) Connect the other end of the positive booster cable to the positive (+) terminal of the booster supply.
- (3) Connect the negative booster cable (B) to the negative (—) terminal of the booster supply.
- (4) Connect the other end of the negative booster cable to a good ground of the engine block of the machine.




■ Disconnection of booster cables

- (1) Disconnect the negative booster cable (B) from the engine block ground.
- (2) Disconnect the negative booster cable (B) from the booster supply.
- (3) Disconnect the positive booster cable (A) from the booster supply.
- (4) Disconnect the positive booster cable (A) from the machine.



⚠ WARNING

- Do not allow the positive (+) terminal to make contact with the negative (-) terminal when connecting the booster cables.
- Wear safety goggles when jump-starting the engine.
- Do not allow the machine to make careless contact with the booster supply.
- Do not make wrong connections. Connect the negative (-) cable to the engine block ground far away from the battery, as sparks may occur when connecting.



⚠ CAUTION

- Use booster cables and end clips of proper size suited to the battery capacity.
- Use the batteries of the equal capacity for the machine and booster supply.
- Check booster cables and end clips for signs of damage and corrosion.
- Connect the clips positively.

3. PERIODICAL MAINTENANCE

3.1 Precautions

Whether or not the inspection service and lubrication are performed at the correct regular intervals exerts significant influence on the occurrence of trouble and service life of the machine. In this manual, typical intervals for inspection and service are given. However, flexibility should be introduced as to interval or type of services to enable your machine to always operate in the best condition.

General precautions:

- 1) Always use Sakai genuine parts for replacement.
- 2) Use lubricants recommended by Sakai. Avoid mixing different brand lubricants. Refer to the lubricant chart on 66.
- 3) For hydraulic oil replenishment, changing, level checking, filter cleaning or replacement, oiling and greasing, use extreme care to prevent dust from entering.
- 4) For checking oil level or changing oil, park the machine on a level and hard surface.
- 5) Change oil while its temperature remains high after operation.
- 6) For a long-term storage, fill the fuel tank, lubricate necessary points and run the machine for more than 20 minutes once a month.
- 7) In freezing weather, add antifreeze to the coolant according to the ambient temperature.
- 8) For the hydraulic pump and motor, have them serviced at authorized service shops.
- 9) Turn the starter switch OFF when performing services such as repairing broken wires, short circuits and tightening loose terminals.

Periodical Replacement of Essential Maintenance Parts

In order secure safety for work and travel, conduct inspection and services. Further, for enhanced safety, following parts and components should be replaced periodically. These parts are prone to material deterioration due to aging or physical change due to friction, while it is difficult to determine their useful limit by regular inspection, which makes it necessary to replace with new ones after certain period of service to maintain their perfect function.

If any abnormality is detected such as crack, deformation or oil leakage, go ahead and replace them even if it is within scheduled replacement time.

3. PERIODICAL MAINTENANCE

System or Mechanism	Part name	Periodical replacement maintenance parts	Replacement period	Remarks
1. Brake system	Master cylinder	Seals (rubber parts)	2 years	Adopted machines only
	Wheel cylinder	Seals (rubber parts)	2 years	∕
	Brake piping parts	Brake hose	2 years	
		Air hose	2 years	Adopted machines only
	Operating parts	Cable	4 years	∕
2. Steering system	Orbitrol (steering valve)	Seals (rubber parts)	2 years	
	Hydraulic piping parts	Hydraulic hose	2 years	
	Steering cylinder	Seals (rubber parts)	2 years	
	Hydraulic pump	Seals (rubber parts)	4 years	
3. Power transmission system (inclusive of axle)	Axle	Seals (rubber parts)	4 years	Adopted machines only
	Drive pump	Seals (rubber parts)	4 years	∕
	Drive motor	Seals (rubber parts)	4 years	∕
	Hydraulic piping parts	Hydraulic hose	4 years	∕
	Rubber isolator	Rubber isolator	4 years	∕
4. Fuel system	Piping parts	Fuel hose	4 years	
5. Engine related	Engine mounting parts	Rubber isolator	4 years	
	Seals (rubber parts)	Packing and others	4 years	
	Drive parts	V-belt	2 years	
6. Cooling system	Piping parts	Radiator hose	2 years	
7. Control related parts	Cable	Cable	4 years	Adopted machines only

⚠ CAUTION:


- With a new machine, change the engine oil and change the engine oil filter elements after 50 hours of operation for the first time only. (Refer to page 58)
- When trouble occurs in the location indicated by the indicator lamp on the monitor display, sensor will work and corresponding lamp comes on. If this occurs, conduct necessary service regardless of the periodical service interval recommendation.
 - 1) The hydraulic filter (line filter) warning lamp ⇨ Replace elements
- Check the electric wiring at a regular interval not exceeding one month:
 - 1) Damage to the wire harness and loose clamps
 - 2) Loose connections
 - 3) Function of electrical systems

3. PERIODICAL MAINTENANCE

3.1.1 Lifting the machine on a hoist

⚠ WARNING


- Get a qualified personnel to lift and lower the machine on a hoist.
- Use sturdy wire ropes.
- Lock articulation by means of lock bar located at the center of machine.



⚠ CAUTION


To do the lifting and lowering work, fold the awning.

- (1) Put wire ropes securely on the hook and lifting points as shown.
- (2) If wire ropes make contact with other parts of the machine, put pieces of cloth or wooden blocks at the contact points. Carefully perform lifting.
- (3) When lifting, keep the machine properly ballanced.




3.2 Walk-around Checking

For efficient operation, daily, before-operation checking is very important. Before starting, perform walk-around checking for loose bolts, nuts and signs of leakage in addition to items as shown below:



3.3 Periodical Maintenance Points



3. PERIODICAL MAINTENANCE

Interval	Sym- bol	Description	Inspection and service	Lubricant	Q'ty
Every 10 hours or daily	⑩⑥	Radiator	Check coolant level, add as necessary	Coolant	1
	⑩⑦	Fan belt	Check tension and adjust		
	⑩⑧	Engine oil level gauge	Check oil level, add as necessary	Engine oil	1
Every 50 hours	①	Hydraulic oil level gauge	Check oil level, add as necessary	Hydraulic oil	1
	⑤	Fuel sedimenter	Check and remove water and sediment		1
	⑧	Air cleaner	Check indicator		1
	⑪	Battery	Maintenance free battery Check connections		
	⑭	Brake	Check function, adjust as necessary		1
Every 250 hours	⑨	Tire	Check condition and air pressure		2
	⑩	Engine oil filter	Change element		1
	⑫	Rubber isolators	Check condition		10
	⑬	Vibrator	Check oil level	Gear oil	1
	⑭	Brake links	Apply grease	Grease	2
	⑳	Center pin and tilt pin bearing	Apply grease	Grease	4
	㉑	Steering cylinder	Apply grease	Grease	4
	㉒	Transmission	Check oil level, add as necessary	Gear oil	1
	㉔	Engine oil pan	Change oil	Engine oil	1
	㉖	Cylinder anchor pin and Push rod anchor pin	Apply grease	Grease	4
Every 500 hours	④	Fuel filter	Change element		1
	⑥	Hydraulic oil return filter	Change element		1
	⑦	Hydraulic oil line filter	Change element		1
	⑮	Control link	Check looseness and adjust		1
Every 1000 hours	②	Hydraulic oil suction filter	Clean element		1
	③	Hydraulic oil tank	Change oil	Hydraulic oil	1
	⑬	Vibrator	Change oil	Gear oil	1
	⑲	Gear case : Wheel motor	Change oil	Gear oil	1
	㉒	Transmission	Change oil	Gear oil	1
	㉓	Final drive/ Differential case	Change oil	Gear oil	1
As required	⑧	Air cleaner	Clean or change element		1
	㉕	Fuel tank	Clean interior		1

* SV510TB-II

3. PERIODICAL MAINTENANCE

3.4 Maintenance Procedure

➔ For servicing the engine, see the separate engine manual.


(1) Every 10 hours or daily

⑩ Radiator

Check to see coolant in sub-tank is up to level mark and replenish with water. Use soft water only.


⚠ CAUTION

- With radiator cap removed, feed water nearly up to filler port, then replenish the sub-tank as well.
- If level is below LOW mark, remove sub-tank cover and replenish with fresh water up to FULL mark.




⚠ WARNING

Do not remove the radiator cap while the coolant is hot.




⑪ Fan belt

- (1) Check the fan belt for wear and damage. Replace as necessary.
- (2) Check the tension. Depress the middle of belt with a push of approx. 10 kg (22 lb.) A properly adjusted belt deflects 10 ~ 15 mm (0.4" ~ 0.6").
- (3) To adjust, loosen alternator bracket bolt (A) and plate bolt (B), and slide the alternator.



⑱ Engine oil level gauge


Shut down the engine and check the engine oil level. If it is not between MAX and MIN marks, add oil through the fill hole.



(2) Every 50 hours



① Hydraulic oil level gauge

Check the oil level with the sight glass on the side of tank. The level is proper if it is between H and L marks. Of necessary, add the hydraulic fluid from the fill port.



⑤ Fuel sedimenter


Check the float level. If it comes up to the warning mark, take off the plug at the bottom and drain water.



3. PERIODICAL MAINTENANCE

⑧ Air cleaner

When the red float of the dust indicator reaches the service level (a mark on the indicator), clean the element (see page 63).



⑪ Battery

(1) The batteries are maintenance free type.

You do not have to check the battery electrolyte level or add distilled water as you would do with a conventional type battery.

(2) Retighten any loose terminals. Apply grease or vaseline to the terminals to retard rusting.


⑭ Brake

(1) Disengage the brake referring to the procedure on page 28.

(2) Loosen the lock nuts (B). Then, using a wrench, tighten the bolts (A) in an alternate sequence by 1/4 turn at a time so as to disengage the braking disk.

(3) After towing is completed, remove bolts (A) completely with nuts (B) and seals (C). Then, replace seals (C), apply silicon based Teco Luqu /101 grease to the bolts (A) and install all parts again.


(4) Adjust bolts (A) to obtain a jut of 34 mm (1 1/4 in.) then, lock into position with nuts (B).



(3) Every 250 hours



⑫ Rubber Isolators

Check the rubber blocks for cracks, and their mounting bolts for looseness.




⑬ Vibrator

Check for the oil level and leakage.



⑭ Brake links

Apply grease to the brake link bracket.



3. PERIODICAL MAINTENANCE

⑩ Engine oil filter

⑳ Engine oil pan

➔ See the separate engine manual.



(1) After completion of operation and while the oil is warm, drain the oil with the drain plug (A) removed.

⚠ WARNING


When draining a hot oil, use care not to get burned.

(2) Refit the drain plug (A) and fill the crankcase with the engine oil from the fill hole (B).

(3) Change the oil filter (C).




NOTE: For a new machine, change oil at 50 operating hours for the initial time only.




㉑ Center pin and tilt pin bearings

Apply grease at 4 locations.




㉒ Steering cylinder

Apply grease at 4 locations.



② Transmission

Check for oil level, and add oil through the fill port as necessary.



(4) Every 500 hours


④ Fuel filter

➔ See the separate engine manual.
Change the filter cartridge.

⑥ Hydraulic oil return filter


⑦ Hydraulic oil line filter

Change the elements.



⑮ Control link

- 1) Check the nuts for looseness. Adjust the rod.
- 2) Apply grease to F-R lever shaft.



3. PERIODICAL MAINTENANCE


(5) Every 1,000 hours

② Hydraulic oil suction filter

Take off the hydraulic tank cover. Take out and clean the strainer, change the strainer if necessary.

③ Hydraulic oil tank

- (1) Remove the drain plug, and drain oil while it is warm.
- (2) Clean inside of the tank, and fill fresh oil to the specified level.
- (3) Start and run the engine at idling for 2 to 5 minutes. When the hydraulic oil has become free from air bubbles, stop the engine and recheck the oil level.





⚠ WARNING

When draining a hot oil, use care not to get burned.

⑬ Vibrator

- (1) Rotate the drum till the drain plug comes to bottom.
- (2) Remove drain plug, level gauge plug and filler plug.
- (3) Drain oil from vibrator.
- (4) Clean the vibrator before reinstalling it.
- (5) Feed oil at filler port until oil flows out of level gauge hole.
- (6) Reinstall the level gauge plug as well as filler plug after cleaning them.



⚠ WARNING


When draining a hot oil, use care not to get burned.

⚠ CAUTION

The oil capacity of the vibrator is 44 liters each. Do not fill more than 44 liters.


①9 Gear case / Wheel motor

- (1) Position the drum so that the drain plug comes to the bottom.
- (2) Remove the drain plug and drain the oil while it is warm.
- (3) Rotate the drum so that a drain hole may come to top. Reinstall the drain plug and fill the oil through the fill hole until it overflows at the level hole.
- (4) Reinstall the level plug and drain plug.



②2 Transmission


- (1) Drain the gear reducer oil by removing the drain plug.
- (2) Reinstall the drain plug.
- (3) Remove the level plug and fill port plug.
- (4) Fill oil through the fill port until oil starts overflowing from the level port.
- (5) Reinstall the level plug and fill port plug.



3. PERIODICAL MAINTENANCE


23 Final drive

- (1) Rotate the wheel till the drain port is located at the lowest position. Remove plug to drain oil.
- (2) At the final drive, adjust the position of plug until it is parallel to the ground.
- (3) Fill oil through the fill port till oil overflows from the level port.
- (4) When the final drive case is filled to the specified level, reinstall the removed plugs.



23 Differential case

- (1) Drain oil by removing the drain plug and fill port plug.
- (2) Reinstall the drain plug.
- (3) Fill oil through the fill port till it overflows from the fill port.
- (4) Reinstall the removed plugs.



(6) As required

⑧ Air cleaner


When the red float of the dust indicator reaches the service level (a mark on the indicator), clean the element as described below:

- (1) Remove the butterfly nut and pull out the element.
- (2) Blow compressed air from inside of the element.

⚠ WARNING

Exercise caution not to get dust in your eyes.

- (3) Check the element for any damage and replace as necessary, before pushing the dust indicator reset button.
- (4) Reinstall the element and tighten with butterfly nut.



NOTE: In normal use, change the Inner element once in every six cleanings of the outer element.

⚠ CAUTION


Replace the element when the red float reaches the service level even if it is cleaned.

3. PERIODICAL MAINTENANCE

25 Fuel tank

- (1) With the drain plug removed, remove the water and sediment from the bottom of the tank.
- (2) If sedimentation is substantial, clean the interior of the tank.
- (3) When the necessary work and refueling are complete, firmly tighten the filler cap.

NOTE: When removing the water and sediment from the tank filled with the fuel, the fuel will gush out if the drain plug is screwed out completely.



⚠ WARNING

- The fuel will catch fire if open flames or ignition sources are used close to it.
- Do not smoke or use a match or cigarette lighter close to it.



3.5 Capacities and Lubricants Specification

1. General rules

- 1) Never feed water or lubricant with the strainer removed.
- 2) Use recommended lubricant and hydraulic fluid.
- 3) Do not use lubricants and hydraulic fluid of different brands.
- 4) When replacing oil, drain it completely and clean the container with flushing oil before filling new oil.

2. Capacity

Compartment	Type of fluid	Capacity in liters (gal.)
Fuel tankDiesel	oil	250 (66.0)
Engine oil pan	Engine oil	13 (3.4)
Hydraulic tank	Hydraulic oil	50 (13.2)
Wheel motor	Gear oil	3.9 (1.0)
Radiator	Coolant	22 (5.8)
Vibrator	Gear oil	40 (10.6)
Transmission	Gear oil	2.0 (0.5)
Differential	Gear oil	9.5 (2.5)
Final drives	Gear oil	1.75 x 2(0.5x 2)

3. Rating

Lubricant	Service classification	Ambient temp. and applicable viscosity rating			Applicable standards
		-15 ~ 30°C (5 ~ 86°F) Cold	0 ~ 40°C (32 ~ 104°F) Moderate	15 ~ 55°C (59 ~ 131°F) Tropical	
Engine oil	API grade CD	SAE 10W-30	SAE 30	SAE 40	MIL-L-2104B
Gear oil	API grade GL4	SAE 80W-90	SAE 90	SAE 140	MIL-L-2105
Hydraulic oil	Anti wear	ISO-VG32 over VI 140	ISO-VG46 over VI 140	ISO-VG68 over VI 110	ISO-3448
Grease	Lithium type extreme pressure				NLGI-2
Fuel	Diesel oil				ASTM D975-2D

3. PERIODICAL MAINTENANCE

4. Recommended lubricants


Lubricant Oil company	Engine oil API – CC	Gear oil API GL 4	Hydraulic oil VG 46	Grease (NLGI – II)
CALTEX	RPM DELO 300 oil	Universal Thuban 90	Rando Oil HD 46	Martifack EP 2
BP	BP Vanellus C3-30	BP Gear Oil EP 90	BP Energol HLP 46	BP Energrease LS – EP 2
ESSO	Esso Lube D3-30	Esso Gear Oil GP 90	Nuto H 46	Beacon EP 2
MOBIL	Mobil Delvac 1330	Mobil Pegasus Gear Oil 90	Nuto Oil 25	Beacon EP 25
SHELL	Shell Rotella CT Oil 30	Shell Spirax 90 EP	Shell Tellus Oil 46	Shell Alvania EP Grease 2
CASTROL	Castrol CRD 30	Castrol Hypoy 90	Hyspin AWS 46	Spherrol ELP 2

- CAUTION:** (1) Fill the fluid reservoirs with the filters installed.
 (2) Use recommended fuels and lubricants only.

3. PERIODICAL MAINTENANCE

Fuse box


The fuse box houses five 15A-fuses, three 20A-fuses and two 30A-fuses lined up with spares fitted for 15A, 20A- and 30A-fuses. Use fuses of correct capacity. See page 26.



NOTE: When a fuse is burned, determine the cause before replacing.


Battery

- ★ Leaving the battery unused for long without attention or using its power excessively at a time can cause damage to the plates, leading to a shortened life.
- ★ For long-term storage, charge it fully, tighten the caps securely, store in a cool and dry place, and check the level of charge at least once a month.
- ★ Maintain the level of charge above 75%.
- ★ In cold weather, it is desirable to start the engine with the battery charged 100%. Do not try to start the engine with less than 75%.



4. SPECIFICATIONS

(1) SV510D-II




MODEL	SV510D-II	
WEIGHTS (with ROPS)		
Operating Weight	24,140 lbs	(10,950 kg)
Load on front	12,830 lbs	(5,820 kg)
Load on rear	11,310 lbs	(5,130 kg)
DIMENSIONS		
Overall Length	226 in.	(5,740 mm)
Overall Width	91 in.	(2,300 mm)
Overall Height	83 in.	(2,105 mm)
with ROPS	113 in.	(2,870 mm)
Wheelbase	117 in.	(2,970 mm)
Ground Clearance	17.0 in.	(435 mm)
Curb Clearance	17.5 in.	(445 mm)
Drum Width	84 in.	(2,130 mm)
Drum Diameter	60 in.	(1,530 mm)
Pad Height	---	
No. of Pads	---	
Tire Size	23.1-26-8PR (OR) Diamond tread	
SPEEDS (Forward & Reverse)		
1st	0 ~ 3.7 mph	(0 ~ 6 km/h)
2nd	0 ~ 6.2 mph	(0 ~ 10 km/h)
VIBRATING POWER		
Amplitude	Low 0.04 in. (0.90 mm)	High 0.08 in. (2.00 mm)
Frequency	2,200 VPM (36.7 Hz)	1,650 VPM (27.5 Hz)
Centrifugal Force	38,580 lbs (17,500 kgf)	50,710 lbs (23,000 kgf)

GRADABILITY (Theoretical)	62%	(32°)
MIN. TURN RADIUS	221 in.	(5.6 m)
ENGINE	Isuzu BB-6BG1T with turbocharger	
Type	Water-cooled, 4-cycle, 6-cylinder	
Displacement	396 cu. in.	(6.494 liter)
Rated Output @2,000 rpm	138 HP	(103 kW)
Max. Torque @1,600 rpm	380 ft-lb	(515 N-m)
Electrical System	24 V	
Battery	24V (12V-100Ah x 2)	
Alternator	24 V - 50 amps	
POWER LINE		
Transmission	Hydrostatic transmission	
Differential	Auto lock type	
Final Drive	Planetary gear	
VIBRATING SYSTEM		
Transmission	Hydrostatic transmission	
Vibrator	Eccentric shaft type	
BRAKE SYSTEM		
Service Brake	Hydrostatic dynamic brake through drive system	
Secondary (parking & auto)	Spring-applied, hydraulically released type (SAHR)	
Emergency Pedal Brake	Hydrostatic + SAHR	
STEERING SYSTEM	Hydraulic type (articulated type)	
FLUID CAPACITY		
Fuel Tank	66 gal	(250 liter)
Hydraulic Tank	13 gal	(50 liter)

*The above specifications may be changed without notice.

4. SPECIFICATIONS

(2) SV510T-II




MODEL	SV510T-II	
WEIGHTS (with ROPS)		
Operating Weight	24,960 lbs	(11,320 kg)
Load on front	13,630 lbs	(6,180 kg)
Load on rear	11,330 lbs	(5,140 kg)
DIMENSIONS		
Overall Length	227 in.	(5,760 mm)
Overall Width	91 in.	(2,300 mm)
Overall Height	84 in.	(2,125 mm)
with ROPS	114 in.	(2,890 mm)
Wheelbase	117 in.	(2,970 mm)
Ground Clearance	17.5 in.	(450 mm)
Curb Clearance	18.5 in.	(465 mm)
Drum Width	84 in.	(2,130 mm)
Drum Diameter	63 in.	(1,600 mm)
Pad Height	4.0 in.	(100 mm)
No. of Pads	140 pcs.	
Tire Size	23.1-26-8PR (OR) Lug tread	
SPEEDS (Forward & Reverse)		
1st	0 ~ 3.7 mph	(0 ~ 6 km/h)
2nd	0 ~ 6.2 mph	(0 ~ 10 km/h)
VIBRATING POWER	Low	High
Amplitude	0.04 in. (0.90 mm)	0.08 in. (2.00 mm)
Frequency	2,200 VPM (36.7 Hz)	1,650 VPM (27.5 Hz)
Centrifugal Force	41,890 lbs (19,000 kgf)	55,120 lbs (25,000 kgf)

GRADABILITY (Theoretical)	62%	(32°)
MIN. TURN RADIUS	221 in.	(5.6 m)
ENGINE	Isuzu BB-6BG1T with turbocharger	
Type	Water-cooled, 4-cycle, 6-cylinder	
Displacement	396 cu. in.	(6,494 liter)
Rated Output @2,000 rpm	138 HP	(103 kW)
Max. Torque @1,600 rpm	380 ft-lb	(515 N-m)
Electrical System	24 V	
Battery	24V (12V-100Ah x 2)	
Alternator	24 V - 50 amps	
POWER LINE	Hydrostatic transmission	
Transmission	Auto lock type	
Differential	Planetary gear	
Final Drive		
VIBRATING SYSTEM	Hydrostatic transmission	
Transmission	Eccentric shaft type	
Vibrator		
BRAKE SYSTEM	Hydrostatic dynamic brake	
Service Brake	through drive system	
Secondary (parking & auto)	Spring-applied, hydraulically released type (SAHR)	
Emergency Pedal Brake	Hydrostatic + SAHR	
STEERING SYSTEM	Hydraulic type (articulated type)	
FLUID CAPACITY		
Fuel Tank	66 gal	(250 liter)
Hydraulic Tank	13 gal	(50 liter)

*The above specifications may be changed without notice.

(3) SV510TF-II




MODEL	SV510TF-II	
WEIGHTS (with ROPS)		
Operating Weight	29,875 lbs	(13,550 kg)
Load on front	18,610 lbs	(8,440 kg)
Load on rear	11,265 lbs	(5,110 kg)
DIMENSIONS		
Overall Length	226 in.	(5,750 mm)
Overall Width	91 in.	(2,300 mm)
Overall Height	84 in.	(2,135 mm)
with ROPS	114 in.	(2,900 mm)
Wheelbase	117 in.	(2,970 mm)
Ground Clearance	18.5 in.	(465 mm)
Curb Clearance	19.0 in.	(485 mm)
Drum Width	84 in.	(2,130 mm)
Drum Diameter (*)	65 in.	(1,650 mm)
* Refer SV510TB-II drum specifications when used as padfoot roller (without smooth shells).		
Tire Size	23.1-26-8PR (OR) Lug tread	
SPEEDS (Forward & Reverse)		
1st	0 ~ 3.7 mph	(0 ~ 6 km/h)
2nd	0 ~ 6.2 mph	(0 ~ 10 km/h)
VIBRATING POWER	Low	High
Amplitude	0.04 in. (0.90 mm)	0.08 in. (2.00 mm)
Frequency	2,200 VPM (36.7 Hz)	1,650 VPM (27.5 Hz)
Centrifugal force	41,890 lbs (19,000 kgf)	55,120 lbs (25,000 kgf)

<i>Note: Refer SV510T-II specifications when used as padfoot roller.</i>	
GRADABILITY (Theoretical)	50% (27°)
MIN. TURN RADIUS	221 in. (5.6 m)
ENGINE	Isuzu BB-6BG1T with turbocharger
Type	Water-cooled, 4-cycle, 6-cylinder
Displacement	396 cu. in. (6.494 liter)
Rated Output @2,000 rpm	138 HP (103 kW)
Max. Torque @1,600 rpm	380 ft-lb (515 N-m)
Electrical System	24 V
Battery	24V (12V-100Ah x 2)
Alternator	24 V - 50 amps
POWER LINE	
Transmission	Hydrostatic transmission
Differential	Auto lock type
Final Drive	Planetary gear
VIBRATING SYSTEM	
Transmission	Hydrostatic transmission
Vibrator	Eccentric shaft type
BRAKE SYSTEM	
Service brake	Hydrostatic dynamic brake through drive system
Secondary (parking & auto)	Spring-applied, hydraulically released type (SAHR)
Emergency pedal brake	Hydrostatic + SAHR
STEERING SYSTEM	Hydraulic type (articulated type)
FLUID CAPACITY	
Fuel tank	66 gal (250 liter)
Hydraulic tank	13 gal (50 liter)

*The above specifications may be changed without notice.

4. SPECIFICATIONS

(4) SV510TB-II



MODEL	SV510TB-II	
WEIGHTS (with ROPS)		
Operating Weight	26,015 lbs	(11,800 kg)
Load on front	14,880 lbs	(6,750 kg)
Load on rear	11,135 lbs	(5,050 kg)
DIMENSIONS		
Overall Length w/ blade	244 in.	(6,185 mm)
Overall Length w/o blade	227 in.	(5,760 mm)
Overall Width w/ blade	110 in.	(2,800 mm)
Overall Width w/o blade	91 in.	(2,300 mm)
Overall Height with ROPS	114 in.	(2,890 mm)
Wheelbase	117 in.	(2,970 mm)
Curb Clearance	18.5 in.	(465 mm)
Drum Width	84 in.	(2,130 mm)
Drum Diameter	63 in.	(1,600 mm)
Pad Height	4.0 in.	(100 mm)
No. of Pads	140 pcs.	
Tire Size	23.1-26-8PR (OR) Lug tread	
SPEEDS (Forward & Reverse)		
1st	0 ~ 3.7 mph	(0 ~ 6 km/h)
2nd	0 ~ 6.2 mph	(0 ~ 10 km/h)
VIBRATING POWER	Low	High
Amplitude	0.04 in. (0.90 mm)	0.08 in. (2.00 mm)
Frequency	2,200 VPM (36.7 Hz)	1,650 VPM (27.5 Hz)
Centrifugal Force	41,890 lbs (19,000 kgf)	55,120 lbs (25,000 kgf)

Leveling Blade Width	110 in.	(2,800 mm)
GRADABILITY (Theoretical)	62%	(32°)
MIN. TURN RADIUS	221 in.	(5.6 m)
ENGINE	Isuzu BB-6BG1T with turbocharger	
Type	Water-cooled, 4-cycle, 6-cylinder	
Displacement	396 cu. in.	(6,494 liter)
Rated Output @2,000 rpm	138 HP	(103 kW)
Max. Torque @1,600 rpm	380 ft-lb	(515 N-m)
Electrical System	24 V	
Battery	24V (12V-100Ah x 2)	
Alternator	24 V - 50 amps	
POWER LINE		
Transmission	Hydrostatic transmission	
Differential	Auto lock type	
Final Drive	Planetary gear	
VIBRATING SYSTEM		
Transmission	Hydrostatic transmission	
Vibrator	Eccentric shaft type	
BRAKE SYSTEM		
Service Brake	Hydrostatic dynamic brake through drive system	
Secondary (parking & auto)	Spring-applied, hydraulically released type (SAHR)	
Emergency Pedal Brake	Hydrostatic + SAHR	
STEERING SYSTEM	Hydraulic type (articulated type)	
FLUID CAPACITY		
Fuel Tank	66 gal	(250 liter)
Hydraulic Tank	13 gal	(50 liter)

*The above specifications may be changed without notice.

SAKAI AMERICA, INC.

SAKAI AMERICA MANUFACTURING, INC.

(subsidiaries of SAKAI HEAVY INDUSTRIES, LTD. - Tokyo, Japan)

90 International Parkway, Adairsville, Georgia 30103, U.S.A.

Tel: 770-877-9433

Fax: 770-877-9886

Website: www.sakaiamerica.com

www.sakainet.co.jp

Printed in USA

SAKAI®