

SW800/850 Series

SHOP MANUAL

SAKAI®

PREFACE

To make a machine working to maximum efficiency over a long period of time without any machine troubles, correct OPERATION, PREVENTIVE MAINTENANCE, TROUBLE-SHOOTING and REPAIR are of vital importance.

This shop manual provides instructions, for the most part, on GENERAL INFORMATION, STRUCTURE/FUNCTION, CHECKING/ADJUSTMENT, and TROUBLE-SHOOTING of the SAKAI SW800/850 Series Vibrating Rollers.

This manual is designed to serve as a guide for the operator and maintenance personnel to acquire correct information and repair procedure on these machines in order to give a correct decision on problems which the machines will confront, thus leading to quality repair. Fully understand the contents of the manual and make the best of it.

We will make utmost efforts to make this manual more useful for you through revisions.

Your opinions and advices will be particularly welcome and will be carefully considered.

CONTENTS

| | |
|--|--------------|
| SPECIFICATIONS | 1-001 |
| STRUCTURE & OPERATION | 2-001 |
| INSPECTION & ADJUSTMENT | 3-001 |
| TROUBLE-SHOOTING | 4-001 |

SPECIFICATIONS

SPECIFICATIONS

1. External Views and Specifications


1-1. SW8001-002
1-2. SW8501-003

SPECIFICATIONS

1. External Views and Specifications

1-1. SW800

Unit in mm {in}




SW8001001

| | | | | | |
|--------------------------------|---|-------------------------|--|--------------|--------------|
| Model | SW800 | Vibrating power: | | | |
| Weight: | | Low amplitude | | | |
| Gross weight | 10,200 kg {22,490 lbs} | Frequency | 67 Hz | 50 Hz | 42 Hz |
| Empty weight | 9,200 kg {20,280 lbs} | | {4,000 vpm} | {3,000 vpm} | {2,500 vpm} |
| Dimension: | | Centrifugal force | 121 kN | 68 kN | 47 kN |
| Overall length | 5,620 mm {221"} | | {27,120 lbs} | {15,210 lbs} | {10,580 lbs} |
| Overall width | 1,905 mm {75"} | High amplitude | | | |
| Overall height | 3,080 mm {121"} | Frequency | 50 Hz | 42 Hz | |
| Wheelbase | 3,300 mm {130"} | | {3,000 vpm} | {2,500 vpm} | |
| Wheel | | Centrifugal force | 108 kN | 76 kN | |
| Front | Roll (dia. x width) 1,300 x 1,700 mm {51" x 67"} | | {24,250 lbs} | {16,980 lbs} | |
| Rear | Roll (dia. x width) 1,300 x 1,700 mm {51" x 67"} | Engine: | | | |
| Performance: | | Model | ISUZU "A-4BG1T" Diesel Engine (with turbo charger) | | |
| Travel speed (forward/reverse) | | Total displacement | 4.329 liters {264 cu.in} | | |
| Low | 0 ~ 7.5 km/h {0 ~ 4.6 mile/h} | Rated output | 82 kW {111 PS}/2,300 min ⁻¹ {rpm} | | |
| High | 0 ~ 12.5 km/h {0 ~ 7.7 mile/h} | Max. torque | 333 N·m/1,600 min ⁻¹ {rpm} | | |
| | | | {246 ft-lb/1,600 rpm} | | |
| Vibrating power: | | Tank capacity: | | | |
| Gradability | 33 % {18.3°} | Fuel tank | 220 liters {58 gal} | | |
| Rolling width | 1,700 mm {67"} | Hydraulic tank | 80 liters {21 gal} | | |
| Minimum turning radius | 6.0 m {237"} | Sprinkler tank | 500 liters x 2 {132 gal x 2} | | |

NOTE: Gradability is the calculated value. It may vary with ground surface conditions.

1-2. SW850

Unit in mm {in}



SW8501001

| | | | | | |
|--------------------------------|---|-------------------------|--|--------------|--------------|
| Model | SW850 | Vibrating power: | | | |
| Weight: | | Low amplitude | | | |
| Gross weight | 12,350 kg {27,230 lbs} | Frequency | 67 Hz | 50 Hz | 42 Hz |
| Empty weight | 11,150 kg {24,580 lbs} | | {4,000 vpm} | {3,000 vpm} | {2,500 vpm} |
| Dimension: | | Centrifugal force | 148 kN | 82 kN | 58 kN |
| Overall length | 5,820 mm {229"} | | {33,290 lbs} | {18,520 lbs} | {13,010 lbs} |
| Overall width | 2,205 mm {87"} | High amplitude | | | |
| Overall height | 3,130 mm {123"} | Frequency | 50 Hz | 42 Hz | |
| Wheelbase | 3,400 mm {134"} | | {3,000 vpm} | {2,500 vpm} | |
| Wheel | | Centrifugal force | 141 kN | 100 kN | |
| Front | Roll (dia. x width) 1,400 x 2,000 mm {55" x 79"} | | {31,750 lbs} | {22,490 lbs} | |
| Rear | Roll (dia. x width) 1,400 x 2,000 mm {55" x 79"} | Engine: | | | |
| | | Model | ISUZU "A-6BG1T" Diesel Engine | | |
| | | Total displacement | 6.494 liters {396 cu.in} | | |
| Performance: | | Rated output | 90 kW {123 PS}/2,300 min ⁻¹ {rpm} | | |
| Travel speed (forward/reverse) | | | {121 HP/2,300 rpm} | | |
| Low | 0 ~ 7 km/h {0 ~ 4.3 mile/h} | Max. torque | 392 N·m/1,600 min ⁻¹ {rpm} | | |
| High | 0 ~ 11 km/h {0 ~ 6.8 mile/h} | | {289 ft-lb/1,600 rpm} | | |
| Vibrating power: | | Tank capacity: | | | |
| Gradability | 31 % {17.2°} | Fuel tank | 250 liters {66 gal} | | |
| Rolling width | 2,000 mm {79"} | Hydraulic tank | 80 liters {21 gal} | | |
| Minimum turning radius | 6.3 m {248"} | Sprinkler tank | 600 liters x 2 {159 gal x 2} | | |

NOTE: Gradability is the calculated value. It may vary with ground surface conditions.

STRUCTURE & OPERATION

STRUCTURE & OPERATION

1. Engine-related Units

| | |
|--------------------------------------|-------|
| 1-1. Engine mount (SW800) | 2-003 |
| 1-2. Engine mount (SW850) | 2-004 |
| 1-3. Intake system (SW800) | 2-005 |
| 1-4. Intake system (SW850) | 2-006 |
| 1-5. Exhaust system (SW800) | 2-007 |
| 1-6. Exhaust system (SW850) | 2-008 |
| 1-7. Cooling piping & radiator | 2-009 |
| 1-8. Fuel piping and fuel tank | 2-010 |
| 1-9. Fuel controls (SW800) | 2-011 |
| 1-10. Fuel controls (SW850) | 2-012 |

2. Description and Operation of Hydraulic System

| | |
|---|-------|
| 2-1. Structure of hydraulic pump and motor | |
| 2-1-1. Propulsion pump/vibrator pump ass'y | 2-013 |
| 2-1-2. Steering pump | 2-014 |
| 2-1-3. Propulsion motor ass'y | 2-015 |
| 2-1-4. Vibrator motor ass'y | 2-016 |
| 2-2. Coupling and hydraulic circuit | |
| 2-2-1. Coupling | 2-017 |
| 2-2-2. Hydraulic circuit (SW800) | 2-019 |
| 2-2-3. Hydraulic circuit (SW850) | 2-020 |
| 2-3. Propulsion system | |
| 2-3-1. Propulsion controls | 2-021 |
| 2-3-2. Hydraulic piping [I] | 2-022 |
| 2-3-3. Hydraulic piping [II] | 2-023 |
| 2-3-4. Propulsion circuit | 2-024 |
| 2-3-5. Description and operation of propulsion system | 2-025 |
| 2-4. Vibrating system | |
| 2-4-1. Amplitude select valve (selection of motor rotating direction) | 2-028 |
| 2-4-2. Drum and vibrator | 2-029 |
| 2-4-3. Hydraulic piping [I] | 2-030 |
| 2-4-4. Hydraulic piping [II] | 2-031 |
| 2-4-5. Vibrator motor | 2-032 |
| 2-4-6. Description and operation of vibrating system | 2-033 |
| 2-4-7. Operations of switches and solenoids | 2-035 |
| 2-5. Steering system | |
| 2-5-1. Orbitrol | 2-037 |
| 2-5-2. Steering cylinder ass'y | 2-038 |
| 2-5-3. Steering piping | 2-039 |

| | |
|--|-------|
| 2-5-4. Steering circuit | 2-040 |
| 2-5-5. Description and operation of steering circuit | 2-041 |

3. Brake System

| | |
|---|-------|
| 3-1. Brake pedal and linkage | 2-042 |
| 3-2. Description and operation of parking brake circuit | 2-043 |

4. Sprinkler


| | |
|--|-------|
| 4-1. Sprinkler piping [I] (SW800: From Machine No.10122 SW850: From Machine No.10126) | 2-044 |
| 4-2. Sprinkler piping [II] (SW800: From Machine No.10123 SW850: From Machine No.10127) | 2-045 |

5. Electric System

| | |
|---|-------|
| 5-1. Locations of instrument panel and relays [I] (SW800: From Machine No.10122 SW850: From Machine No.10126) | 2-046 |
| 5-2. Locations of instrument panel and relays [II] (SW800: From Machine No.10123 SW850: From Machine No.10127) | 2-047 |
| 5-3. Locations of electric components [I] (SW800: From Machine No.10122 SW850: From Machine No.10126) | 2-048 |
| 5-4. Locations of electric components [II] (SW800: From Machine No.10123 SW850: From Machine No.10127) | 2-049 |
| 5-5. Function and operation of engine stopper | 2-050 |
| 5-6. Electric wiring diagram [I] (SW800: From Machine No.10122 SW850: From Machine No.10126) | 2-052 |
| 5-7. Electric wiring diagram [II] (SW800: From Machine No.10123 SW850: From Machine No.10127) | 2-053 |

1.Engine-related Units


1-1. Engine mount (SW800)



SW8002001

- 1. Engine mount (front)
- 2. Engine mount (rear)


1-2. Engine mount (SW850)



SW8502001

- 1. Engine mount (front)
- 2. Engine mount (rear)


1-3. Intake system (SW800)



SW8002002

- 1. Air cleaner
- 2. Intake hose
- 3. Air feed pipe
- 4. Turbo charger


1-4. Intake system (SW850)



SW8502002

- 1. Air cleaner
- 2. Intake hose


1-5. Exhaust system (SW800)



SW8002003

- 1. Exhaust pipe
- 2. Muffler
- 3. Exhaust pipe
- 4. Turbo charger




1-6. Exhaust system (SW850)



- 1. Exhaust pipe
- 2. Muffler
- 3. Exhaust pipe

SW8502003


1-7. Cooling piping & radiator



SW8002004

1. Radiator
2. Sub tank
3. Radiator inlet hose
4. Radiator outlet hose
5. Oil cooler


1-8. Fuel piping & fuel tank



- | | |
|-----------------------------------|------------------------------------|
| 1. Fuel tank | 6. Pipe (filter to injection pump) |
| 2. Sedimenter | 7. Hose (engine to fuel tank) |
| 3. Hose (fuel tank to sedimenter) | 8. Filter |
| 4. Hose (sedimenter to feed pump) | 9. Fuel unit |
| 5. Pipe (feed pump to filter) | |

SW8002005


1-9. Fuel controls (SW800)



SW8002006

1. Throttle lever
2. Throttle cable
3. Engine stopper
4. Engine stopper cable
5. Throttle lever adjusting screw

1-10. Fuel controls (SW850)




SW8502004

1. Throttle lever
2. Throttle cable
3. Engine stopper
4. Engine stopper cable
5. Throttle lever adjusting screw

2. Description and Operation of Hydraulic System

2-1. Structure of hydraulic pump and motor

2-1-1. Propulsion pump/vibrator pump ass'y



Propulsion pump:

- | | |
|---|---|
| 1. Port A (reverse travel) | 6. Circuit pressure gauge port (port B) |
| 2. Port B (forward travel) | 7. Charge relief valve |
| 3. Multi-function valve (port A) | 8. Charge circuit pressure gauge port |
| 4. Multi-function valve (port B) | 9. Control valve |
| 5. Circuit pressure gauge port (Port A) | 10. Servo piston |
| | 11. Cut-off valve |

Vibrator pump:

12. Port A2 (front circuit)
13. Port A3 (rear circuit)
14. Circuit pressure gauge port (port A2)
15. Circuit pressure gauge port (port A3)
16. Suction port
17. Frequency (delivery) select valve


Specifications (propulsion pump)

- Model : A4VG90HW
- Max. displacement : 90cm³/rev(cc/rev)
- Relief valve setting : 40.2MPa (410kgf/cm²) {5830psi}
- Cut-off valve setting : 37.3MPa (385kgf/cm²) {5470psi}
- Charge circuit setting : 2.5MPa (25kgf/cm²) {355psi}

Specifications (vibrator pump)

- Model : AP2D36
- Max. displacement : 28cm³/rev(cc/rev) x 2
- Circuit pressure setting : 22.5MPa (230kgf/cm²) {3270psi} (Set by amplitude select valve)

2-1-2. Steering pump




1. Port A
2. port B
3. Drain port

Specifications

- Model : A2FM16
- Displacement : $16\text{cm}^3/\text{rev}(\text{cc}/\text{rev})$
- Circuit pressure setting : 22.5MPa ($230\text{kgf}/\text{cm}^2$) { 3270psi }
(Set by amplitude select valve)

SW8002008

2-1-3. Propulsion motor ass'y



SW8002009

- | | |
|------------------------------------|-------------------------------------|
| 1. Port A | 9. Flushing valve (rear motor only) |
| 2. Port B | 10. Drain circuit port |
| 3. Circuit pressure gauge port (A) | Brake: |
| 4. Circuit pressure gauge port (B) | 11. Disc |
| 5. Brake release port | 12. Plate |
| 6. Brake release bolt hole | 13. Brake piston |
| 7. Gear reducer | Motor: |
| 8. Gear reducer fill hole plug | 14. Piston |
| | 15. Cylinder block |
| | 16. Swashplate |


Specifications (SW800)

- Model : MF55-5111 (front)
: MF55-506 (rear)
- Displacement : 55.1cm³/rev(cc/rev)
- Flushing relief setting : 2.4MPa (24kgf/cm²) {340psi}
- Circuit pressure setting : 40.2MPa (410kgf/cm²) {5830psi}
(To be set on propulsion pump side)

Specifications (SW850)

- Model : MF75E (front)
: MF75D (rear)
- Displacement : 75cm³/rev(cc/rev)
- Flushing relief setting : 2.4±1MPa (24±1kgf/cm²) {340±14psi}
- Circuit pressure setting : 40.2MPa (410kgf/cm²) {5830psi}
(To be set on propulsion pump side)

2-1-4. Vibrator motor ass'y



SW8002010


- 1. Suction port
- 2. Delivery port

Specifications

- Model : SGP123R517
- Displacement : 23.3cm³/rev(cc/rev)
- Circuit pressure setting : 15.2MPa (155kgf/cm²) {2200psi}
(To be set on Orbitrol side)

2-2. Coupling and hydraulic circuit


2-2-1. Coupling




SW8002011

1. Flywheel
2. Bolt
3. Coupling
4. Bolt
5. Set screw
6. Spring pin
7. Boss

2-2-2. Hydraulic circuit (SW800)




2-2-3. Hydraulic circuit (SW850)



2-3. Propulsion system


2-3-1. Propulsion controls



SW8002013

1. Forward-reverse (F-R) lever
2. Vibrator switch
3. Forward-reverse (F-R) lever switch
4. Reverse alarm switch
5. Control cable
6. Control lever (propulsion pump)


2-3-2. Hydraulic piping [I]



SW8002014

- | | |
|--|--|
| <ul style="list-style-type: none"> 1. Return filter 2. Return hose (propulsion pump to filter) 3. Return hose (filter to hydraulic tank) 4. Unloader valve 5. Hose (unloader) 6. High pressure hose (forward travel of front motor) 7. High pressure hose (reverse travel of rear motor) 8. Brake release hose (filter to brake release valve) | <ul style="list-style-type: none"> 9. Brake release hose (brake relief valve to front propulsion motor) 10. Return hose (front propulsion motor to hydraulic tank) 11. Return hose (propulsion pump to hydraulic tank) 12. Hydraulic tank drain hose <p>* Hose (10) meets with vibrator hose (17) and leads to tank.</p> |
|--|--|


2-3-3. Hydraulic circuit [II]



SECTION A-A SW8002015

- | | |
|---|---|
| <ul style="list-style-type: none"> 6. High pressure hose (forward travel of front propulsion motor) 7. High pressure hose (reverse travel of front propulsion motor) 9. Brake release hose (Brake release valve to front propulsion motor) 10. Return hose (front propulsion motor to hydraulic tank) 14. Propulsion pump 15. Front propulsion motor 16. Rear propulsion motor | <ul style="list-style-type: none"> 17. High pressure hose (forward travel of front motor) 18. High pressure hose (reverse travel of rear motor) 19. Brake release hose (brake release valve to rear propulsion motor) 20. Return hose (rear propulsion motor to hydraulic tank) 21. Brake release valve 22. Hydraulic tank <p>* Items 6, 7, 8 and 9 are the same ones as listed in the previous page.</p> |
|---|---|

2-3-4. Propulsion circuit



- 1. Engine
- 2. Coupling
- 3. Propulsion pump ass'y
 - a. Control valve
 - b. Servo cylinder
 - c. High pressure relief valve
 - d. Charge relief valve
 - e. Cut-off valve
- 4. Return filter
- 5. Unloader valve
- 6. Vibrator pump ass'y
- 7. Rear propulsion motor ass'y
 - f. Shuttle valve
 - g. Flushing valve
 - h. Negative brake
 - i. Gear reducer
- 8. Front propulsion motor
 - h. Negative brake valve
 - i. Gear reducer
- 9. Front drum
- 10. Rear drum
- 11. Brake release valve
- 12. Suction filter
- 13. Steering pump ass'y
- 14. Orbitrol ass'y
 - k. Relief valve
- 15. Line filter (charge circuit)

SW8002016

2-3-5. Description and operation of propulsion system

- ◆ See the hydraulic circuit on page 2-024.

Description of propulsion system

- Made up of propulsion pump (3), front propulsion motor (8), front drum (10), rear propulsion motor (7) and rear drum (9). Brake release solenoid valve (11) is mounted on the chassis.

Basic function of propulsion pump and propulsion motor


- Propulsion pump
A piston pump is used which selects forward travel, neutral and backing by varying the swashplate inclination, and thus varying the piston stroke. The travel speed is infinitely variable by the operation of the F-R (forward-reverse) lever.
- Propulsion motor
A fixed displacement piston motor (piston stroke is not variable) is used.

Operation (It is assumed that the machine travels forward.)

★The negative brake (spring-applied hydraulically released brake) is supposed to have been released.

- ◆ Assemblies such as pump ass'y and motor ass'y are indicated by numbers such as '1' and '2', while component parts of assemblies are shown by small letters such as 'a' and 'b'.
- ◆ The circuit of the front motor and that of the rear motor connect in parallel with each other.
 - When the forward-reverse lever (F-R lever) is moved forward, control valve (a) functions to tilt the pump swashplate in the forward travel direction.
 - Propulsion pump (3) discharges oil from its port B into the forward travel circuit, then the oil flow is divided into two lines; the forward travel line connecting to port A of front motor (8) and that connecting to port B of rear motor (7).
 - The oil fed into the forward travel ports of the motors drives the motors, flowing out from the opposite side ports. Two flows of oil from the motors meet with each other and get into port A of pump (3). At the same time, part of oil in the rear motor is dumped into the tank through shuttle valve (f) and flushing valve (g) both of which are built in motor (7), and also through the motor casings.
 - Power from the motors is delivered to drums (9) and (10) through gear reducers (i).
 - ◆ Front motor (10) is not equipped with shuttle valve (f) and low pressure relief valve (g).

NOTE: Because the propulsion circuit is a closed loop circuit, the suction and discharging functions are reversed with each other when the travel direction is reversed. (The direction of oil flow is reversed.)



SW8002017

Disengaging the negative brake:


- When energized, brake release solenoid (11) functions to deliver oil, through it, from the charge circuit to the brake release ports in the propulsion motor.
- The oil then pushes the brake piston in each negative brake (h), disengaging the brake.

Circuit protection against high pressure:

- Cut off valve (e) is fitted in the propulsion pump. If the circuit pressure exceeds the setting of the valve, the valve functions and exerts oil pressure on the pump servo piston to reduce pump delivery.
- Decrease in delivery (travel speed reduction) lowers the circuit pressure.
- In addition to this cut off valve, the circuit includes high pressure relief valve (c) which opens to protect the circuit if the circuit pressure exceeds the permissible maximum of the cut off valve.

Charge circuit:


- The propulsion circuit is of a closed circuit, which needs feeding of oil into it for making up for deficiency and for other purposes.
 - In the charge circuit, oil from steering pump (13) flows into Orbitrol (14), then the whole amount of oil goes to propulsion pump (3) via filter (15) irrespective of the steering wheel operation.
 - The pressure adjustment is achieved by charge relief valve (d) built in the propulsion pump when the F-R lever is in the neutral position. When travelling, the pressure is adjusted by flushing valve (g) built in rear propulsion motor (7).
- Oil that flows through the charge circuit plays other roles. Those are renewing and cooling of oil and removal of foreign matter.



SW8002018

2-4. Vibrating system

2-4-1. Amplitude select valve (selection of motor rotating direction)



SW8002019

Port P (inlet)

Port T (outlet)

Port A1 (connected to port B in front motor and to port A in rear motor)

Port B1 (connected to port A in front motor and to port B in rear motor)

1. Main relief valve

2. Port relief valve

3. Port relief valve

4. Check valve

5. Solenoid

6. Solenoid

7. Spool

Specifications

- Model

: 1D04T1S00432-0

- Main relief valve setting



: 22.5MPa (230kgf/cm²)

{3270psi}

- Port relief valve setting

: 24.0MPa (245kgf/cm²)

2-4-2. Drum and vibrator




SW8002020

- | | |
|-----------------------|---------------------|
| 1. Vibrator shaft | 13. Cover |
| 2. Roller bearing | 14. Vibrator motor |
| 3. Sleeve | 15. Shim |
| 4. Spring pin | 16. Breather |
| 5. Housing | 17. Disc |
| 6. Vibrator shaft | 18. Sleeve |
| 7. Axle shaft | 19. Spring pin |
| 8. Plug (fill, drain) | 20. Drum |
| 9. Oil seal | 21. Housing |
| 10. Roller bearing | 22. Propulsor motor |
| 11. Damper | 23. Plate |
| 12. Oil seal | |

- * Rear motor
(Low amplitude with oil fed into port A)
- * Front motor
(Low amplitude with oil fed into port B)
- ★ See 2-1-3 Propulsion motor ass'y.



2-4-3. Vibrator piping [I]



SW8002021

1. Vibrator pump
2. Suction hose
3. Delivery hose (pump to amplitude select valve) (front)
4. Delivery hose (pump to amplitude select valve)
5. Return hose (amplitude select valve to hydraulic tank) (front)
6. Return hose (amplitude select valve to hydraulic tank) (rear)
7. Oil cooler
8. Return hose (oil cooler to hydraulic tank)
9. Drain hose (vibrator pump to hydraulic tank)
10. Suction filter (vibrator pump)
11. Frequency select valve
12. Pilot pressure hose (for frequency select valve)

2-4-4. Vibrator piping (Ⅱ)




SW8002022

- | | |
|--|--|
| 13.Vibrator motor (front) | 19.Amplitude select valve (rear) |
| 14.Vibrator operating valve (front) | 20.High pressure hose (hose B) |
| 15.High pressure hose (hose A) | 21.High pressure hose (hose A) |
| 16.High pressure hose (hose B) | 22.Drain hose (vibrator motor to hydraulic tank) |
| 17.Drain hose (vibrator motor to hydraulic tank) | 23.Hydraulic tank |
| 18.Vibrator motor (rear) | |

※Hose (17) meets with vibrator motor hose (22) and leads to tank. ……P. 2-032

2-4-5. Vibrator circuit



- 1. Engine
- 2. Coupling
- 3. Propulsion pump ass'y
- 4. Vibrator pump ass'y
 - a. Solenoid valve (frequency select)
 - b. Control piston (frequency select)
 - c. Spring (delivery control)
- 5. Amplitude select valve
 - d. Solenoid a (Low)
 - e. Solenoid b (High)
- 6. Amplitude select valve (rear)
 - d. solenoid a (High amp.)
 - e. Solenoid b (Low amp.)
 - f. Spool
 - g. Main relief valve
 - h. Port relief valve
- 7. Front vibrator motor
- 8. Rear vibrator motor
- 9. Front vibrator
- 10. Rear vibrator
- 11. Oil cooler
- 12. Suction filter

SW8002023

2-4-6. Description and operation of vibrating system

Description


- Made up of vibrator pump assembly (4), front amplitude select valve (5), rear amplitude select valve, front vibrator motor (7), rear vibrator motor (8), front vibrator (9) and rear vibrator (10).

Basic function of vibrator pump and motor

- **Vibrator pump**
A piston pump (twin pump) is in use. A pump delivery select solenoid valve selects three steps of delivery (three steps of frequency).
- **Vibrator motor**
A bent axis type fixed displacement piston motor is used. The displacement per rotation of motor shaft is not variable.

Operation

- The vibrator pump delivers an amount of oil set by the frequency selector switch, which is drained to the tank via frequency select valves (5), (6) and oil cooler (11).
- ★ **Only the rear propulsion circuit includes an oil cooler.**
- The frequency select solenoid valves provide:
Maximum delivery when solenoids (d) and (e) are not energized.
Medium delivery when solenoid (e) is energized.
Minimum delivery when solenoid (d) is energized.
- If the amplitude selector switch selects Low amplitude or High, spool (f) of amplitude select valve moves to block the unload circuit and feeds the vibrator motors. Oil drives vibrator motors (7) and (8), being dumped to the tank via one-way valves (i) and oil cooler (11).
- ★ **The oil cooler is included in the rear vibrator circuit only.**



SW8002024


- The amplitude select (Vibrator motor rotating direction select) valves provide:
 - High amplitude when solenoid (d) of front valve (5) and solenoid (e) of rear valve (6) are energized.
 - Low amplitude when the opposite solenoids are energized.
- ★ For operation of the solenoid valve, see descriptions on page 2-035.

Operation of port relief valves

- Even if the amplitude select valve is brought to the neutral position, the vibrator shaft tends to continue rotation due to inertia. On the other hand, there is a shortage of oil in the feed line (line which feeds oil to motor) of the motor, because ports A1 and B1 are blocked.
- Then the one-way valve mounted in port relief valve (h) on the low pressure side opens to feed part of oil in the return line to the motor.
- In addition, because the outlet port of the motor stays closed, oil displaced from the inertia-rotating motor flows into the return line by opening the port relief valve in the outlet circuit.

Circuit protection

- * See the circuit diagram on page 2-033.
- If the system pressure rises to the setting of relief valves (g) built in solenoid valves (5) and (6), the relief valves open to protect the circuit.




SW8002025

2-4-7. Operation of vibrator switches and solenoids

Models SW800 and SW850 have a system to control vibrator pump delivery in three steps (frequency in three steps) and amplitude in two steps (vibratory force in two steps). Description of the system is given below.

★ The vibrator shaft rotation varies with varying pump delivery. That is, the frequency varies. Amplitude is changed by reversing the rotating direction of the vibrator shaft (See P.2-029).

1. Electric wiring diagram for vibrating system



SW8002026

2. Switch connection

2-1. Amplitude selector switch

| Amplitude | Terminal number | | | | Solenoid energized | | Symbol |
|-----------|-----------------|---|---|---|--------------------|--------|--------|
| | 1 | 2 | 3 | 4 | F | R | |
| Low amp. | ○ | ○ | ○ | | b | a (b)* | |
| OFF | ○ | | ○ | | | | |
| High amp. | ○ | | ○ | ○ | a | b (a)* | |

2-2. Frequency selector switch

| Frequency | Terminal number | | | | | Solenoid energized | Symbol |
|------------------|-----------------|---|---|---|---|--------------------|--------|
| | 1 | 2 | 3 | 4 | 5 | | |
| High frequency | ○ | ○ | ○ | ○ | ○ | — | |
| Medium frequency | ○ | ○ | ○ | ○ | | b | |
| Low frequency | ○ | ○ | | ○ | | a | |

* Amplitude select valve for rear vibrator. Letters (a, b) in parentheses (): SW800 → From Machine

3. Operation of amplitude selector switches and solenoids

1) Amplitude selector switch set to Low amplitude []

Terminal 1 connects to terminal 2. Solenoid (b) of the front amplitude select valve and solenoid (a) of the rear amplitude select valve are energized.

- 2) Amplitude selector switch set to High amplitude [\wedge]
Terminal 4 connects to terminal 5. Solenoid (a) of the front amplitude select valve and solenoid (b) of the rear amplitude select valve are energized. At the same time, front vibrator relay (2) and rear vibrator relay (3) are energized.
★ **For function of relays, see page 2-036.**

4. Operation of amplitude selector switch, relays and solenoids

- 1) Frequency selector switch in Low frequency position [\wedge] (Not affected by amplitude selector switch.)

Terminals 1 and 2 of the frequency select switch connect with each other to directly energize solenoid (a) of the frequency select valve. Solenoid (a) moves the pump swash plate to Low Delivery position. This offers Low frequency.

- 2) Frequency selector switch in Medium frequency position [\wedge] (terminal 1 connects with terminal 3) with amplitude selector switch in Low amplitude position [\sim] (terminal 1 connects with terminal 2)

Current from terminal 3 of the frequency selector switch flows through terminals 3 and 2 of vibration relay (1), energizing solenoid (b). At the same time current is fed to terminal 3 of relay (2). At this time, the system is not influenced by relay (2), because relay (2) remains deenergized. Solenoid (b) shifts the pump swashplate to Medium delivery position. This gives Medium delivery.

- 3) Frequency selector switch in Medium frequency position [\wedge] (terminal 1 connects with terminal 3) with amplitude selector switch in High amplitude position [\wedge] (Terminal 4 connects with terminal 5.)

★ **For current flow from the frequency selector switch, see item 3-2) above.**

Terminals 3 and 5 of vibration relay (2) connect with each other and current from the frequency selector switch energizes solenoid (b) of the frequency select valve. This gives the same frequency (Medium frequency) as in item 4-2) above.

- 4) Frequency selector switch in High frequency position [\wedge] (Terminals 1 and 4 connect with terminals 3 and 5 respectively) with amplitude selector switch in Low amplitude position [\sim] (terminal 1 connects with terminal 2)

Current flow from terminal 3 of the frequency selector valve is the same as in item 4-2) above, however, current from terminal 5 passes through terminals 3 and 2 of vibration relay (3) to the coil of relay (1) to energize it. This disconnects terminal 3 from terminal 2. Solenoids (a) and (b) of frequency select solenoid valve are not energized. This sets the swashplate to High delivery position, providing High frequency.

- 5) Frequency selector switch in High frequency position [\wedge] (terminals 1 and 4 connect with terminal 3 and 5 respectively) with amplitude selector switch in High amplitude position [\wedge] (terminal 4 connects with terminal 5.)

★ **The connection and circuit formation are the same as those in item 4-4) above.**


★ **For current flow from the amplitude selector switch, see item 3-2) above.**

1. Current from terminal (3) of the frequency selector switch is simultaneously fed to terminal (3) of relays (1) and (2). Current is fed to solenoid (b), because relay (2) is energized to connect terminal 3 with terminal 5 of relay (2).
2. On the other hand, current from terminal 5 of the frequency selector switch does not pass to relay (1), because relay (3) remains energized to disconnect its terminal 3 from terminal 2. Relay (1) remains deenergized. As a result, current from terminal 3 of frequency selector switch is fed to solenoid (b) of amplitude select valve. The pump offers Medium delivery (Medium frequency).

* As described in item 5-5) above, if the amplitude selector switch is in High amplitude position,

2-5. Steering system

2-5-1. Orbitrol




SW8002040

- | | |
|---------------------|------------------------|
| 1. Geroler set | 11. Seal gland bush |
| 2. Drive | 12. Filter sub ass'y |
| 3. Spool | 13. Lock nut |
| 4. Sleeve | 14. Spool |
| 5. Pin | 15. Valve seat |
| 6. Centering spring | 16. Ball |
| 7. Thrust needle | 17. Ball guide |
| 8. Retaining ring | 18. Inner valve spring |
| 9. Oil seal | 19. Spacer |
| 10. Dust seal | 20. End cap |

Specifications

- Valve system : Open center non-load reaction
- Displacement : 461 cm³/rev (cc/rev)
- Relief valve setting : 15.2 MPa (155 kgf/cm²) {2200 psi}


2-5-2. Steering cylinder ass'y



SW8002027

- | | | |
|---------------|------------------|-----------------------|
| 1. Cylinder | 7. Washer | 13. Wear-ring |
| 2. Piston rod | 8. Dust seal | 14. Spherical bearing |
| 3. End cap | 9. U-packing | 15. Ring |
| 4. Bush | 10. O-ring | 16. Grease fitting |
| 5. Piston | 11. O-ring | |
| 6. Nut | 12. Slipper seal | |


2-5-3. Steering piping



SW8002028

- | | |
|------------------------------|--|
| 1. Steering pump | 6. High pressure hose (left turn) |
| 2. Pump outlet hose | 7. High pressure hose (right turn) |
| 3. Suction hose | 8. Charge line hose (Orbitrol to filter) |
| 4. Steering valve (Orbitrol) | 9. Line filter (charge line) |
| 5. Steering cylinders | |

2-5-4. Steering circuit



SW8002029

- 1. Engine
- 2. PTO (engine side)
- 3. Suction filter
- 4. Steering pump
- 5. Orbitrol
 - a. Relief valve
 - b. Check valve
- 6. Steering cylinder
- c. Piston rod
- 7. Line filter (charge circuit)

2-5-5. Description and operation of steering system

Description:

- The steering system is made up of steering pump (4), Orbitrol (5), steering cylinders (6) and line filter (7).


The steering mechanism is of an articulated type in which the machine frame is articulated at its center.

Operation

- Oil from pump (4) enters Orbitrol (5). The valve feeds an amount of oil to steering cylinders (6). The amount of oil handled varies with the direction in which the steering wheel is rotated and with the speed at which the steering wheel is turned.
- The fluid fed into both steering cylinders (6) moves the piston rods (c) to achieve steering. The oil displaced from the opposite side of the pistons flows, through Orbitrol (5) and line filter (7), to the propulsion charge circuit.

★ Refer to “Charge circuit”.


- Relief valve (a) built in Orbitrol (5) opens to relieve the pressure if the system pressure exceeds the setting of the relief valve, thus protecting the circuit.



SW8002030

3. Brake System

3-1. Brake pedal and linkage



SW8002031

- | | |
|---|---------------------------------------|
| 1. Brake pedal | 5. Lever (F-R lever neutral position) |
| 2. Rod | 6. Lever (F-R lever neutral position) |
| 3. Adjusting bolt (pedal height adjustment) | 7. Foot brake switch |
| 4. Stopper | |

3-2. Description and operation of parking brake circuit

Description:

- Consists of brake pedal (1), foot brake switch (7), brake relay (8), parking brake switch (9), brake release solenoid (10) and parking brakes (negative brakes) (11), (12).

★ **The foot brake switch is ON when the brake pedal is not depressed, and OFF if the pedal is pushed down on.**


Operation:

Parking brake switch set to position RELEASE:

- Setting the parking brake switch to the RELEASE position causes the current to flow, through terminals 1 and 3, to terminal 3 of the brake relay.
- If, at this time, the brake pedal is not depressed, foot brake switch (7) remains ON, energizing the brake relay.
- This connects terminal 3 with terminal 5 of the brake relay. The solenoid of the brake release valve is energized to disengage the parking brakes (negative brakes) (11).


Parking brake switch set to position PARKING:

- Pushing down on the brake pedal opens foot brake switch (7) to deenergize brake relay (8). Even if, at this time, parking brake switch (9) is in the RELEASE position, terminal 3 remains disconnected with terminal 5, for brake relay (8) remains deenergized. Solenoid (10) remains deenergized. Brake is applied.
- Setting parking brake switch (9) to the PARKING position disconnects terminal 1 from terminal 3. Solenoid (10) is deenergized. At the same time, terminal connects with terminal 5 to light brake lamp on the combination meter.



4. Sprinkler


4-1. Sprinkler piping [I] (SW800: To Machine No.10122 SW850: To Machine No.10126)



SW8002033

- | | |
|---------------------------------|------------------------------------|
| 1. Sprinkler pump (front) | 7. Hose (pump to pipe) |
| 2. Sprinkler tank ass'y (front) | 8. Sprinkler pump (rear) |
| 3. Sprinkler filter (front) | 9. Sprinkler tank ass'y (rear) |
| 4. Sprinkler pipe (front) | 10. Sprinkler filter (rear) |
| 5. Hose (tank to filter) | 11. Sprinkler pipe (rear) |
| 6. Hose (filter to pump) | 12. Hose (front pump to rear pump) |

**4-2. Sprinkler piping [Ⅱ] (SW800: From Machine No.10123
SW850: From Machine No.10127)**




- 1. Sprinkler pump
- 2. Sprinkler tank
- 3. Sprinkler filter
- 4. Sprinkler pipe

- 5. Hose (tank to filter)
- 6. Hose (filter to pump)
- 7. Hose (filter to pump)
- 8. Hose (pump to sprinkler pipe)

SW8002043

5. Electric System


5-1. Instrument panel and relays [I] (SW800: From Machine No.10122 SW850: From Machine No.10126)




SW8002034

- | | | |
|----------------------------|-----------------------|---------------------|
| 1. Combination meter panel | 7. Foot brake relay | 13. Job lamp relay |
| 2. Vibrator relay (1) | 8. Fuse box | 14. Diode unit |
| 3. Vibrator relay (3) | 9. Diode | 15. Lamp relay |
| 4. Vibrator relay (2) | 10. Engine stop relay | 16. Sprinkler relay |
| 5. Horn relay | 11. Delay relay | 17. Sprinkler relay |
| 6. Lamp check relay | 12. Glow timer | |


5-2. Instrument panel and relays [Ⅱ] (SW800: To Machine No.10123 SW850: To Machine No.10127)




VIEW A



VIEW B



VIEW D




VIEW C

- | | | |
|----------------------------|-------------------------|-----------------------|
| 1. Combination panel | 7. Vibrator relay (4) | 13. Diode |
| 2. Sprinkler relay (rear) | 8. Diode | 14. Engine stop relay |
| 3. Sprinkler relay (front) | 9. Vibrator relay (1) | 15. Delay relay |
| 4. Fuse box | 10. Vibrator relay (3) | 16. Vibrator relay |
| 5. Horn relay | 11. Starter motor relay | 17. Glow timer |
| 6. Foot brake relay | 12. Lamp check relay | |

SW8002041


5-3. Locations of electric components [1] (SW800: To Machine No.10122 SW850: To Machine No.10126)



SW8002035

- | | |
|--|--|
| 1. Sprinkler pump | 15. Tachometer sensor |
| 2. Headlamps | 16. Starter |
| 3. Battery relay | 17. F-R lever switch |
| 4. Fusible link | 18. Reverse alarm switch |
| 5. Horn | 19. Amplitude selector switch (front) (vibrator motor rotating direction select) |
| 6. Alternator | 20. Frequency select valve (vibrator pump delivery select) |
| 7. Amplitude select valve (front) (vibrator motor rotating direction select) | 21. Brake release solenoid valve |
| 8. Thermo unit | 22. Vibrator switch |
| 9. Job lamp | 23. Frequency selector switch (vibrator pump delivery select) |
| 10. Glow plug | 24. Amplitude selector switch (vibrator motor rotating direction select) |
| 11. Engine oil pressure switch | |
| 12. Engine stopper | |
| 13. Sprinkler pump (rear) | |
| 14. Reverse alarm | |

5-4. Locations of electric components [II] (SW800:From Machine No.10123 SW850: from Machine No.10127)



- | | |
|---|---|
| 1. Sprinkler pump (front) | 15. Tachometer sensor |
| 2. Headlamps | 16. Starter |
| 3. Battery relay | 17. F-R lever switch |
| 4. Fusible link | 18. Reverse alarm switch |
| 5. Horn | 19. Amplitude select valve (front) (selects rotating direction of vibrator drive motor) |
| 6. Alternator | 20. Frequency select valve (selects vibrator drive pump delivery) |
| 7. Amplitude select valve (rear) (selects rotating direction of vibrator drive motor) | 21. Brake release solenoid valve |
| 8. Thermo unit | 22. Vibrator switch |
| 9. Job lamp | 23. Frequency selector switch (selects vibrator drive pump delivery) |
| 10. Glow plug | 24. Amplitude selector switch (selects rotating direction of vibrator drive motor) |
| 11. Engine oil pressure switch | |
| 12. Engine stopper | |
| 13. Sprinkler pump (rear) | |
| 14. Reverse alarm | |


SW8002042

5-5. Description and operation of engine stopper

Description

- Operation of the starter switch alone starts and stops the engine. The major components of this device are the engine stopper and engine stop relay.

When starting the engine:



SW8002036

Operation


When starting:

- Turning the starter switch ON connects starter switch terminal B to terminal BR to energize the engine stop relay. In the engine stop relay, terminal 3 connects with terminal 5. The current flows as follows: Battery → Battery relay → Terminal A of engine stopper → Terminal B of engine stopper → Terminal (5) of engine stop relay → Terminal (3) of engine stop relay → Plus (+) terminal of motor in engine stopper.

The motor is driven. (The control cable is extended.) Terminal D rotates with the motor. When insulated part of terminal D reaches terminal B, the circuit between terminal A and terminal B is open to cut off the current from the battery.


The motor continues running by inertia. When the metal part of terminal D makes contact with terminal B, both poles of the motor are earthed to stop the motor.

- In this state, the control cable is extended completely, allowing the injection pump stop lever to stay in the operating position. The engine runs.

**When stopping:**


- Turning the starter switch OFF breaks the contact between terminal B and terminal BR, deenergizing the engine stop relay. The current is delivered in the sequence as in the following: Battery relay → Terminal A of engine stopper → Terminal C of engine stopper → Terminal (6) of engine stop relay → Terminal (3) of engine stop relay → Plus (+) terminal of motor in engine stopper. The motor runs. (The control cable is retracted.)
- Terminal D rotates with the motor. When the insulated portion of terminal D reaches terminal C, the circuit between terminal A and terminal B is open to cut off current from the battery. The motor continues running by inertia. When the metal portion of terminal D touches terminal C, both terminals of the motor lead to earth. The motor is shut down.
- In this condition, the control cable is completely retracted. The injection pump stop lever stays in the STOP position to cut off the fuel supply. The engine stops.

5-6. Electric wiring diagram [I] (SW800:To Machine No.10122 SW850:To Machine No.10126)



SW8002038

5-7. Electric wiring diagram [I] (SW800:From Mchine No.10123 SW850:From Machine No.10127)



SW8002039

INSPECTION & ADJUSTMENT

INSPECTION & ADJUSTMENT

1. Standard Value Chart

- 1-1. Standard value chart for engine, travel speed and hydraulic pressure (SW800)3-002
- 1-2. Standard value chart for engine, travel speed and hydraulic pressure (SW850)3-003

2. Inspection & Adjustment

- 2-1. Measurement and adjustment of pressure in propulsion main circuit3-102
- 2-2. Measurement of propulsion charge circuit pressure3-106
- 2-3. Measurement of parking brake release pressure3-108
- 2-4. Measurement and adjustment of vibrator circuit pressure3-109
- 2-5. Measurement of steering circuit pressure3-113
- 2-6. Throttle linkage adjustment3-114
- 2-7. F-R lever linkage adjustment3-115

★Precautions for Use of Standard Value Chart

- 1) Values in the chart are based upon ones when the machine leaves the factory. They should be used for estimation of wear after extended operation and for guidance when the machine is repaired.
- 2) Values in the chart are ones based on various test results etc. They should be used for a guide for fault finding practice in due consideration of the past repair frequency and operating record of the machine.
- 3) Values in the chart should not be used for the standard for claim application.

★Precautions for Checking, Adjustment and Fault Finding

- ⚠ For checking, adjustment and fault finding practices, park the machine on level ground and secure with the safety pins engaged.
- ⚠ When working with other workers, use hand signals positively and keep people not concerned away from the work area.
- ⚠ Cool off the coolant or hydraulic fluid when removing the radiator cap or the hydraulic tank filler cap. Hot fluids can burn you.
- ⚠ Do not put your hands close to parts in motion such as fan belts.

1. Standard Value Chart

1-1. Standard value chart for engine, travel speed and hydraulic pressure (SW800)

| Item | | Measuring conditions | Unit | Standard value for new machine | Permissible range | |
|--------------|--------------------------------|--|--|---|---|-------------------------|
| Engine | Speed | Low idle | min ⁻¹ (rpm) | 950 ± 25 | ← | |
| | | High idle | | 2580 ± $\begin{smallmatrix} 0 \\ 50 \end{smallmatrix}$ | ← | |
| | | Rated speed | | 2300 | — | |
| Travel speed | Forward | <ul style="list-style-type: none"> • Engine at full throttle • Coolant temp. : Green zone on gauge • Hydraulic oil working temperature : 50 ± 5°C {122±41°F} | km/h (mph) | 0 ~ 7.0 ± 1.5 {0 ~ 4.35 ± 0.93} | ← | |
| | | | | 2nd | 0 ~ 11.0 ± 1.5 {0 ~ 6.21 ± 0.93} | ← |
| | Reverse | | | 1st | 0 ~ 7.0 ± 1.5 {0 ~ 4.35 ± 0.93} | ← |
| | | | | 2nd | 0 ~ 11.0 ± 1.5 {0 ~ 6.21 ± 0.93} | ← |
| Oil pressure | Propulsion circuit | <ul style="list-style-type: none"> • Hydraulic oil working temperature : 50 ± 5°C {122±41°F} • For adjustment, see relevant items in this chapter, "INSPECTION AND ADJUSTMENT" | MPa (kgf/cm ²) {psi} | 37.2 ± $\begin{smallmatrix} 0 \\ 2.0 \end{smallmatrix}$ (380 ± $\begin{smallmatrix} 0 \\ 20 \end{smallmatrix}$) {5400 ± 280} | 34.3 (350) {4970} | |
| | | | | High relief pressure | 43.1 ± $\begin{smallmatrix} 0 \\ 2.0 \end{smallmatrix}$ (440 ± $\begin{smallmatrix} 0 \\ 20 \end{smallmatrix}$) {6260 ± 280} | 39.2 (400) {5690} |
| | | | | Charge relief pressure | 2.9 ± 0.3 (30 ± 3.0) {420 ± 42} | 2.0 (20) {280} |
| | Vibrator circuit | | | Main relief pressure | 17.2 ± 1.0 (175 ± 10) {2490 ± 140} | 20.6 (210) {2130} |
| | | | | Port relief pressure | 22.5 ± 1.0 (230 ± 10) {3270 ± 140} | 20.6 (210) {2980} |
| | Steering relief pressure | | | 18.1 ± 1.0 (185 ± 10) {2630 ± 140} | 16.7 (170) {2410} | |
| | Parking brake release pressure | | | 2.9 ± 0.3 (30 ± 3.0) {420 ± 42} | 2.0 (20) {280} | |

1-2. Standard value chart for engine, travel speed and hydraulic pressure (SW850)

| Item | | Measuring conditions | Unit | Standard value for new machine | Permissible range |
|--------------|--------------------------------|------------------------|--|---|-------------------------|
| Engine | Speed | Low idle | min ⁻¹ (rpm) | 800 ± 25 | ← |
| | | High idle | | 2580 ± $\frac{0}{50}$ | ← |
| | | Rated speed | | 2300 | — |
| Travel speed | Forward | 1st | km/h (mph) | 0 ~ 7.0 ± 1.5 {0 ~ 4.35 ± 0.93} | ← |
| | | 2nd | | 0 ~ 11.0 ± 1.5 {0 ~ 6.21 ± 0.93} | ← |
| | Reverse | 1st | | 0 ~ 7.0 ± 1.5 {0 ~ 4.35 ± 0.93} | ← |
| | | 2nd | | 0 ~ 11.0 ± 1.5 {0 ~ 6.21 ± 0.93} | ← |
| Oil pressure | Propulsion circuit | Cut off valve setting | MPa (kgf/cm ²) {psi} | 37.2 ± $\frac{0}{2.0}$ (380 ± $\frac{0}{20}$) {5400 ± 280} | 34.3 (350) {4970} |
| | | High relief pressure | | 43.1 ± $\frac{0}{2.0}$ (440 ± $\frac{0}{20}$) {6260 ± 280} | 39.2 (400) {5690} |
| | | Charge relief pressure | | 2.9 ± 0.3 (30 ± 3.0) {420 ± 42} | 2.0 (20) {280} |
| | Vibrator circuit | Main relief pressure | | 17.2 ± 1.0 (175 ± 10) {2490 ± 140} | 20.6 (210) {2130} |
| | | Port relief pressure | | 22.5 ± 1.0 (230 ± 10) {3270 ± 140} | 20.6 (210) {2980} |
| | Steering relief pressure | | | 18.1 ± 1.0 (185 ± 10) {2630 ± 140} | 16.7 (170) {2410} |
| | Parking brake release pressure | | | 2.9 ± 0.3 (30 ± 3.0) {420 ± 42} | 2.0 (20) {280} |

2. Inspection & Adjustment

2-1. Measurement and adjustment of pressure in propulsion main circuit

⚠ Park on level ground. Apply the parking brake. Stop the engine and block the wheels.

⚠ Make certain that the parking brake functions correctly.



★ Ensure that the propulsion charge circuit pressure is as specified.

1. Measurement

★ Hydraulic oil temperature: $50 \pm 5^{\circ}\text{C}$ ($122 \pm 41^{\circ}\text{F}$)

1-1. Cut off valve

- 1) Mount a pressure gauge to the couplings fitted in gauge ports (1) and (2) of the propulsion pump.
 - Port (1): for forward travel
 - Port (2): for reverse travel
 - Pressure gauge:
 - 0 ~ 60 MPa (0 ~ 600 kgf/cm²)
 - {0 ~ 9000 psi}
- 2) Apply the parking brake by operating the parking brake switch.
- 3) Start the engine and set the throttle to high idle.
- 4) Move the F-R lever so that the pressure in the port to be measured may build up. Take the pressure reading quickly. Immediately when the measurement has been taken, bring the lever to the neutral position.



1-2. High pressure relief valve

- 1) The gauge mounting procedure is the same as that in step 1-1-1) above.
- 2) Screw in adjust screw (5) of cut off valve (3) one full turn. Block the cut off valve.
 - ★ For the adjustment screw, see Fig. SW8003013.
- 3) Start the engine and set the throttle to high idle.

- 4) By the operation of the F-R lever, load the engine so that its revolution is reduced from high idle (2,580 min⁻¹) (2,580 rpm) to the rated speed (2,300 min⁻¹) (2,300 rpm). Read the pressure at the rated revolution and return the F-R lever to the neutral position as quickly as practicable.

★ **The procedure (Tilting the F-R lever → Reading the pressure → Bringing the F-R lever to neutral) should not exceed 3 seconds.**

- 5) When the measurement is complete, reset the cut off valve by screwing out cut off valve adjust screw (5) one full turn and tightening locknut (4).
- 6) Ensure that the cut off valve setting is correct by using procedures as described in steps 1-1-1) to 1-1-4) above.

2. Adjustment

If the measured value falls outside the permissible range, adjust as follows:

2-1. Cut off valve

- 1) If locknut (4) of cut off valve (3) has no signs of looseness, dismount and disassemble the cut off valve to clean.

Do not loosen locknut (4) to keep the setting unchanged.

★ **Renew parts having signs of damages.**

- Tightening torque:

Item (3): 22 N·m (224 kgf·cm) {16.2 lbf·ft}

Item (4): 35 N·m (357 kgf·cm) {25.8 lbf·ft}

★ **Carefully perform disassembly and reassembly taking necessary measures to prevent ingress of foreign matter.**

- 2) To adjust the setting, loosen locknut (4) and rotate adjust screw (5).


- Adjust screw rotation:

Clockwise → Pressure increases


Counterclockwise → Pressure decreases

- Increase or decrease in pressure per 1/4 turns of adjust screw:

2.28 MPa (23.3 kgf/cm²) {331 psi}



SW8003001



SW8003013

- 3) For the pressure measurement during the adjustment, use procedures as stated in step 1-1.
- 4) When the adjustment is complete, tighten locknut (4) and recheck to see if correctly adjusted.
- 5) If the valve is beyond adjustment, take necessary measures referring to relevant items in "TROUBLE-SHOOTING".

2-2. High pressure relief valve

- 1) Screw in adjust screw (4) of cut off valve (3) one full turn and block the cut off valve.
- 2) If locknut (11) of high pressure relief valve (7) (for forward travel) or of high pressure relief valve (8) (for reverse travel) has no signs of looseness, dismount and disassemble the high pressure relief valve. Do not loosen locknut (4) to keep the setting unchanged.

★ Renew parts having signs of damage.

• Tightening torque:

Items (7),(8)

150 N·m (1,530 kgf·cm) {110 lbf·ft}

Item (9)

100 N·m (1,020 kgf·cm) {73.8 lbf·ft}

Item (10)


50 N·m (510 kgf·cm) {36.9 lbf·ft}

Item (11)

20 N·m (204 kgf·cm) {14.8 lbf·ft}

★ Carefully perform disassembly and reassembly taking necessary measures to prevent ingress of foreign matter.

- 3) To adjust the setting, loosen locknut (11) and rotate adjust screw (12).
 - Adjust screw rotation:
 - Clockwise → Pressure increases
 - Counterclockwise → Pressure decreases
 - Pressure increase or decrease per 1/4 turns of adjust screw:
 - 4.9 MPa (50 kgf/cm²) {711 psi}



Inspection & Adjustment

- 4) For the pressure measurement during the adjustment, use procedures as described in step 1-2 above.
- 5) When the adjustment is complete, tighten locknut (11) and recheck to see if correctly adjusted.
- 6) When the adjustment is complete, bring the cut off valve to the correct setting by screwing out adjust screw (5) of the cut off valve one full turn and tightening locknut (4).
- 7) Recheck the setting of the cut off valve by using the procedures in steps 1-1-1) to 1-1-4) above.
- 8) If the valve is beyond adjustment, take necessary measures referring to relevant items in "TROUBLE-SHOOTING".



2-2. Measurement of propulsion charge circuit pressure

- ⚠ **Park the machine on level ground. Apply the parking brake. Stop the engine and block the wheels.**
- ★ **Because oil is supplied from the steering circuit, make sure, before the measurement, that the steering system works correctly.**
- ⚠ **Ensure that the neutral position of the F-R lever perfectly aligns with the neutral position of the pump swashplate.**

1. Measurement


★ **Hydraulic oil temperature: 50±5°C (122±41°F)**

- 1) Disconnect hose (13) running from propulsion to vibrator pump, and fit a pressure gauge with adapter (5).
 - Gauge port: G3/8
 - Pressure gauge: 0 ~ 5 MPa (0 ~ 50 kgf/cm²) {0 ~ 700 psi}
- 2) Start the engine and set the throttle to high idle.
- 3) The charge pressure will vary. Take the maximum pressure reading.



2. Adjustment

- 1) If locknut (15) of charge relief valve (14) has no signs of looseness, dismount, disassemble and clean the charge relief valve. Do not loosen locknut (15) to keep the setting unchanged.
 - ★ **Renew parts with signs of damage.**
 - Tightening torque:
 - Item (13) 70 N·m (714 kgf·cm) {51.7 lbf·ft}
 - Item (14) 44 N·m (449 kgf·cm) {32.5 lbf·ft}
 - ★ **Carefully perform disassembly and reassembly taking necessary measures to prevent ingress of foreign matter.**



- 2) To adjust the setting, loosen locknut (15) and rotate adjust screw (16).
 - Adjust screw rotation:
 - Clockwise → Pressure increases
 - Counterclockwise → Pressure decreases
 - Increase or decrease in pressure per 1/4 turns of adjust screw:
0.38 MPa (3.9 kgf/cm²) {55 psi}
- 3) For the pressure measurement during the adjustment, use procedures as described in steps 1-1) to 1-3) above.
- 4) When the adjustment is complete, tighten locknut (14) and recheck to see if correctly adjusted.
- 5) If the valve is beyond adjustment, take necessary measures referring to relevant items in "TROUBLE-SHOOTING".

2-3. Measurement of parking brake release pressure

⚠ Park on level ground. Apply the parking brake. Stop the engine and block the wheels.

★ Because the charge pressure is also used for releasing the brake, make sure, before the measurement, that the pressure to change the travel speed is correct.

1. Measurement

★ Hydraulic oil temperature: $50\pm 5^{\circ}\text{C}$ ($122\pm 41^{\circ}\text{F}$)



- 1) Disconnect brake release hoses (1) from the propulsion motor and fit a pressure gauge with adapter (4).

★ Plug the open port of the motor.

• Pressure gauge:

0 ~ 5 MPa (0 ~ 50 kgf/cm²) {0 ~ 700 psi}

- 2) Start the engine and set the throttle to high idle.
- 3) Make sure that the F-R lever stays in the neutral position.
- 4) Press down the parking brake switch to free the brake and read the pressure when the brake is released.



2-4. Measurement and adjustment of vibrator circuit pressure


▲ Park on level ground. Apply the parking brake. Stop the engine and block the wheels.

1. Measurement

★ Hydraulic oil temperature: 50±5°C (122±41°F)


1-1. Main relief valve

- 1) Remove plugs (1) and (2) from the vibrator pump motor and attach a pressure gauge with adapter ①.
 - Gauge port (1): Front
 - Gauge port (2): Rear
 - Pressure gauge:
 - 0 ~ 40 MPa (0 ~ 400 kgf/cm²) {0 ~ 6000 psi}
- 2) Disconnect hose (3) running from frequency select valve to vibrator motor. Plug the end of hose to block the line.



★ **Plug the open port of the motor.**

- 3) Operate the frequency selector switch and amplitude selector switch to select MEDIUM FREQUENCY and LOW AMPLITUDE respectively. **For the machines falling into the following machine numbers, select CONT mode by means of CONT/AUTO selector switch. SW800: From Machine No. 10123 SW850: From Machine No.10127.**




- 4) Start the engine and set the throttle to high idle.

- 5) Operate the vibrator by pressing the vibrator switch on top of the F-R lever. Measure the main relief pressure.

★ **Take the reading and shut down the vibrator as quickly as practicable.**

★ **The procedure (Starting the vibrator → Pressure measurement → Shutting down the vibrator) should not exceed 3 seconds.**



1-2. Port relief valve

1) The gauge points are the same as those of the main relief valve as described in steps 1-1-1) and 1-1-2) above.

2) Screw in adjusting screw (6) of main relief valve (4) by 1/2 turns, and block the main relief valve.

★For the adjust screw, see Fig. SW6503006.

3) Operate the frequency selector switch to select MEDIUM FREQUENCY. **For the machines of the following machine numbers, select CONT mode by means of the CON/AUTO selector switch.**
SW800: From Machine No.10123 SW850:
From Machine No.10127.

4) Start the engine and set the throttle to high idle.

5) Select HIGH AMPLITUDE by operating the amplitude selector switch. Operate the vibrator by pressing the vibrator switch on top of the F-R lever. Measure the port relief pressure in the HIGH AMPLITUDE port.

★Take the reading and shut down the vibrator as quickly as practicable.


6) Select LOW AMPLITUDE by operating the amplitude selector switch. Operate the vibrator by pressing the switch on top of the F-R lever. Measure the port relief pressure in LOW AMPLITUDE port.

★Take the reading and shut down the vibrator as quickly as practicable.

★The procedure (Starting the vibrator → Pressure measurement → Shutting down the vibrator) in steps 5) and 6) should not exceed 3 seconds.

7) When the measurement is complete, restore the standard setting by screwing out the adjusting screw of the main relief valve by 1/2 turns and tightening locknut (5).

8) Use the procedures in steps 1-1-3) to 1-1-5) above to recheck the main relief valve setting.



2. Adjustment

If measured pressures do not fall within the specified range, adjust as follows:

2-1. Main relief valve

1) If there is no signs of looseness in locknut (5) of main relief valve (4), dismount, disassemble and wash clean the main relief valve.

Do not loosen locknut (5) to keep the setting unchanged.

★ **Renew parts with signs of damages.**

• Tightening torque:

Item (4): 83 N·m (850 kgf·cm) {61 lbf·ft}

Item (5): 9.8 N·m (100 kgf·cm) {7.2 lbf·ft}

★ **Carefully perform disassembly and reassembly taking necessary means to avoid ingress of foreign matter.**

2) To adjust the setting, loosen locknut (5) and rotate adjusting screw (6).

• Adjusting screw:

Clockwise turn increases pressure.

Counterclockwise turn decreases pressure.


• Increase or decrease in pressure per 1/4 turns of adjust screw:

3.38 MPa (34.5 kgf/cm²) {490 psi}

3) Use the procedures in item 1-1 (Main relief valve) for pressure measurement during the setting adjustment.

4) When the adjustment is complete, tighten the locknut and recheck the setting.

★ **If the valve is beyond adjustment, take necessary measures referring to relevant instructions in the chapter, TROUBLESHOOTING.**



2-2. Port relief valve

- 1) Screw in adjust screw (6) of the main relief valve by 1/2 turns and block the main relief valve.
- 2) If there is no signs of looseness in locknut (10) of port relief valve (7) or (8), remove, disassemble and wash clean the high pressure relief valve.
Do not loosen locknut (10) to keep the setting unchanged.


★ Renew parts with signs of damages.

- Tightening torque:
 - Items (7),(8)
78.4 N·m (800 kgf·cm) {57.8 lbf·ft}
 - Item (9)
58.8 N·m (600 kgf·cm) {43.4 lbf·ft}
 - Item (10)
9.8 N·m (100 kgf·cm) {7.2 lbf·ft}

★ Carefully perform disassembly and reassembly taking necessary means to avoid ingress of foreign matter.

- 3) To adjust the setting, loosen locknut (10) and rotate adjusting screw (11).
 - Adjusting screw:
 - Clockwise turn increases pressure.
 - Counterclockwise turn decreases pressure.
 - Increase or decrease in pressure per 1/4 turns of adjust screw:
 - 5.5 MPa (56 kgf/cm²) {796 psi}
- 4) Use the procedures in item 1-2 (Port relief valve) for pressure measurement during the setting adjustment.
- 5) When the adjustment is complete, tighten the locknut and recheck the setting.
- 6) When the adjustment is complete, restore the standard setting of the main relief valve by screwing out adjusting screw (6) of the main relief valve by 1/2 turns, and tightening the locknut.
- 7) Use the procedures in steps 1-1-3) to 1-1-5) above to check to see if the main relief valve setting is as specified.

★ If the valve is beyond adjustment, take necessary measures referring to relevant instructions in the chapter, TROUBLESHOOTING.



2-5. Measurement of steering circuit pressure

▲ Park on level ground. Apply the parking brake. Stop the engine and block the wheels.

1. Measurement

★ Hydraulic oil temperature: 45 ~ 55°C (122±41°F)

★ Because the propulsion charge circuit makes use of the pressure of return oil from the steering circuit, check to see if the pressure in the propulsion charge circuit is normal.

1) Disconnect inlet hose (1) from the steering cylinder, and connect a pressure gauge to the hose end using adapter ⑤.

- Pressure gauge:
0 ~ 25 MPa (0 ~ 250 kgf/cm²) {0 ~ 3,500 psi}

2) Start the engine. Ensuring that the F-R lever is in the neutral position, set the throttle lever to high idle.



3) Rotate the steering wheel clockwise to full lock and take the reading of the pressure gauge.

★ Do not allow the relief valve to stay open longer than 3 seconds.

2. Adjustment

If the measured value is not within the permissible range, disassemble and clean the relief valve built in Orbitrol.

- ★ The valve is not adjustable.
- ★ Carefully perform disassembly and reassembly taking necessary means to avoid entry of foreign matter.
- ★ If the valve is beyond adjustment, take necessary measures referring to relevant instructions in the chapter, TROUBLESHOOTING.



2-6. Throttle linkage adjustment

★ When the throttle linkage has been renewed (or reconnected) or if the high idle or low idle rpm is not to specification, adjust as follows:

1. Adjustment

★ **Coolant temperature: Green area on gauge.**

- 1) Set throttle lever (1) to the low idle position.
- 2) Connect throttle cable (2) to fuel injection pump governor lever (3).
- 3) Start the engine. Slacken lock nut (4) and adjust stop bolt (5) until correct low idle revolution is reached.

★ **Low idle:**

SW800: $950 \pm 25 \text{ min}^{-1}$ (rpm)

SW850: $800 \pm 25 \text{ min}^{-1}$ (rpm)




- 4) With throttle lever (1) set to full throttle, loosen locknut (7) and adjust stop bolt (8) so that governor lever (3) makes contact with stopper (6) on the full throttle side.

- 5) Start the engine. Check that the high idle rpm is to specification.

★ **High idle: $2,580 \pm 50 \text{ min}^{-1}$ (rpm)**

◆ If high idle is lower than specified with governor lever (3) in contact with the stopper on the full throttle side, adjust the fuel injection nozzles or repair or renew the fuel injection pump.

★ **The engines of both SW800 and SW850 models are equipped with an exhaust gas control system, and are incapable of adjustment on the high idle side.**



2-7. F-R lever linkage adjustment

★ When the F-R lever linkage has been renewed (or reconnected) or if the F-R lever fails to move smoothly, adjust as described below:

1. Adjustment

★ Hydraulic oil temperature: $50\pm 50^{\circ}\text{C}$ ($122\pm 41^{\circ}\text{F}$)

★ Adjust the length of linkage between the F-R lever and pump control lever so that the pump control lever secures the correct neutral position with the F-R lever held in the neutral position. (F-R lever (1) is positively detent-positioned in the neutral, forward travel and reverse travel positions.)

1) Set the F-R lever to the correct neutral position. Adjust the length of rod (2) and cable (3) as shown.

• Length:

Rod (2) → 290 mm (11.41 in.)

Cable (3) → 401 mm (9.37 in.)



★ Make sure that the F-R lever moves smoothly.

2) Set pump control lever (4) to the neutral position. Connect the cable to the pump control lever with length 'a' adjusted by nuts (5).

3) Move the F-R lever to notch positions (forward and backward) to see if lever (4) certainly follows the F-R lever movement.

4) To adjust the neutral position, rotate nuts (5), while moving the F-R lever (neutral → forward → neutral → backward → neutral), so that the F-R lever travel from the neutral position to the position in which the machine starts traveling is equal for both forward and backward traveling.

★ Perform this adjustment on level and flat concrete pavement while varying the engine revolution in several steps ranging from low to high idles.



TROUBLESHOOTING

TROUBLESHOOTING

| | |
|---|-------|
| 1. Precautions for troubleshooting | 4-002 |
| 2. How to perform troubleshooting practice | 4-003 |
| 3. How to use this chapter, "TROUBLESHOOTING" and how to follow the flow chart | 4-004 |
| 4. Precautions for troubleshooting of electric system | 4-006 |
| 5. Troubleshooting for electric system (Mode E) | 4-201 |
| 6. Troubleshooting (Mode H) | 4-401 |

1. Precautions for Troubleshooting

- ⚠ **Park the machine on level ground. Make sure that the safety pins are engaged, wheels chocked and parking brake applied.**
- ⚠ **When working with other workers, use hand signals authorized, and keep people not concerned away from the work area.**
- ⚠ **If the radiator cap is carelessly removed from a hot engine, hot coolant will gush out to cause a burn. Remove the cap only when the engine has been cooled off.**
- ⚠ **Exercise care not to touch hot parts or not to be caught in rotating parts.**
- ⚠ **When disconnecting electric wires, disconnect the battery negative (-) cable.**
- ⚠ **When taking off plugs or caps from units which are under pressure such as hydraulic, water and air pressures, fit gauges after removing residual pressure.**

- Troubleshooting is to determine the root cause of troubles, repair faulty parts as quickly as practicable, and prevent recurrence of the troubles.
- Important when conducting troubleshooting practice is of course to well understand the structure and function of machines to be handled. For effective troubleshooting, however, it is of prime importance to have a clear picture of the trouble concerned by contacting the operator.

1. When a trouble has occurred, do not attempt to disassemble blindly.

Disassembling in a hurry will invite disadvantageous situations as described below:

- Parts which need not be disassembled may be disassembled.
- Tracing the cause of trouble will become more difficult.

These will cause increased service costs because of wasteful service hours, spare parts or expendables like oil or grease. To make matters worse, such a careless practice will invite operator's (customer's) distrust. For these reasons, sufficient advance investigations and diagnosis in accordance with troubleshooting procedures specified are essential for efficient fault finding practices.

2. Questions to be addressed to the operator (customer) .

- 1) Are there any trouble other than the one in question?
- 2) Was there any abnormal condition with the machine before the trouble occurs?
- 3) Did the trouble occur suddenly without signs of abnormal conditions in advance?
- 4) In what occasion did the trouble occur?
- 5) Has the machine been repaired before the trouble occurs? If so, when has it been repaired?
- 6) Did similar trouble occur in the past?

3. Before-diagnosis inspection

- 1) Perform daily inspections.
- 2) Perform other inspections required for diagnosis.

4. Confirmation of trouble

Know the degree of the trouble. Determine whether it is a trouble cause by improper design etc. or the trouble was caused by incorrect handling.

★ **When making the trouble reoccur in an attempt to trace the source of the trouble by putting the machine in motion, use care not to cause more damage to the machine.**

5. Troubleshooting

From the results of items 2 to 4 above, narrow down the cause of the trouble, and pinpoint the source of the trouble by utilizing the diagnosis flow chart.


★ **The basic points of the diagnosis are:**

- 1) Start from the simple portion.
- 2) Start from the portion having a high probability to solve the problem.
- 3) Investigate related matters.

6. Basic remedy for the trouble

Even if a trouble is rectified, it will develop again if its cause is not determined. It is of prime importance to trace the very cause of the trouble.

2. How to Diagnose the Machine



3. How to Use this Chapter, "TROUBLESHOOTING" and How to Follow the Troubleshooting Flow

1. Troubleshooting codes

- 1) Electric system: E-01 to E-15
- 2) Hydraulic and mechanical systems: H-01 to H-10

2. How to follow the troubleshooting flow

★ See example shown on page 4-005.

① Troubleshooting code No. and fault symptom

On top of the flow chart are code No. and fault symptom.

② General precautions

Under the code and fault symptom are precautions (with mark ★) common to the whole items in the flow chart. Though these precautions are not indicated inside each box (□) which contains checking instructions, pay attention to these precautions when making inspections described in the box (□).


③ Sub classification

To make diagnosis easier or for simplified flow chart, fault symptom is subclassed. Ex. a) Starter does not run

④ How to forward the diagnosis

- Each box (□) contains diagnosis procedure. Depending upon these results of inspection or measurement, proceed to YES or NO line.
- Normally, if the result is YES then proceed to upper line. If NO then go to the lower line.

NOTE: The number above each box (□) is a reference number. It does not mean a sequence in which diagnoses proceed.



- As a result of a diagnosis, if YES line or NO line directly goes to the description in CAUSE column, take necessary action as indicated in REMEDY column.
- Under each box (□) are normal values and conditions necessary for inspection and adjustment. If the result gives an affirmative answer to the question in the box or agrees with the normal value indicated under the box, go to YES line. Otherwise, go to NO line.
- The normal values were taken from the standard value list.
- For locations of component parts such as relay mentioned in the flow chart, see drawings which show locations of key units. Line colors mentioned in the flow charts are indicated in the electric wiring diagram shown under the flow charts. In the actual machine, each harness is identified by color.


① **E-07 Head lamps do not operate**

- ② ★Measure the voltage with the starter switch ON.
 ★Before diagnosis, check to see if the fuse has burnt.

- ③ b) Either right or left lamp does not light
 * Wire color codes in parentheses (): SW800 → To Machine No.10122
 SW850 → To Machine No.10126

Codes with no parentheses → Common to both models

④



4. Precautions for Diagnosis of Electric Circuit

1. When disconnecting or connecting connectors or harnesses, cut the power supply.
2. Before making a diagnosis, check the connectors or harnesses for poor connection.
★ If a connector is at fault, check it by repeating connection and disconnection several times.
3. Before proceeding to the next step, reconnect removed connectors or harnesses in place.
★ Care must be used for the controller circuit. If the power source is switched on with the connector disconnected, this can cause an incorrect measurement.
4. When making a diagnosis of circuits (measurement of voltage, resistance, current, test for continuity, etc.), check to see if tester readings vary by shaking connectors or harnesses.
★ If readings vary, a possible cause is a poor connection of the circuit.
5. For voltage measurement, turn the starter switch ON. For resistance checking, let the switch stay in the Off position.
★ If necessary to take a measurement of resistance by energizing relays or other units with the starter switch ON, necessary instructions are given in the flow charts.

5. Troubleshooting for Electric System (Mode E)

E-01 Engine does not start4-202
 E-02 Engine does not stop4-207
 E-03 Glow plugs do not become red-hot (Engine is hard to start)4-208
 E-04 No charging (charge lamp stays bright.)4-210
 E-05 Reverse alarm does not sound4-211
 E-06 Horn does not sound4-212
 E-07 Headlamps do not operate4-214
 E-08 Job lamps do not come on4-220
 E-09 Vibrator does not operate (Modes E-09 a) to mode E-09 e) are
 common to both models)4-225
 E-10 Parking brake not released4-234
 E-11 Sprinkler is inoperative4-237
 E-12 Fuel gauge reads wrong4-243
 E-13 Coolant temperature gauge reads wrong4-244
 E-14 Tachometer reads wrong4-245
 E-15 Charge warning Lamp, engine oil pressure warning lamp,
 hydraulic oil filter warning lamp and parking brake indicator lamp
 do not come on with starter switch ON4-246

Wire color code

| | | | | | | | | | | | |
|-----|-------------------------|-----|-------------------------|-----|------------------------------|-----|-------------------------------|----|-------------------------|----|-------------------------|
| B | Black | BrY | Brown/ Yellow stripe | L | Blue | LgW | Light green/ White stripe | W | White | YG | Yellow/ Green stripe |
| BR | Black/ Red stripe | G | Green | LB | Blue/ Black stripe | LgY | Light green/ Yellow stripe | WB | White/ Black stripe | YL | Yellow/ Blue stripe |
| BW | Black/ White stripe | GB | Green/ Black stripe | LR | Blue/ Red stripe | R | Red | WG | White/ Green stripe | YR | Yellow/ Red stripe |
| BY | Black/ Yellow stripe | GL | Green/ Blue stripe | LW | Blue/ White stripe | RB | Red/ Black stripe | WL | White/ Blue stripe | YW | Yellow/ White stripe |
| Br | Brown | GR | Green/ Red stripe | LY | Blue/ Yellow stripe | RG | Red/ Green stripe | WR | White/ Red stripe | Gy | Gray |
| BrB | Brown/ Black stripe | GW | Green/ White stripe | Lg | Light green | RL | Red/ Blue stripe | WY | White/ Yellow stripe | O | Orange |
| BrR | Brown/ Red stripe | GY | Green/ Yellow stripe | LgB | Light green/ Black stripe | RW | Red/ White stripe | Y | Yellow | Sb | Sky blue |
| BrW | Brown/ White stripe | | | LgR | Light green/ Red stripe | RY | Red/ Yellow stripe | YB | Yellow/ Black stripe | P | Pink |

E-01 Engine does not start


★Set the F-R lever to the neutral position.

★For voltage measurement, turn the starter switch ON.

* Wire color codes in parentheses (): SW800 → From Machine No.10123
 SW850 → From Machine No.10127


Wire color codes having no parentheses → Common to both models

a) Starter is inoperative. (1/2)



| | Possible cause | Remedy |
|--|--|--|
| | Starter faulty. | Renew. |
| | Wire from safety relay terminal C to starter terminal C not connected or incorrectly connected. | Repair or renew wire. |
| <p style="text-align: center;">7</p> <p style="text-align: center;">YES</p> | To A on page 4-204 | |
| <p style="text-align: center;">6</p> <p style="text-align: center;">YES</p> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;"> <p>Is specified voltage fed to safety relay terminal B?</p> <ul style="list-style-type: none"> • 20~28V </div> <p style="text-align: center;">NO</p> | <p>Wire from starter terminal B to safety relay terminal B not connected or incorrectly connected.</p> <p>Alternator faulty (including regulator).</p> | <p>Repair or renew wire.</p> <p>Renew.</p> |
| | Wire B from battery relay to starter not connected or incorrectly connected. | Repair or renew wire. |
| | Battery relay contact faulty. | Renew. |
| | Battery relay coil faulty. | Renew. |
| | Wire BR or RB(BrY) from starter switch terminal BR to battery relay terminal BR not connected or incorrectly connected (including diode). | Repair or renew wire. |
| | Starter switch faulty (between terminals B and BR). | Renew. |
| <p style="text-align: center;">16</p> <p style="text-align: center;">YES</p> | Wire BY(L) or WG from battery relay to starter switch terminal B not connected or incorrectly connected. | Repair or renew wire. |
| <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;"> <p>Is specified voltage fed to battery relay terminal that carries wire WG?</p> <ul style="list-style-type: none"> • 20~28V </div> <p style="text-align: center;">NO</p> | Wire from battery to battery relay not connected or incorrectly connected. | Repair or renew cable. |
| | Battery capacity lowered. | Charge or renew. |

a) Starter is inoperative. (2/2)




Electric wiring diagram for mode E-01 (a)

* Wire color codes in parentheses (): SW800 → From Machine No.10123

SW850 → From Machine No.10127

Codes with no parentheses → Common to both models



SW800: From Machine No.10123
 SW850: From Machine No.10127

SW8004001


b) Engine stopper does not operate.

* Wire color codes in parentheses (): SW800 → From Machine No.10123
 SW850 → From Machine No.10127

Codes with no parentheses → Common to both models

★It is assumed that the starter operation is normal.

★Measure the voltage with the starter switch ON.




Electric wiring diagram for mode E-01 (b) and E-02

* Wire color codes in parentheses (): SW800 → From Machine No.10123

SW850 → From Machine No.10127

Codes with no parentheses → Common to both models



SW8004002


E-02 Engine does not stop

★ Measure the voltage with the starter switch OFF.

* Wire color codes in parentheses (): SW800 → From Machine No.10123

SW850 → From Machine No.10127

Codes with no parentheses → Common to both models



E-03 Glow plugs do not become red-hot (Engine is hard to start)

★It is assumed that the starter operation is normal.


★Measure the voltage with the starter switch ON.

* Wire color codes in parentheses (): SW800 → From Machine No.10123
 SW850 → From Machine No.10127

Codes with no parentheses → Common to both models

a) Glow indicator does not become bright.

★The glow indicator should become bright when the starter switch is turned to the HEAT position, and come off when preheating is complete.



b) Indicator becomes bright, but engine does not start smoothly.




Electric wiring diagram for mode E-03

* Wire color codes in parentheses (): SW800 → From Machine No.10123

SW850 → From Machine No.10127

Codes with no parentheses → Common to both models



SW8004003

E-04 No charging (charge lamp stays bright.)

★The voltage measurement should be taken with the starter switch ON.

★First, check to see if fuse has burnt.


| | | Possible cause | Remedy |
|--|-----|---|-----------------------|
| <p>1</p> <p>Does specified voltage appear at alternator terminal L that carries wire LgB?</p> <ul style="list-style-type: none"> • 27.5~29.5V • Run engine at higher than medium speed. <p>NO</p> <p>2</p> <p>Does specified voltage appear at alternator terminal B that carries wire R?</p> <ul style="list-style-type: none"> • 20~28V • Turn starter switch ON. <p>NO</p> <p>3</p> <p>Is resistance of alternator earth wire as specified?</p> <ul style="list-style-type: none"> • Lower than 1Ω • Disconnect wire from alternator. <p>NO</p> | YES | Lamp check relay faulty. | Renew. |
| | YES | Alternator faulty. | Renew. |
| | NO | Alternator earth wire not connected or incorrectly connected. | Repair or renew wire. |
| | NO | Wire R or Y from battery to alternator terminal B not connected or incorrectly connected. | Repair or renew wire. |

Electric wiring diagram for mode E-04

* Wire color codes in parentheses (): SW800 ⇒ From Machine No.10123

SW850 ⇒ From Machine No.10127

Codes with no parentheses ⇒ Common to both models



SW8004004

E-05 Reverse alarm does not sound

★First, check that the fuse is not blown.

★The voltage measurement should be taken with the starter switch ON.

* Wire color codes in parentheses (): SW800 → From Machine No.10123
 SW850 → From Machine No.10127


Codes with no parentheses → Common to both models

| | | Possible cause | Remedy |
|--|---|--|-----------------------|
| <p>1</p> <p>Does specified voltage appear at reverse alarm terminal that carries wire RY?</p> <ul style="list-style-type: none"> • 20~28V • Move F-R lever to Backward. | <p>2 YES</p> <p>Is resistance of reverse alarm earth wire as specified?</p> <ul style="list-style-type: none"> • Less than 1Ω • Disconnect wire from reverse alarm. | Reverse alarm faulty. | Renew. |
| | NO | Reverse alarm earth wire not connected or incorrectly connected. | Repair or renew wire. |
| | <p>3</p> <p>Does specified voltage appear at reverse alarm switch terminal that carries wire RY?</p> <ul style="list-style-type: none"> • 20~28V • Move F-R lever to Backward. | Wire RY from reverse alarm switch to reverse alarm not connected or incorrectly connected. | Repair or renew wire. |
| | <p>4 YES</p> <p>Does specified voltage appear at reverse alarm switch terminal that carries wire RW(WG)?</p> <ul style="list-style-type: none"> • 20~28V | Reverse alarm switch faulty. | Renew. |
| | NO | Wire RW(WG) from reverse alarm switch to fuse not connected or incorrectly connected. | Repair or renew wire. |

Electric wiring diagram for mode E-05

* Wire color codes in parentheses (): SW800 → From Machine No.10123
 SW850 → From Machine No.10127

Codes with no parentheses → Common to both models



SW8004005

E-06 Horn does not sound

★First, check that fuse is not blown.

★Take the voltage measurement with the starter switch ON.

* Wire color codes in parentheses (): SW800 → From Machine No.10123

SW850 → From Machine No.10127

Codes with no parentheses → Common to both models


| | | Possible cause | Remedy |
|--|--|---|-----------------------|
| <p>1 YES</p> <p>Is stated voltage present at horn terminal that carries wire Lg?</p> <ul style="list-style-type: none"> • 20~28V • Switch ON horn switch. | <p>2 YES</p> <p>Is resistance of horn earth wire as specified?</p> <ul style="list-style-type: none"> • Lower than 1Ω • Disconnect wire from horn. | Horn faulty. | Renew. |
| | <p>NO</p> <p>3 YES</p> <p>Is stated voltage present at horn relay terminal 5 that carries wire Lg?</p> <ul style="list-style-type: none"> • 20~28V • Switch ON horn switch. | Horn earth wire not connected or incorrectly connected. | Repair or renew wire. |
| | <p>NO</p> <p>4 YES</p> <p>Is stated voltage present at horn relay terminals 2 and 3 that carry wire RW(WG)?</p> <ul style="list-style-type: none"> • 20~28V | Wire Lg from horn to horn relay terminal not connected or incorrectly connected. | Repair or renew wire. |
| | <p>NO</p> <p>5 YES</p> <p>Is resistance between horn switch terminals normal?</p> <ul style="list-style-type: none"> • Switch OFF horn switch. • Lower than 1Ω • Disconnect earth wire from horn switch. | To "A" on this page | |
| | <p>NO</p> <p>6 YES</p> <p>Is resistance of horn switch earth wire as specified?</p> <ul style="list-style-type: none"> • Lower than 1Ω • Disconnect earth wire from horn switch. | Wire RW(WG) from horn relay terminals 2 and 3 to fuse not connected or incorrectly connected. | Repair or renew wire. |
| | <p>NO</p> <p>7 YES</p> <p>Is stated voltage present at horn switch terminal that carries wire GR?</p> <ul style="list-style-type: none"> • 20~28V • Switch OFF horn switch. | Horn switch faulty. | Renew. |
| | <p>NO</p> <p>8 YES</p> <p>Is stated voltage present at horn relay terminal 1 that carries wire GR?</p> <ul style="list-style-type: none"> • 20~28V • Switch OFF horn switch. | Horn switch earth wire not connected or incorrectly connected. | Repair or renew wire. |
| | <p>NO</p> <p>8 NO</p> | Horn switch faulty. | Renew. |
| <p>A</p> <p>Is stated voltage present at horn switch terminal that carries wire GR?</p> <ul style="list-style-type: none"> • 20~28V • Switch OFF horn switch. | Wire GR from horn relay terminal 1 to horn switch not connected or incorrectly connected. | Repair or renew wire. | |
| | | Horn relay faulty. | Renew. |

Electric wiring diagram for mode E-06

* Wire color codes in parentheses (): SW800 → From Machine No.10123

SW850 → From Machine No.10127

Codes with no parentheses → Common to both models



SW8004015


E-07 Headlamps do not operate

★Measure the voltage with the starter switch ON.

★Before diagnosis, check to see if the fuse has burnt.

a) Lamp on each side does not come on.

(SW800: To Machine No.10122 SW850: To Machine No.10126)



| | | Possible cause | Remedy |
|---|-----|---|-----------------------|
| | | Lamp switch defective. | Renew. |
| | | Wire RY from fuse to lamp switch terminals 1 and 4 not connected or incorrectly connected. | Repair or renew wire. |
| | | Relay defective. | Renew. |
| <p>6</p> <p>Is resistance of relay earth wire as specified?</p> <p>• Lower than 12V</p> | YES | Wire RB from relay terminal 5 to head lamp (to branch point) not connected or incorrectly connected. | Repair or renew wire. |
| | NO | Relay earth wire not connected or incorrectly connected. | Repair or renew wire. |
| <p>7</p> <p>Is stated voltage fed to lamp switch terminal 6 that carries wire BrY?</p> <p>• 20~28V • Set lamp switch to low beam.</p> | YES | Wire BrY from lamp switch terminal 6 to relay terminal 1 not connected or incorrectly connected. | Repair or renew wire. |
| | NO | Lamp switch defective. | Renew. |
| | | Lamp switch defective. | Renew. |
| | | Wire RY from lamp switch terminal 1 to fuse (from branch point) not connected or incorrectly connected. | Repair or renew wire. |
| | | Wire RW from lamp switch terminal 5 to lamp (to branch point) not connected or incorrectly connected. | Repair or renew wire. |
| | | Lamp switch defective. | Renew. |

b) Either right or left lamp does not light

* Wire color codes in parentheses (): SW800 → To Machine No.10122


SW850 → To Machine No.10126

Codes with no parentheses → Common to both models

| | Possible cause | Remedy |
|--|---|---|
| <p>1</p> <p>Has filament of bulb burnt?</p> <p>YES</p> | Filament has burnt. | Renew. |
| <p>2</p> <p>Is stated voltage fed to inoperative lamp terminal that carries wire RB(RW)?</p> <p>YES</p> <p>NO</p> <ul style="list-style-type: none"> • 20~28V • Switch ON lamp switch. | <p>Lamp earth wire not connected or incorrectly connected.</p> <p>High beam: Wire RW from lamp to lamp switch terminal 5 (from branch point) not connected or incorrectly connected.</p> <p>Low beam: Wire RB from lamp to relay terminal 5 (from branch point) not connected or incorrectly connected.</p> | <p>Repair or renew wire.</p> <p>Repair or renew wire.</p> |


Electric wiring diagram for mode E-07 (a), (b)

(SW800: To Machine No.10122 SW850: To Machine No.10126)



SW8004006

c). Both left and right lamps do not come on
 (SW800: From Machine No.10123 SW850: From Machine No. 10127).




d) Either left or right lamp does not light.

* Wire color codes in parentheses ():

SW800 → From Machine No.10123


SW850 → From Machine No.10127

Codes with no parentheses → Common to both models



Electric wiring diagram for mode E-07 (c), (d)

(SW800: From Machine No.10123 SW850: From Machine No.10127)



SW8004016


E-08 Job lamps do not come on

★Measure the voltage with the starter switch ON.

★First, check to see if the fuse has burnt.

a) Both left and right lamps do not come on.

(SW800: To Machine No.10122 SW850: To Machine No.10126)



| | | Possible cause | Remedy |
|---|-----|--|-----------------------|
| | | Job lamp switch defective. | Renew. |
| | | Wire RY from fuse to job lamp switch terminals 1 and 4 not connected or incorrectly connected. | Repair or renew wire. |
| | | Job lamp relay defective. | Renew. |
| <p>6</p> <p>Is resistance of job lamp relay earth wire as specified?</p> <p>• Lower than 12V</p> | YES | Wire O from job lamp relay terminal 5 to job lamps (to branch point) not connected or incorrectly connected. | Repair or renew wire. |
| | NO | Job lamp relay earth wire not connected or incorrectly connected. | Repair or renew wire. |
| <p>7</p> <p>Is stated voltage fed to job lamp switch terminal 6 that carries wire YB?</p> <p>• 20~28V • Set job lamp switch to Low.</p> | YES | Wire YB from job lamp switch terminal 6 to job lamp relay terminal 1 not connected or incorrectly connected. | Repair or renew wire. |
| | NO | Job lamp switch defective. | Renew. |
| | | Job lamp switch defective. | Renew. |
| | | Wire RY from job lamp switch terminal 1 to fuse (from branch point) not connected or incorrectly connected. | Repair or renew wire. |
| | | Wire RL from job lamp switch terminal 5 to lamps (to branch point) not connected or incorrectly connected. | Repair or renew wire. |
| | | Job lamp switch defective. | Renew. |

b) Either left or right lamp does not come on.

* Wire color codes in parentheses (): SW800 → To Machine No.10122


SW850 → To Machine No.10126

Codes with no parentheses → Common to both models

| | Possible cause | Remedy |
|---|--|---|
| <p>1</p> <p>Has filament of bulb burnt?</p> <p>YES</p> | Bulb filament has burnt. | Renew. |
| <p>2</p> <p>Is stated voltage fed to job lamp (in-operative) terminal that carries wire RL (O)?</p> <p>YES</p> <p>NO</p> <ul style="list-style-type: none"> • 20~28V • Switch on job lamp switch. | <p>Job lamp earth wire not connected or incorrectly connected.</p> <p>High beam: Wire RL from job lamp to job lamp switch terminal 5 (from branch point) not connected or incorrectly connected.</p> <p>Low beam: Wire O from job lamp to relay terminal 5 (from branch point) not connected or incorrectly connected.</p> | <p>Repair or renew wire.</p> <p>Repair or renew wire.</p> |


Electric wiring diagram for mode E-08

(SW800: To Machine No.10122 SW850: To Machine No.10126)



c). Both lamps do not come on.

(SW800: From Machine No.10123 SW850: From Machine No. 10127).




d) Either left or right lamp does not come on.

* Wire color codes in parentheses ():

SW800 → From Machine No.10123


SW850 → From Machine No.10127

Codes with no parentheses → Common to both models



Electric wiring diagram for mode E-08 (c), (d)

(SW800: From Machine No.10123 SW850: From Machine No.10127)



E-09 Vibrator does not operate (Modes E-09 a) to mode E-09 e) are common to both models)

★Measure the voltage with the starter switch ON.

★First, check that fuse has not burnt.

a). Both left and right side vibrators are inoperative.

* Wire color codes in parentheses (): SW800 → To Machine No.10122
 SW850 → To Machine No.10126

Codes with no parentheses → Common to both models


| | | Possible cause | Remedy |
|--|-----|--|--|
| <p>1</p> <p>Is stated voltage present at vibrator switch terminal that carries wire Br?</p> <p>• 20~28V • Switch on vibrator switch.</p> | YES | Wire Br from vibrator switch to amplitude selector switch (to branch point) not connected or incorrectly connected. | Repair or renew wire. |
| | NO | <p>2 YES</p> <p>Is stated voltage present at vibrator switch terminal that carries wire LR(G)?</p> <p>• 20~28V</p> <p>NO</p> | Vibrator switch defective. |
| | | | <p>*1: Wire LR from fuse to vibrator switch not connected or incorrectly connected.</p> <p>*2: Wire G from CONT/AUTO selector switch terminal 3 to F-R lever switch (vibrator switch) not connected or incorrectly connected. See Electric wiring diagram for modes E-09 (f), (g) and (h).</p> |

*1: SW800 To Machine No.10122 SW850 To Machine No.10126
 *2: SW850 From Machine No.10123 SW850 From Machine No.10127

Electric wiring diagram for mode E-09 (a), (b), (c), (d) and (e)

* Wire color codes in parentheses (): SW800 → From Machine No.10123
 SW850 → From Machine No.10127

Codes with no parentheses → Common to both models



SW8004008

Troubleshooting for Electric System

b). LOW amplitude not selected.


* Wire color codes in parentheses (): SW800 → From Machine No.10123

SW850 → From Machine No.10127

Codes with no parentheses → Common to both models

Solenoid code letters in brackets [] indicate solenoids for rear vibrators

★Diagnose with vibrator switch ON.



*1 Solenoids which function when Low amplitude is selected.

(SW800: To Machine No.10122 SW850: To Machine No.10126)

- Front: b Wire color code WB
- Rear: a Wire color code LgY

(SW800: From Machine No.10123 SW850 From Machine No.10127)

- Front: b Wire color code WB
- Rear: b Wire color code LgY

*2 Color code of wire connected to amplitude selector switch terminal 2


- Front: WB(LR)
- Rear: LgY

*3 Color code of wire connected to amplitude selector switch terminal 1

- Front: Br
- Rear: Br

c). HIGH amplitude not selected.
Solenoid code letters in brackets [] solenoids for rear vibrators

★Diagnose with vibrator switch ON.



*1 Solenoids which function when HIGH amplitude is selected.
(SW800: To Machine No.10122 SW850: To Machine No.10126)

- Front: a Wire color code GL
- Rear: b Wire color code YR

(SW800: From Machine No.10123 SW850 From Machine No.10127)

- Front: a Wire color code GL
- Rear: a Wire color code YR

*2 Color code of wire connected to amplitude selector switch terminal 5

- Front: GL
- Rear: YR

*3 Color code of wire connected to amplitude selector switch terminal 4


- Front: Br
- Rear: Br

d). LOW frequency (\wedge) not selected.

* Wire color codes in parentheses (): SW800 → From Machine No.10123
 SW850 → From Machine No.10127

Codes with no parentheses → Common to both models

★To diagnose, set amplitude selector switch to LOW or HIGH. (LOW frequency is not influenced by the amplitude selector switch.)




e). Medium frequency (\surd) not selected.

* Wire color codes in parentheses (): SW800 → From Machine No.10123
 SW850 → From Machine No.10127

Codes with no parentheses → Common to both models

★Diagnose with amplitude selector switch set to LOW, because this circuit is influenced by signals from amplitude selector switch in the front vibrator circuit.




f). Neither CONT mode nor AUTO mode is inoperative.
 (SW800: From Machine No.10123 SW850: From Machine No. 10127).

| | Possible cause | Remedy |
|---|---|-----------------------|
| <p>1 YES</p> <p>Is stated voltage present at CONT/AUTO selector switch terminal 1 that carries wire YW?</p> | CONT/AUTO selector switch defective. | Renew. |
| <p>NO</p> <ul style="list-style-type: none"> • 20~28V • Switch on vibrator switch. • Select CONT and AUTO modes. | Wire YW from fuse to vibrator switch not connected or incorrectly connected (including fuse). | Repair or renew wire. |

g). CONT mode is not selected in both forward and reverse travel.
 (SW800: From Machine No.10123
 SW850: From Machine No. 10127)

| | Possible cause | Remedy |
|--|--|-----------------------|
| <p>1 YES</p> <p>Is stated voltage present at vibrator switch terminal that carries wire Br?</p> | Wires Br from vibrator switch to amplitude selector switch terminals 1 and 4 (to branch point) not connected or incorrectly connected. | Repair or renew wire. |
| <p>NO</p> <ul style="list-style-type: none"> • 20~28V • CONT/AUTO selector switch: CONT • Vibrator switch: ON | Vibrator switch defective. | Renew. |
| <p>2 YES</p> <p>Is stated voltage present at vibrator switch terminal that carries wire G?</p> | Wire G from CONT/AUTO selector switch to vibrator switch (to branch point) not connected or incorrectly connected. | Repair or renew wire. |
| <p>NO</p> <ul style="list-style-type: none"> • 20~28V • CONT/AUTO selector switch: CONT | CONT/AUTO selector switch defective. | Renew. |
| <p>3 YES</p> <p>Is stated voltage present at CONT/AUTO selector switch terminal 3 that carries wire G?</p> | | |
| <p>NO</p> <ul style="list-style-type: none"> • 20~28V | | |

h). AUTO mode is not selected.
 (SW800: From Machine No.10123 SW850: From Machine No. 10127).




| | Possible cause | Remedy |
|---|--|-----------------------|
| | Wire Br from vibration relay (4) terminal 5 to amplitude selector switch terminals 1 and 4 not connected or incorrectly connected. | Repair or renew wire. |
| | Vibration relay (4) defective. | Renew. |
| | Vibration relay (4) earth wire not connected or incorrectly connected. | Repair or renew wire. |
| | Wire O from starter motor relay terminal 2 to vibration relay (4) terminal 2 not connected or incorrectly connected. | Repair or renew wire. |
| | Starter motor relay contact sticking. | Renew. |
| <p>7 YES</p> <p>Is stated voltage present at starter motor relay (4) terminal 5 that carries wire LB?</p> <p>• Lower than 1V</p> | | |
| | Diode included in wire LB from starter switch terminal C to F-R lever switch defective. | Repair or renew wire. |
| <p>8 YES</p> <p>Is stated voltage present at F-R lever switch terminal that carries wire Gy?</p> <p>• 20~28V • F-R lever: Move forward or backward.</p> | Wire Gy from F-R lever switch to starter motor relay terminal 3 not connected or incorrectly connected. | Repair or renew wire. |
| | F-R lever switch defective. | Renew. |
| <p>9 YES</p> <p>Is stated voltage present at F-R lever switch terminal that carries wire GW?</p> <p>• 20~28V</p> | Wire GW from fuse to F-R lever switch not connected or incorrectly connected. | Repair or renew wire. |
| | Wire P from CONT/AUTO selector switch terminal 2 to vibration relay (4) terminal 3 not connected or incorrectly connected. | Repair or renew wire. |
| | CONT/ AUTO selector switch defective. | Renew. |

E-10 Parking brake not released

* Wire color codes in parentheses (): SW800 → From Machine No.10123
 SW850 → From Machine No.10127

Codes with no parentheses → Common to both models

- ★The foot brake switch normally closes. It opens if the brake pedal is depressed.
- ★Diagnose with the parking brake switch ON, and the brake pedal not depressed.
- ★Measure the voltage with the starter switch ON.
- ★First, check to see if fuse has burnt.




| | Possible cause | Remedy |
|--|---|-----------------------|
| | Brake release solenoid valve defective. (See mode H-09.) | |
| | Brake release valve solenoid defective. | Renew. |
| | Brake release valve solenoid earth wire not connected or incorrectly connected. | Repair or renew wire. |
| | Wire Br from brake release valve solenoid to brake relay terminal 5 not connected or incorrectly connected. | Repair or renew wire. |
| | Brake relay defective. | Renew. |
| | Brake relay earth wire not connected or incorrectly connected. | Repair or renew wire. |
| | Wire LgR from foot brake switch terminal 2 not connected or incorrectly connected. | Repair or renew wire. |
| <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-right: 5px;">Is specified voltage present at foot brake switch terminal that carries wire RG(WY)?</div> <div style="margin-right: 5px;">9</div> <div style="border-left: 1px solid black; border-right: 1px solid black; padding: 0 5px;">YES</div> </div> | Foot brake switch defective. | Renew. |
| | Wire RG(WY) from fuse to foot brake switch not connected or incorrectly connected. | Repair or renew wire. |
| | Wire Y from parking brake switch terminal 3 to brake relay terminal 3 not connected or incorrectly connected. | Repair or renew wire. |
| | Parking brake switch defective. | Renew. |
| <div style="display: flex; align-items: center;"> <div style="border-left: 1px solid black; border-right: 1px solid black; padding: 0 5px;">NO</div> </div> | Wire RG(WY) from fuse to parking brake switch terminal 1 not connected or incorrectly connected. | Repair or renew wire. |

Electric wiring diagram for mode E-10

* Wire color codes in parentheses (): SW800 → From Machine No.10123

SW850 → From Machine No.10127

Codes with no parentheses → Common to both models



SW8004010

E-11 Sprinkler is inoperative

★Measure the voltage with the starter switch ON.

★Check that the fuse is not damaged.

a). CONT mode is not selected.


(SW800: To Machine No.10122 SW850: To Machine No. 10126).

* The diagnosis procedures below are for the rear vibrator. The wire color codes enclosed in brackets [] are for the front vibrator.

| | | Possible cause | Remedy | | | | |
|--|-----|----------------|--|---|--|---|-----------------------|
| <p>1</p> <p>Is specified voltage present at sprinkler pump terminal that carries wire Y [W]?</p> <ul style="list-style-type: none"> • 20~28V • Operate sprinkler switch. | YES | 2 | YES | Sprinkler pump faulty. | Renew. | | |
| | | | NO | <ul style="list-style-type: none"> • Lower than 1 Ω • Disconnect wire from pump. | Sprinkler pump earth wire not connected or incorrectly connected. | Repair or renew wire. | |
| | NO | 3 | YES | <ul style="list-style-type: none"> • 20~28V • Operate sprinkler switch. | Wire Y[W] from sprinkler pump to sprinkler relay terminal 5 not connected or incorrectly connected. | Repair or renew wire. | |
| | | | NO | 4 | YES | To 'A' on this page | |
| | | | | NO | <ul style="list-style-type: none"> • 20~28V | Wire LW[LW] from sprinkler relay terminal 3 to fuse (from branch point) not connected or incorrectly connected. | Repair or renew wire. |
| | | | | | | | |
| | 5 | 6 | YES | <ul style="list-style-type: none"> • 20~28V • Operate sprinkler switch. | Sprinkler relay faulty (coil or contact). | Renew. | |
| | | | | NO | <ul style="list-style-type: none"> • Lower than 1 Ω • Disconnect wire from relay. | Sprinkler relay earth wire not connected or incorrectly connected. | Repair or renew wire. |
| NO | | 7 | YES | <ul style="list-style-type: none"> • 20~28V • Operate sprinkler switch. | Wire G[R] from sprinkler switch terminal 2 to sprinkler relay terminal 1 not connected or incorrectly connected. | Repair or renew wire. | |
| | | | NO | 8 | YES | Sprinkler switch faulty. | Renew. |
| | | NO | <ul style="list-style-type: none"> • 20~28V | Wire LW[LW] from sprinkler relay terminal 3 to fuse (from branch point) not connected or incorrectly connected. | Repair or renew wire. | | |

Electric wiring diagram for mode E-11 a)

(SW800: To Machine No.10122 SW850: To Machine No.10126)




SW8004009

Troubleshooting for Electric System

b). CONT mode is not selected (If CONT mode is inoperative, Timer mode is also inoperative).
 (SW800: From Machine No.10123 SW850: From Machine No. 10127)

* The diagnosis procedures below are for the rear vibrator. The wire color codes enclosed in brackets [] are for the front vibrator.



| | Possible cause | Remedy |
|--|---|-----------------------|
| | Wire GB from sprinkler switch terminal 2 to sprinkler relay terminal 1 (to branch point) not connected or incorrectly connected (including fuse). | Repair or renew wire. |
| | Wire BY from fuse to sprinkler relay terminal 3 (to branch point) not connected or incorrectly connected (including fuse). | Repair or renew wire. |
| | Sprinkler switch defective. | Renew. |
| | Wire BY from fuse to sprinkler switch terminal 1 (to branch point) not connected or incorrectly connected (including fuse). | Repair or renew wire. |
| | Sprinkler pump defective. | Renew. |
| | Sprinkler pump earth wire not connected or incorrectly connected. | Repair or renew wire. |
| | Wire Y [W] from sprinkler relay terminal 5 to sprinkler pump not connected or incorrectly connected. | Repair or renew wire. |
| | Sprinkler relay defective. | Renew. |
| | Sprinkler relay earth wire not connected or incorrectly connected. | Repair or renew wire. |
| | Wire GB [GB] from fuse to sprinkler relay terminal 3 (to branch point) not connected or incorrectly connected. | Repair or renew wire. |
| | Wire BY[BY] from sprinkler relay terminal 3 to fuse (to branch point) not connected or incorrectly connected. | Repair or renew wire. |

9

Is specified voltage present at sprinkler relay terminal 1 that carries wire GB [GB]?

- 20–28V
- Sprinkler switch: CONT

YES

10

Is resistance of sprinkler relay earth wire as specified?

- Lower than 1 Ω
- Disconnect wire from relay.

YES

NO


c). TIMER mode not selected.

(SW800: From Machine No.10123 SW850: From Machine No. 10127)

| | | Possible cause | Remedy |
|--|-----|--|--|
| <p>1</p> <p>Is specified voltage present at sprinkler timer connectors 1 and 3 that carry wire G? • 20~28V • Sprinkler switch: TIMER</p> | YES | Is specified voltage present at sprinkler timer connector 1 that carries wire GB? • 20~28V • Sprinkler switch: TIMER | <p>2 YES</p> <p>Wire GB from sprinkler timer connector 4 to sprinkler switch terminal 2 (to branch point) not connected or incorrectly connected.</p> <p>Repair or renew wire.</p> |
| | NO | Is specified voltage present at sprinkler switch terminal 5 that carries wire G? • 20~28V • Sprinkler switch: TIMER | <p>3 YES</p> <p>Wire G from sprinkler switch terminal 5 to sprinkler timer connectors 1 and 3 not connected or incorrectly connected.</p> <p>Repair or renew wire.</p> |
| | NO | Is specified voltage present at sprinkler switch terminal 4 that carries wire BY? • 20~28V | <p>4 YES</p> <p>Sprinkler switch defective.</p> <p>Renew.</p> |
| | NO | | <p>NO</p> <p>Wire BY from fuse to sprinkler switch terminal 4 not connected or incorrectly connected (including fuse).</p> <p>Repair or renew wire.</p> |

Electric wiring diagram for modes E-11 b), c)

(SW800: From Machine No.10123 SW850: From Machine No.10127)



SW8004019

E-12 Fuel gauge reads wrong

★Other gauges and lamps are normal.

★Measure the voltage with the starter switch ON.




Table 1

| Fuel unit wire YB | Gauge reading |
|-------------------|---------------|
| Disconnected | Empty |
| Grounded | Full |

Table 2


| Fuel unit float | Resistance (Ω) |
|-----------------|----------------|
| Full | 10~17.5 |
| Empty | 82.5~90 |

Electric wiring diagram for mode E-12

* Wire color codes in parentheses (): SW800 → From Machine No.10123

SW850 → From Machine No.10127

Codes with no parentheses → Common to both models



SW8004011

E-13 Coolant temperature gauge reads wrong

- ★Other gauges and lamps operate correctly.
- ★Measure the voltage with the starter switch ON.




Table 1

| Thermo unit terminal wire Sb | Gauge reading |
|------------------------------|---------------|
| Disconnected | Lowest |
| Grounded | Highest |


Table 2

| Thermo unit temperature | Resistance (Ω) |
|-------------------------|----------------|
| 50°C | 150~158 |
| 100°C | About 27.4 |

Electric wiring diagram for mode E-13

* Wire color codes in parentheses (): SW800 → From Machine No.10123
 SW850 → From Machine No.10127

Codes with no parentheses → Common to both models



SW8004012


E-14 Tachometer reads wrong

* Wire color codes in parentheses (): SW800 → From Machine No.10123
 SW850 → From Machine No.10127

Codes with no parentheses → Common to both models

★Other gauges and lamps operate correctly.


★Measure the voltage with the starter switch ON.



Electric wiring diagram for mode E-14

* Wire color codes in parentheses (): SW800 → From Machine No.10123
 SW850 → From Machine No.10127

Codes with no parentheses → Common to both models



SW8004013


E-15 Charge warning lamp, engine oil pressure warning lamp, hydraulic oil filter warning lamp and parking brake indicator lamp do not come on with starter switch ON.

* Wire color codes in parentheses (): SW800 → From Machine No.10123
 SW850 → From Machine No.10127

Codes with no parentheses → Common to both models

★These lamps illuminate only when the starter switch is turned to the ON position (for bulb failure check) and when unusual conditions have occurred.

★Measure the voltage with the starter switch ON.




| | | Possible cause | Remedy |
|--|--|---|--------------------------|
| | | Lamp bulb damaged. | Renew. |
| | | Combination meter faulty. | Renew combination meter. |
| <p>5 YES</p> <p>Does check relay give a working sound (a click)?</p> <ul style="list-style-type: none"> • Starter switch ON. | | Wire BY(YG) from check relay terminal 3 to combination meter not connected or incorrectly connected. | Repair or renew wire. |
| <p>6 YES</p> <p>Is resistance of wire BY(YG) from combination meter to check relay terminal 3 as specified?</p> <ul style="list-style-type: none"> • Lower than 1Ω • Disconnect each end of wire BY(YG). | | Check relay faulty. | Renew. |
| <p>NO</p> <p>7 YES</p> <p>Is resistance of check relay earth wire as specified?</p> <ul style="list-style-type: none"> • Lower than 1Ω • Disconnect earth wire from relay. | | Check relay earth wire not connected or incorrectly connected. | Repair or renew wire. |
| <p>NO</p> <p>8 YES</p> <p>Does starter run?</p> <ul style="list-style-type: none"> • Turn starter switch to START. | | Wire YW(WL) from fuse to combination meter not connected or incorrectly connected. | Repair or renew wire. |
| | | Fuse has burnt. | Renew. |
| | | Wire LgB from check relay terminal 2 to alternator terminal L not connected or incorrectly connected. | Repair or renew wire. |
| | | Wire LgW from starter switch terminal ACC to check relay terminal 1 not connected or incorrectly connected. | Repair or renew wire. |
| | | Starter switch faulty (between terminals B and ACC). | Renew. |

Electric wiring diagram for mode E-15

* Wire color codes in parentheses (): SW800 → From Machine No.10123

SW850 → From Machine No.10127

Codes with no parentheses → Common to both models



SW8004014

6. Fault Finding for Hydraulic and Mechanical Systems (Mode H)

| | |
|---|-------|
| Fault modes for hydraulic and mechanic systems and source-of-trouble components | 4-402 |
| H-01 Not propelled | 4-404 |
| H-02 Travel speed not gained or low traction | 4-408 |
| H-03 Vibrator does not work | 4-412 |
| H-04 Weak vibratory force | 4-413 |
| H-05 Frequency is not selected | 4-413 |
| H-06 Steering not performed | 4-414 |
| H-07 Heavy or slow steering | 4-414 |
| H-08 Parking brake not applied sufficiently | 4-415 |
| H-09 Parking brake not released | 4-415 |
| H-10 No sprinkling | 4-415 |

Fault modes for hydraulic and mechanical systems and possible sources of troubles

| Possible source | | Fault mode | Propulsion | | | |
|-----------------|--|-------------------------------|---------------------------------|------------------------------|----------------------------------|------------------------------|
| | | | Not propelled | | Speed not gained or low traction | |
| | | | a) Forward and reverse | b) Either forward or reverse | a) Forward and reverse | b) Either forward or reverse |
| Propulsion | Propulsion pump | Pump (including servo device) | ● | ● | ● | |
| | | Servo valve/servo linkage | ● | ● | ● | ● |
| | | High pressure relief valve | ● | ● | ● | ● |
| | | Charge relief valve | ● | | ● | ● |
| | | Cut off valve | ● | | ● | |
| | Front drive | Inside of Motor | ● | ● | ● | ● |
| | | Reduction gear | ● | | ● | |
| | | Parking brake | ● | | ● | |
| | Rear drive | Inside of motor | ● | ● | ● | ● |
| | | Reduction gear | ● | | ● | |
| | | Parking brake | ● | | ● | |
| | | Flushing valve | ● | | ● | |
| | | | Brake release solenoid valve | | | |
| | Vibrator | | Frequency select solenoid valve | | | |
| | | Inside of pump | ● | | ● | |
| | | Frequency select piston | | | | |
| Front | | Inside of motor | | | | |
| | | Amplitude select valve | | | | |
| | | Main pressure relief valve | | | | |
| | | Port relief valve | | | | |
| | | Vibrator | | | | |
| Rear | | Motor unit | | | | |
| | | Amplitude select valve | | | | |
| | | Main pressure relief valve | | | | |
| | Port relief valve | | | | | |
| | Vibrator | | | | | |
| Steering | Steering pump | | | | | |
| | Orbitrol (including pressure relief valve) | | | | | |
| | Steering cylinder | | | | | |
| | Steering mechanism | | | | | |
| | Steering column | | | | | |
| Sprinkler | Sprinkler pump | | | | | |
| | Filter, Sprinkler pipe, Nozzle | | | | | |
| Others | Coupling | ● | | | | |
| | F-R lever linkage | ● | ● | ● | ● | |
| Diagnosis code | | | H-01a | H-01b | H-02a | H-02b |


H-01 Not propelled

★Diagnose electric systems first. If they are normal, then use the following procedures.

★Start with checking the oil level in the hydraulic tank.

a) Not propelled in both directions (forward and backward).


(1/2)



| | | Possible cause | Remedy |
|---|---|---|--|
| <p>6</p> <p>Is charge circuit pressure in propulsion line as specified?</p> <p>*See Standard Value Chart.</p> <p>7 YES</p> <p>Is charge circuit pressure higher than permissible value with F-R lever moved forward and backward?</p> <p>*See Standard Value Chart.</p> <p>NO</p> <p>14</p> <p>Is fault rectified if charge relief valve is disassembled and cleaned?</p> <p>NO</p> <p>15 YES</p> <p>Does charge pressure return to normal with ports (A, B) in front motor blocked (unloader valve opened)?</p> <p>NO</p> <p>16</p> <p>Disconnect hoses from ports A and B from the front motor and connect both ports directly. plug hoses.</p> <p>NO</p> <p>*1 Recheck the item enclosed by a dotted line. *2 Due to difficulty in deciding checking sequence, a 'NO' line on this page carries two checking items. • Generally, checking items with smaller reference number have higher probability.</p> | YES | To 'A' on page | |
| | | Rear wheel flushing valve faulty. | <ul style="list-style-type: none"> Clean and adjust. Renew if necessary. |
| | | Charge relief valve faulty. | <ul style="list-style-type: none"> Clean and adjust. Renew if necessary. |
| | | Oil leakage at sliding portions (such as piston) of front wheel motor. | Repair. Renew if necessary. |
| | | Oil leakage at sliding portions (such as piston) of rear wheel motor. | Repair. Renew if necessary. |
| | | Internal leakage of brake cylinder. | Repair. Renew if necessary. |
| | | Steering pump faulty. | Renew. |
| | | Leakage at sliding portions (pistons of propulsion pump or vibrator pump etc.). | Repair or renew wire. |
| | | Pump servo valve or servo linkage defective. | Repair or renew wire. |
| | | F-R lever linkage defective. | Repair or renew wire. |
| | Unloader valve lever in incorrect position. | Set correctly. | |
| | Damaged splined portions in coupling or pump shaft. | Repair or renew wire. | |


Fault Finding for Hydraulic and Mechanical Systems

a) Not propelled in both directions (forward and backward).
(2/2)



- * Due to difficulty in deciding checking sequence, a 'YES' line on this page carries two checking items.
- Generally, checking items with smaller reference number have higher probability.

b) Machine is propelled in one direction only.




H-02 Travel speed not gained or low traction

★Start diagnosis with electric systems. If they are normal, use the procedures below:

★Check oil level in the hydraulic tank before proceeding to the following procedures.

a) Speed not gained in both travel directions.

(1/2)



| | | Possible cause | Remedy |
|---|-----|---|---------------------------------------|
| <p>6 YES</p> <p>Is propulsion main circuit pressure (relief pressure) as specified?</p> <p>*See Standard Value Chart.</p> | YES | To 'A' on page 4-410. | |
| | NO | To 'B' on page 4-410. | |
| | | Rear motor flushing valve faulty. | Clean and adjust. Renew if necessary. |
| | | Charge relief valve faulty. | Clean and adjust. Renew if necessary. |
| <p>14 YES</p> <p>Does charge pressure return to normal with motor ports A and B blocked (unloader valve opened)?</p> | YES | Leakage at sliding portions (such as piston) of front motor. | Repair. Renew if necessary. |
| | NO | Leakage at sliding portions (such as piston) of rear motor. | Repair. Renew if necessary. |
| <p>15</p> <p>Does charge pressure return to normal with brake valve inlet hose blocked?</p> <p>*1</p> | | Inner leakage of motor brake cylinder | Repair. Renew if necessary. |
| | | Steering pump faulty. | Renew. |
| | | Leakage at sliding portions (piston) of propulsion pump or vibrator pump. | Repair. Renew if necessary. |
| | | Pump servo valve or servo linkage faulty. | Repair. Renew if necessary. |
| | | F-R lever linkage faulty. | Repair. Renew if necessary. |
| | | Unloader valve lever position incorrect. | Set lever correctly. |

*1 Recheck the item enclosed by a dotted line.

*2 Due to difficulty in deciding checking sequence, a 'NO' line on this page carries two checking items.

- Generally, checking items with smaller reference number have higher probability.

Fault Finding for Hydraulic and Mechanical Systems

a) Speed not gained in both travel directions.
(2/2)


| | | Possible cause | Remedy | | |
|---|--------|---|---|--|-----------------------------|
| A | 7 YES | Front wheel drive motor reduction gear damaged. | Repair. Renew as necessary. | | |
| | NO | Front drive motor damaged. | Repair. Renew as necessary. | | |
| | 8 YES | Rear drive motor reduction gear damaged. | Repair. Renew as necessary. | | |
| | NO | Rear motor damaged. | Repair. Renew as necessary. | | |
| | 9 YES | Propulsion pump performance lowered. | Repair. Renew as necessary. | | |
| | NO | Propulsion motor performance lowered. | Repair. Renew as necessary. | | |
| B | 10 YES | Cut off valve faulty. | Clean and adjust. Renew if necessary. | | |
| | NO | 11 YES | High pressure relief valve faulty. | Clean and adjust. Renew if necessary. | |
| | NO | 11 NO | 12 YES | Leakage at sliding portions (such as piston) of front motor. | Repair. Renew as necessary. |
| | NO | 12 NO | Leakage at sliding portions (such as piston) of rear motor. | Repair. Renew as necessary. | |

Drain oil from front motor reduction gear. Are metal particles noticeable in oil?
 Drain oil from rear motor reduction gear. Are metal particles noticeable in oil?
 Is amount of drain in front and rear motors normal?
 Is fault rectified if cut off valve is disassembled and cleaned?
 Is fault rectified if high pressure relief valve is disassembled and cleaned?
 Does charge pressure return to normal with front motor ports (A and B) blocked (un-loader valve opened)?

* Due to difficulty in deciding checking sequence, a 'YES' line on this page carries three checking items.
 • Generally, checking items with smaller reference number have higher probability.

*See Standard Value Chart.

b) Speed not gained or low traction in either forward or backward travel direction.



H-03 Vibrator does not work

★Diagnose electric systems first. If they are normal, then use procedures as instructed below:

★Check the oil level in the hydraulic tank before proceeding to the following procedures.

a) Both front and rear vibrators are inoperative.

| | | Possible cause | Remedy |
|---|-----------------------------|--|-----------------------------|
| 1 | YES Does machine travel? | Vibrator pump or pump coupling faulty. | Repair. Renew if necessary. |
| | NO | Engine coupling faulty. | Repair. Renew if necessary. |

b) Either front or rear vibrator is inoperative.


| | | Possible cause | Remedy | |
|---|--|---|--|---|
| 1 | Either in LOW or HIGH amplitude | 2 YES Is faulty condition reversed if port relief valve on inoperative side is exchanged with that on normally functioning side? | Clean and adjust. Renew if necessary. | |
| | | NO | Amplitude select valve faulty. Repair. Renew if necessary. | |
| 3 | In both LOW and HIGH amplitudes | YES Is faulty condition reversed if relief valve on inoperative side is exchanged with that on normally functioning side? | Main pressure relief valve faulty (Foreign matter present or valve faulty.). Clean and adjust. Renew if necessary. | |
| | | NO | To 'A' on this page | |
| A | 4 Does motor generate load sounds or rotating sounds? | YES | Vibrator faulty. Repair. Renew if necessary. | |
| | | 5 Does amplitude select solenoid valve spool move smoothly? | YES | Vibrator drive motor faulty. Repair. Renew if necessary. |
| | | | NO | Amplitude select solenoid valve faulty. Repair. Renew if necessary. |

H-04 Weak vibratory force

★Diagnose the electric systems first. If they are normal, use procedures as follows.


★Check the oil level in the hydraulic tank before proceeding to the following procedures.

*Vibratory force is weak in either front or rear vibrator.




H-05 Frequency is not selected

★Diagnose electric systems first. If they are normal, then use the following procedures.




H-06 Steering not performed

★Start with checking the oil level in the hydraulic tank.




H-07 Heavy or slow steering

★Start with checking the oil level in the hydraulic tank.




*Fully extend the steering piston rod, disconnect hose from piston rod side. Exert pressure from cylinder head side.




H-08 Parking brake not applied sufficiently

★Diagnose electric systems first. If they are normal, then use procedures stated as below.




H-09 Parking brake not released

★Diagnose electric systems first. If they are normal, use procedures described as below.



H-10 No sprinkling

★Diagnose electric systems first. If they are normal, then use procedures described below.



SAKAI HEAVY INDUSTRIES, LTD.

Head office: 1-4-8, Shiba-Daimon, Minato-ku
Tokyo, Japan

Telephone: Tokyo(03) 3431-9971

Facsimile: (03) 3431-6212