

SAKAI

MASTERS OF COMPACTION



774

Diagnostic
Information

Please See Operators and Service Manual for additional information.

ALL Work Must be performed by a factory trained technician to prevent injury. This manual is not intended to replace the service manual but to assist with additional information.



WARNING

Unexpected machine movement may cause a serious accident. When inspecting the machine while the engine is running, always follow the instructions below.

- Park the machine on level, flat ground.
- Apply the parking brake.
- Set chocks in front and behind each drum or tire.
- Make sure that service personnel are given the appropriate information at the appropriate time.
- Make sure that no one can enter any hazardous area.

CAUTION

Do not work on the hydraulic system while the engine is running and the system is hot and under pressure. Do not disconnect hydraulic hoses or fittings until the system has cooled and pressure has been properly relieved.

Before removing any plugs from the pressure measurement ports, always release any residual pressure from the piping and open the cap of the fluid tank to release and pressure.

WARNING

Inadvertent starting the engine may cause a serious accident.

When inspecting the engine, make sure to exchange the appropriate cues and hand signal with the person at the operator station to avoid any accidents.

CAUTION

Before inspecting inside of the engine compartment, always stop the engine.

Contact with the fan, V-belt or exhaust system parts while the engine is running may cause serious injury.




774 Operators Manual
Scan QR Code to View




ENGINE	KUBOTA	
	V3800-CR-TI-EV03	
	EPA Tier 4	
	Diesel, water cooled, 4 cycle, 4 cylinder, with turbo charger	
	3.769 (230.0)	
	81.8 (110) / 2,400	
	12(12 / 750×2)	
	12 / 80	
DRIVE SYSTEM	Hydrostatic	
	All wheel (2 drums)	
VIBRATION SYSTEM	Hydraulic	
	2	
	Single eccentric shafts	Double eccentric shafts
BRAKE SYSTEM	Dynamic braking through hydrostatic drive system / F-N-R lever	
	Hydrostatic + Spring applied hydraulically released type (SAHR) / Brake pedal	
	SAHR / Panel button	
STEERING SYSTEM	Hydraulic	
	36.7 / 6.5	
FLUID CAPACITY	186 (49.1)	
	90 (23.8)	
	300 + 450 (79.3 + 118.9)	
	20 (5.3)	

Lubricant	Service classification	Ambient temp. and applicable viscosity rating			Applicable standards
		-15 – 30°C (5 – 86°F) Cold	0 – 40°C (32 – 104°F) Moderate	15 – 55°C (59 – 131°F) Tropical	
Engine oil	API grade CJ-4	SAE 10W-30	SAE 10W-30	SAE 10W-30	MIL-L-2104B
Gear oil	API grade GL5	SAE 80W-90	SAE 90	SAE 140	MIL-L-2105
Hydraulic oil	Anti wear	ISO-VG32 over VI 140	ISO-VG46 over VI 140	ISO-VG68 over VI 110	ISO-3448
Grease	Lithium type extreme pressure				NLGI-2
Fuel	Diesel oil				ASTM D975-2D
DEF	ISO22241-1 or AUS32				


Compartment	Type of fluid	Capacity in liters (gal.)
Fuel tank	Diesel oil	186 (49.1)
Engine oil pan	Engine oil	13.2 (3.49)
Radiator	Coolant	18 (4.75)
Hydraulic oil tank	Hydraulic oil	90 (22.1)
Gear case (Wheel motor)	Gear oil	3.2 (0.84) × 2
Vibrator (SW774)	Gear oil	16.5 (4.36) × 2
Vibrator (SW774ND)	Gear oil	33 (8.71) × 2
Water tank	Water	Front : 300 (79.2) / Rear : 450 (118.8)
DEF tank	DEF	20 (5.3)





Aftertreatment monitor display (part)


OK monitor display (part)



Fuel gauge

Tachometer / Hour meter

Temperature gauge



DEF meter

Parked manual regeneration lamp / Regeneration lamp

Exhaust equipment high temperature lamp

DEF quality warning lamp (red)

Disable regeneration lamp

DEF level warning lamp (amber)

Battery charge lamp
Goes on when troubles have occurred in electric system while engine is running

Parking brake indicator lamp
Goes on when parking brake is engaged.

Engine stop warning lamp
Goes on when a serious abnormality is detected in the engine.

Engine warning lamp
Goes on when an abnormality is detected in the engine.

Hydraulic oil filter warning lamp
Goes on when filter is clogged.



Engine oil pressure warning lamp
Goes on when engine lubricating oil pressure is lowered below specified value.

Vibrator indicator lamp
Goes on when vibrator operates.

Eco lamp
Goes on when the engine speed select switch is shifted to the ECO position.





- ① Combination meter
- ② Vibration drum selector switch
- ③ Vibration mode selector switch
- ④ Vibration amplitude selector switch (For SW774)
Vibration type selector switch (For SW774ND)
- ⑤ Vibration frequency selector switch (Only SW774)
- ⑥ Sprinkler selector switch
- ⑦ Sprinkler switch
- ⑧ Sprinkler timer
- ⑨ Horn switch
- ⑩ Engine diagnostic switch
- ⑪ Hazard switch
- ⑫ Parking brake switch
- ⑬ Flood lamp switch
- ⑭ Dimmer switch
- ⑮ Lamp switch
- ⑯ Engine speed selector switch
- ⑰ Parked regeneration switch
- ⑱ Brake pedal
- ⑲ Starter switch
- ⑳ Turn signal lever
- ㉑ Swivel release pedal
- ㉒ Forward-Neutral-Reverse (F-N-R) lever with vibrator switch

FUSE & RELAY BOX



1	FUSE 15A WATER SPRAY
2	FUSE 15A OPTION
3	FUSE 15A POWER OUTLET
4	FUSE 20A OPTION
5	FUSE 15A OPTION
6	FUSE 15A LIGHTNING
7	FUSE 15A FLOOD LAMP
8	FUSE 15A PEDAL BRAKE SW. BACK UP SW. PARKING SW.
9	FUSE 15A FLASHER UNIT HORN RELAY
10	FUSE 15A VIB. THOTTLE RELAY INTERLOCK SW.
11	FUSE 15A OPTION
12	FUSE 30A STARTER PRE-RELAY STARTER RELAY FUSE 5A
13	N/C
14	N/C
15	N/C
16	FUSE 20A COMP RELAY
17	FUSE 30A HEATER RELAY
18	FUSE 5A COMB. METER POWER
19	FUSE 30A ECU MAIN RELAY
20	FUSE 10A DEF TANK SENSOR PRE NOX SENSOR POST NOX SENSOR

21	FUSE 5A ECU A6 EGR VALVE
22	FUSE 5A ACU 18 IGNITION SW. COMB. METER ECU VB/VBB 1G-SW SERVICE TOOL
23	FUSE 5A PARKING INTERLOCK RELAY
24	FUSE 5A ECU V12 ST-SW
25	FUSE SPARE 20A
26	FUSE SPARE 15A
27	FUSE SPARE 15A
28	FUSE SPARE 15A
29	FUSE SPARE 30A
30	FUSE SPARE 20A
31	FUSE SPARE 10A
32	FUSE SPARE 5A
33	RELAY PARKING INTERLOCK
34	RELAY NEUTRAL
35	RELAY SPEED PULSE ON/OFF
36	RELAY HORN
37	RELAY WATER SPLAY
38	RELAY WATER SPLAY PUMP (A)
39	RELAY WATER SPLAY PUMP (B)
40	RELAY VIB. GRIP-OFF-AUTO CHANGE
41	RELAY VIB. FREQ. CHANGE 1
42	RELAY VIB. FREQ. CHANGE 2
43	RELAY STARTER PRE
44	RELAY PARKING BRAKE
45	RELAY VIB. THROTTLE
46	RELAY FOR OPTION 1



Engine diagnostic switch

Engine troubleshooting can be conducted using the trouble code selector switch.

Do not operate this switch during the normal operation.



As shown in the figure, set the switch to the OFF position during the normal operation.

DIAG. position : Engine diagnostic is activated

OFF position : Engine diagnostic is shut off

IMPORTANT

When the engine malfunctions or fails, make for appropriate inspection, maintenance, or repair.



Under self-diagnosis

Wait to start



Find the cause of the failures by SPN & FMI Codes listed in Kubota Diagnosis Manuals


Without FAILURE





DTC MESSAGE : 0 OF 0
 SPN : ---
 FMI : ---
 SA : ---

With FAILURES

DTC MESSAGE : 4 OF 5
 SPN : 32
 FMI : 24
 SA : 1







Crank, No Start

Are there any Engine Codes present?


No, Is there fuel in the machine?

No, Add Fuel and Prime using hand pump.

Yes, Is there fuel present at filters?

No, Replace filters as needed or remove fuel restriction, repair as needed.

Injector Pump



SCV (Suction Control Valve)



Yes, Please Kubota Diagnostic Manual for info.


Yes, There fuel present at Fuel Pump ?


No, Replace filters as needed or remove fuel restriction, repair as needed.

Yes, Connect Diagmaster and check for Target and Actual rail pressure. Should be almost the same to start.


No, Check SCV and Injector Pump

Yes, Test Compression and have injectors tested.







Drive Cable




Note: If all checks out electrically. Test Charge Pressure at **350-400** PSI. And Drive Pump at **6236** PSI.




Foot Brake Switch









○ : Continuous sprinkling
 AUTO : Spraying is done interlocking with forward / backward movement.
 TIMER : Intermittent (timer) sprinkling

Will not Spray Water

Is there water in the tanks?

No, Fill tanks with water and test.

Yes, Are both Front and Rear Pump sprayers not spraying?

No, Isolate circuit and Test.

Yes, Check F1 15a for Power. Is fuse good?

Is the pump running?

Yes, Is there Power at the Spray Mode Switch on Blue/Black Wire?

No, Remove and Replace as needed and Test.

No, Is there good Power and Ground at Pump?

Yes, check for obstruction or replace pump as needed.

Yes, Move the Spray Mode Selector Switch and Test for power across switch on Blue/White and Blue/Yellow wire. Is there Power Across the Switch?

No, Test wire from F1 to Switch and Repair or Replace as needed.

No, Check F1 15a. Is the fuse Good?

Yes, check connections or replace pump as needed.

Yes, Is there power coming out of the Water Spray Relay on Light Green Wire?

No, Replace defective switch and test.

No, Replace fuse and Test.

Yes, Check Pump Relay for that Circuit and replace as needed.

Yes, Test Light Green Wire from Water Spray Relay to Pump A and B Switches for continuity and repair as needed.



No, Repair Connections or Replace defective Water Spray Relay.







Water Mode

Water Pump A

Water Pump B





Front Drum will not vibrate low

Are the Vibrate Switches in correct position?

Yes, Is there power at the Low Solenoid(White/Blue Stripe) when turned to "ON" position?

No, See Next Page Or Ops Manual for More Info.

No, Is there power at the Low/High Switch Pin 6 (White/Blue Stripe)?

Yes, Is there a good ground on the solenoid?

Yes, Is there power at the Low/High Switch on Pin 4 (Green/Blue Stripe)?

Yes, Repair broken wire connection to solenoid.

No, Repair ground and test.

Yes, Remove the coil from the solenoid. Does it magnetize when turned to "ON" position?

No, Is there power on Front/Rear Selector Switch on Pin 6 (Green/Blue Wire)?

Yes, Repair or Replace defective High/Low Switch.

No, Repair or Replace coil.

Yes, Internal Failure. Repair solenoid valve as needed.

No, Is there power on Front/Rear Selector Switch on Pin 4 (Green/Blue)?



Yes, Repair broken wire from High/Low Switch to Front/Rear Switch.

No, Is there power (Yellow/Green) Mode Selector Relay Pin 5 (Yellow/Green Wire)?

Yes, Repair or Replace defective Front/Rear Switch.

Yes, Test and Or Replace Relay.

Yes, Repair Broken wire from Relay.



Front Drum will not vibrate high

Are the Vibrate Switches in correct position?

Yes, Is there power at the Low Solenoid(Brown/Yellow Stripe) when turned to "ON" position?

No, See Next Page Or Ops Manual for More Info.

No, Is there power at the Low/High Switch Pin 5 (Brown/Yellow Stripe)?

Yes, Is there a good ground on the solenoid?

Yes, Is there power at the Low/High Switch on Pin 4 (Green/Blue Stripe)?

Yes, Repair broken wire connection to solenoid.

No, Repair ground and test.

Yes, Remove the coil from the solenoid. Does it magnetize when turned to "ON" position?

No, Is there power on Front/Rear Selector Switch on Pin 6 (Green/Blue Wire)?

Yes, Repair or Replace defective High/Low Switch.

No, Repair or Replace coil.

Yes, Internal Failure. Repair solenoid valve as needed.

No, Is there power on Front/Rear Selector Switch on Pin 4 (Green/Blue)?



Yes, Repair broken wire from High/Low Switch to Front/Rear Switch.

No, Is there power (Yellow/Green) Mode Selector Relay Pin 5 (Yellow/Green Wire)?

Yes, Repair or Replace defective Front/Rear Switch.

Yes, Test and Or Replace Relay.

Yes, Repair Broken wire from Relay.



Rear Drum will not vibrate low

Are the Vibrate Switches in correct position?

Yes, Is there power at the Low Solenoid(Light Green/Black Stripe) when turned to "ON" position?

No, See Next Page Or Ops Manual for More Info.

No, Is there power at the Low/High Switch Pin 3 (Light Green/Black Stripe)?

Yes, Is there a good ground on the solenoid?

Yes, Is there power at the Low/High Switch on Pin 1 (Blue/Red Stripe)?

Yes, Repair broken wire connection to solenoid.

No, Repair ground and test.

Yes, Remove the coil from the solenoid. Does it magnetize when turned to "ON" position?

No, Is there power on Front/Rear Selector Switch on Pin 3 (Blue/Red Wire)?

Yes, Repair or Replace defective High/Low Switch.

No, Repair or Replace coil.

Yes, Internal Failure. Repair solenoid valve as needed.

No, Is there power on Front/Rear Selector Switch on Pin 1 (Yellow/Green)?



Yes, Repair broken wire from High/Low Switch to Front/Rear Switch.

No, Is there power (Yellow/Green) Mode Selector Relay Pin 5 (Yellow/Green Wire)?

Yes, Repair or Replace defective Front/Rear Switch.

Yes, Test and Or Replace Relay.

Yes, Repair Broken wire from Relay.



Rear Drum will not vibrate High

Are the Vibrate Switches in correct position?

Yes, Is there power at the Low Solenoid (Yellow/Red Stripe) when turned to "ON" position?

No, See Next Page Or Ops Manual for More Info.

No, Is there power at the Low/High Switch Pin 2 (Yellow/Red Stripe)?

Yes, Is there a good ground on the solenoid?

Yes, Is there power at the Low/High Switch on Pin 1 (Green/Blue Stripe)?

Yes, Repair broken wire connection to solenoid.

No, Repair ground and test.

Yes, Remove the coil from the solenoid. Does it magnetize when turned to "ON" position?

No, Is there power on Front/Rear Selector Switch on Pin 3 (Blue/Red Stripe)?

Yes, Repair or Replace defective High/Low Switch.

No, Repair or Replace coil.

Yes, Internal Failure. Repair solenoid valve as needed.

No, Is there power on Front/Rear Selector Switch on Pin 1 (Yellow/Green)?



Yes, Repair broken wire from High/Low Switch to Front/Rear Switch.


No, Is there power (Yellow/Green) Mode Selector Relay Pin 5 (Yellow/Green Wire)?


Yes, Repair or Replace defective Front/Rear Switch.

Yes, Test and Or Replace Relay.

Yes, Repair Broken wire from Relay.








Code No.	Description
P0016	Crankshaft Position Sensor (NE)
P0087	Pressure Limiter Opening Abnormal
P0088	High Rail Pressure Abnormality
P0089	SCV Stuck
P0093	High Pressure Fuel Leak
P0112	Intake Air Temp Abnormal (Low)
P0113	Intake Air Temp Abnormal (High)
P0117	Coolant Temp Sensor Abnormal (Low)
P0118	Coolant Temp Sensor Abnormal (High)
P0182	Fuel Temp Sensor Abnormal (Low)
P0183	Fuel Temp Sensor Abnormal (High)
P0192	Rail Pressure Sensor Abnormal (Low)
P0193	Rail Pressure Sensor Abnormal (High)
P0200	Overcharge
P0201	Fuel Injector Cylinder 1 Open Circuit
P0202	Fuel Injector Cylinder 2 Open Circuit
P0203	Fuel Injector Cylinder 3 Open Circuit
P0204	Fuel Injector Cylinder 4 Open Circuit
P0217	Engine Overheat
P0219	Engine Overrun
P0335	Crankshaft Sensor Abnormal (Low)
P0336	Crankshaft Sensor Abnormal (High)
P0340	Camshaft Sensor Abnormal (Low)
P0341	Camshaft Sensor Abnormal (High)
P0380	Air Heater Relay Abnormality
P0400	EGR Feedback Abnormal
P0404	EGR Motor Temp Abnormal
P0628	SCV Abnormal (Low)
P0269	SCV Abnormal (High)

NOTE:
For full description and additional troubleshooting, please see the Kubota Diagnostic manual.



Kubota V3800 Engine Specifications

Engine Model Kubota V3800
Engine Type 4-Stroke, vertical, water-cooled diesel
Number of Cylinders 4
Total displacement, cc (cu.in) 3769 (230.0)
Engine Bore, mm (in) 100.0 (3.94)
Engine Stroke, mm (in) 120.0 (4.72)
Rated Engine Power, hp (kW) 99.2 (74.0)
Rated Engine Speed, rpm 2600
Maximum Engine Speed, rpm 2800
Idle Speed, rpm 775-825
Compression Ratio 19:1
Firing Order 1-3-4-2
Lubrication System Forced lubrication by trochoid pump
Oil Filter Type Full Flow Paper

Fuel System

Fuel System Type Direct injection
Fuel Injection Pump Bosch Type Mini
Injection Nozzle Bosch throttle type
Governor Type All speed mechanical governor

Engine Oil and Filter

Engine Oil Type SAE20, SAE30, 10W-30
Oil Classification API CF-4, CG-4, CH-4 or CI-4
Oil Capacity, L (qts) 13.2 (14.0)
Oil Filter Part Number HH1C0-32430

Service Intervals


Service Air Cleaner Element Every 250 hours
Service Fuel Filter (Element Type) Every 250 hours
Change Engine Oil Every 500 hours
Change Oil Filter Cartridge Every 500 hours
Replace Fuel Filter Cartridge Every 500 hours
Replace Fan Belt Every 500 hours
Check and Adjust Valve Clearance Every 1000 hours
Replace Air Cleaner Element Every 1500 hours
Check Fuel Injection Pump Every 3000 hours

Kubota V3800 Service Specifications

Cylinder Block

Compression Pressure 3.47 MPa (504 psi)
Cylinder Bore I.D (Standard) 100.000-100.022 mm (3.93701-3.93787 in.)
Cylinder Bore I.D (Wear Limit) 100.150 mm (3.9429 in.)
Cylinder Bore Oversize I.D (Standard) 100.500-100.522 mm (3.95670-3.95755 in.)
Cylinder Bore Oversize I.D (Wear Limit) 100.650 mm (3.96260 in.)
Rocker Arm Shaft to Rocker Arm Clearance 0.016-0.045 mm (0.00063-0.0017 in.)
Rocker Arm Shaft O.D 15.973-15.984 mm (0.62886-0.62929 in.)
Rocker Arm I.D 16.000-16.018 mm (0.62993-0.63062 in.)

Sensor Locations



Vehicle Errors Codes

Error Code	Error Details
3360	DPF over-trapping (Lv2)
3370	DPF over-trapping (Lv1)

Engine Errors Codes

	SPN	FMI	Error Details
Kubota	3701	15	Excessive PM3
Kubota	3701	16	Excessive PM4
Kubota	3701	0	Excessive PM5

Regen Errors



Levels 1 – 3 Machine can be regenerated using the interior switch.

Level 4 – Diagmaster Needed to perform soot load reset, and force, reset intervals.

Level 5 – Diagmaster needed. Filter must be cleaned, and soot load reset performed along with intervals.



DO NOT FORCE REGEN WITHOUT CLEANING AT LEVEL 5!

Regen Conditions Needed:

1. Machine above 65 deg C or 150 deg F.
2. Engine at low Idle
3. No engine codes present

To Regen:

Press and Hold "Regen" button up to 10 seconds or until you hear engine pitch change and begin to idle up. **DO NOT TOUCH CONTROLS!** Leave machine alone until process has finished.



• SPN: 1239 FMI: 1/ P0093
Fuel Leak (In High Pressure System)

- De-rated 50%
- DTC is set when total flow/injected fuel flow volume deviates.




Code is commonly caused from air getting into the system from the low pressure fuel side.

Common Causes-

- 1. Loose hose Clamps.**
- 2. Filter Not Tight.**
- 3. Hole in Fuel Lines.**
- 4. Trash in Fuel tank/lines**
- 5. Low Fuel and air into pick up tube.**

Other Causes

- 1. Leaking Injectors**
- 2. Leaking PRV**
- 3. Supply Pump.**



DEF Quality Sensor Errors

DEF Tester



Inspect the DEF quality. The quality should be 32%. Is the quality Correct?

Yes, Inspect Wiring to ACU. Is wiring good?

Yes, Possible bad ACU or DEF Header. Replace as Needed. Try using an ACU from loaner machine to determine ACU.

No, Repair wiring and test unit.

No, Drain is replace test unit. Does code re appear?

Yes, Possible bad ACU or DEF Header. Replace as Needed. Try using an ACU from loaner machine to determine ACU.

No, Repair is complete, Stop!

- **DEF Level Sensor**
 - Uses magnetic float to close micro switches inside tube.
- **DEF Quality Sensor**
 - Measures DEF Density by thermal conductivity.




DEF Typical Physical Properties		
Urea	mass %	32.5
Biuret	mass %	0.3 max
Water	mass %	67.5 typical
Flash Point	°F/°C	250/121
Weight per gallon approximate	lbs	9.0
Density @ 20C	kg/M ³	1089.7 typ


MAF Sensor Error 132

SPN 132 FMI 3 – Mass Air Flow
Sensor Voltage High
Shorted Wire
Faulty MAF Sensor

SPN 132 FMI 4 – Mass Air Flow
Sensor Voltage Low
Shorted Wire
Faulty MAF Sensor



- Pin 1 – 12 VDC from Battery
- Pin 2 – Frame ground
- Pin 3 – Signal to ECU
- Pin 4 – 5 VDC from ECU
- Pin 5 – ECU ground



Signal wire goes to ECU pin
E69 which is E12 on the
Harness.



DEF Injector Fault

DEF Injector short to ground or open circuit or short to +B	P2047
DEF Injector QR Data Fault: Invalid QR Data	P1A24
DEF Injector QR Data Fault: No QR Data	P1A23



P2047 – DEF Injector short to ground or open circuit.



Possible cause: DEF Injector, ACU Harness, ACU Controller

Check DEF injector, injector may be shorted. Recommend removing and test on different machine.

Def injector harness – Check for Continuity on wires and check for corrosion in connector. Replace as needed.

Swap ACU to another machine to test



Harness part No. 1J508-65090



Code 3251 – DPS Error (Differential Pressure Sensor)

SPN: 3251 FMI: 3 Differential Pressure sensor voltage error (too high)

- Voltage on signal wire back to ECU is 4.7 VDC or above
- **Common causes**
 - Broken ground wire
 - Shorted Reference voltage wire to signal wire. (Red to white)
 - Faulty sensor



SPN: 3251 FMI: 4 Differential Pressure sensor voltage error (too low)

- Voltage on signal wire back to ECU is 0.21 VDC or less
- **Common causes**
 - Broken Reference voltage wire to sensor
 - Broken signal wire back to ECU
 - Faulty sensor




High Frequency Regen Code 523602

- SPN: 523602 FMI: 0/ P3024
High Frequency of Regeneration
 - Regeneration request three consecutive times in 30 minutes.
 - Can be caused by operator error. (pushing regen button 3 times within 30 minutes)
 - Check differential pressure sensor and connection for any broken wires.
 - Check air intake system
 - DiagMaster is required to clear code.
 - Perform a regen interval time reset and operate machine for 30 minutes.
 - Check PM sedimentation quantity. If greater than 16k mg, have filter cleaned.

Differential Pressure Sensor (DPS)



Inspect Turbo for Oil




Code 4334 - DEF Pressure Sensor Errors



Possible Causes:

1. **Clogged Filter or Lines**
2. **Faulty DEF Pump – Internal Sensor**
3. **Faulty Wiring**
4. **Faulty ACU**

3	DEF Pressure sensor error: Out-of-Range High	P204D
4	DEF Pressure sensor error: Out-of-Range Low	P204C
15	DEF Pressure sensor error: Offset High	P204B
16	DEF Dosing Pressure error: High	P20E9
18	DEF Dosing Pressure error: Low	P20E8



9Y1200274CRS017A

B: Terminal U-PRES
C: Terminal S5V


K: Terminal SGND

(a) Terminal Layout
(b) DEF Pump Unit

(c) ACU Connector

DEF Pump Components

- DEF Pressure sensor
- Electric heater
- Motor
- Gear pump
- Filter



Code 4364 FMI 1 - Low Conversion Efficiency



1 | Low Conversion Efficiency | P20EE

Common Causes-

1. **Contamination in SCR – Diesel in DEF Tank**
2. **Oil in SCR – Check Turbo and Intake**
3. **Damaged SCR**
4. **Faulty Sensor**
5. **Faulty DEF Injector**

Kubota SPN: 4364 FMI: 1
P20EE – Low Conversion Efficiency

Code is active when averaged Post-NOx is greater than the NOx concentration estimated by NOx reduction efficiency (NOx out is higher than NOx in)



(1) Terminal Power (+12 V) (2) Terminal Ground (3) Terminal CAN2-L (4) Terminal CAN2-H (5) Terminal Ground (a) Terminal Layout (b) Pre NOx Sensor Assembly (c) ACU Connector



Temp Sensor Errors T0 T1 T2

T0 – Black Connector →

4765	0	Exhaust gas temperature sensor 0: High
	2	Invalid DOC Inlet Temperature (T0) Data
	3	Exhaust gas temperature sensor 0: High
	4	Exhaust gas temperature sensor 0: Low
3242	0	Exhaust gas temperature sensor 1: High
	3	Exhaust gas temperature sensor 1: High
	4	Exhaust gas temperature sensor 1: Low
3246	0	Exhaust gas temperature sensor 2: High
	3	Exhaust gas temperature sensor 2: High
	4	Exhaust gas temperature sensor 2: Low

T1 – Grey Connector →

T2 – White Connector →



- **T0** – Inlet Temp.
- **T1** – Intermediate Temp. between DOC and DPF.
- **T2** – Outlet Temp. to the Muffler.



Factory specification	
Temperature	Resistance
100 °C (212 °F)	Approx. 18.3 kΩ
150 °C (302 °F)	Approx. 7.88 kΩ
200 °C (392 °F)	Approx. 4.00 kΩ
250 °C (482 °F)	Approx. 2.30 kΩ

OK	Wiring harness open circuit or connector fault → Check and repair.
NG	Exhaust gas temperature sensor fault → Replace the exhaust gas temperature sensor 0 (T0).

(1) Terminal A-GND3

(2) Terminal IDOC